



## Contents

<b>52 - General information, Body</b>	<b>1</b>
<b>1 Safety information and repair notes</b>	<b>1</b>
1.1 Safety information	1
1.2 Repair instructions	1
<b>2 Basic information on bodywork repairs</b>	<b>2</b>
2.1 General notes on bodywork repairs	2
2.2 Original welding	11
2.3 New parts	11
2.4 Separating cuts	12
2.5 Body - subparts and part sections	12
2.6 Removing residues	12
2.7 Replacement joining techniques in repair work - steel	12
2.8 Replacement joining techniques in repair work - aluminium	13
<b>3 Explanation of symbols</b>	<b>14</b>
3.1 Symbols relating to procedures for separating components	14
3.2 Symbols relating to welding, brazing and soldering	14
3.3 Symbols for rivets	14
3.4 Symbols relating to preparations	15
3.5 Symbols for corrosion protection	15
<b>4 Assessing damage</b>	<b>16</b>
4.1 Measuring methods and damage diagnosis	16
4.2 Inspection of weld seams and cast nodes	17
4.3 Load paths	17
4.4 Alignment	18
4.5 Galvanized body parts, high/highest strength and hot-formed body panels	19
<b>5 Overview of the materials used</b>	<b>22</b>
5.1 Galvanized body parts	22
5.2 Deep-drawn steel	22
5.3 High-strength and ultra-high-strength steels	22
5.4 Hot-formed high-strength steel sheets	23
5.5 Aluminium	23
5.6 Mixture of several materials	24
<b>6 Joining and separating processes</b>	<b>25</b>
6.1 Drilling	25
6.2 Cutting	25
6.3 Sanding	25
6.4 Milling	25
6.5 Loosening adhesive bonds	26
6.6 Pulling out rivets which are only accessible from one side	26
6.7 Resistance spot welding	26
6.8 Hole spot welding, inert gas	28
6.9 Welding with continuous seam and quilting seam, inert gas	29
6.10 MIG welding	30
6.11 Aluminium welding	31
6.12 Gluing	31
6.13 Rivets	34
6.14 Solid rivet	35
6.15 Pop rivet	35
6.16 Riveting errors	37
6.17 Conical notched rivets	38
6.18 Overview of selective assembly processes with a forging device	39
6.19 Flow drill screws	39



6.20	Making a flow-drill screw connection, pre-drilled hole in upper part	40
6.21	Making a flow-drill screw connection, no pre-drilled hole in upper part	40
6.22	Making a flow-drill screw connection, exchanging upper and lower parts	40
6.23	Renewing friction-element-welded joints	41
6.24	Tools	41
<b>7</b>	<b>Repairing surfaces</b>	<b>42</b>
7.1	Dent removal technology	42
7.2	Remove dents without damaging the paint by applying pressure	42
7.3	Remove and pull dents outwards	42
7.4	Dent removal techniques for aluminium panels	42
7.5	Metal and aluminium mastic	43
7.6	Defining the surface with the correct contour and handover to the paint shop	43
<b>8</b>	<b>Corrosion prevention</b>	<b>45</b>
8.1	Corrosion protection of component parts and welded parts	45
8.2	Cavity sealing	45
<b>9</b>	<b>Noise insulation</b>	<b>47</b>
9.1	Removing and installing insulation for inner side of outer door panel	47
<b>10</b>	<b>Plastic repair</b>	<b>49</b>
10.1	Introduction	49
10.2	Distinction of types of plastic	49
10.3	Processing instructions - original products	54
10.4	Preparing plastic repair	56
10.5	Repairing deformation	58
10.6	Sealing plastic assembly parts	58
10.7	Welding plastic assembly parts	60
<b>11</b>	<b>General information - windows</b>	<b>69</b>
11.1	Removing broken window	69
11.2	Window repairs	69
<b>12</b>	<b>Disc repair</b>	<b>70</b>
12.1	Introduction	70
12.2	Preparing glass repair	71
12.3	Carrying out window repairs	72
<b>13</b>	<b>Use of adhesives</b>	<b>73</b>
13.1	Observe the general information on the use of adhesives	73
13.2	Minimum drying times for bonded windows	74
13.3	Preparing undamaged windows for fitting	74
13.4	Preparing new windows for installation	75
13.5	Preparing body flange for installation	76
13.6	Cleaning off excess adhesive	79
13.7	Installation instructions for bonded windows	80
13.8	Bonding log, inc. working sample for bonding operations that require documentation – introduction and overview	82
13.9	Bonding log	82
<b>14</b>	<b>Components with adhesive tapes</b>	<b>86</b>
14.1	Specifications for self-adhesive components	86
<b>15</b>	<b>Passive safety</b>	<b>88</b>
15.1	Passive safety	88
<b>16</b>	<b>Noises</b>	<b>89</b>
16.1	Overview of fitting locations – vibration damper film	89
16.2	Overview of fitting locations – noise insulation	89
16.3	Locating noises	90
16.4	Locating noises using audio recordings	92
16.5	Checklist - locating noises	94
<b>17</b>	<b>Preparation for disposal</b>	<b>98</b>



17.1	Preparing gas strut for disposal	98
17.2	Preparing covered gas strut for disposal	98
17.3	Preparing rear lid drive unit VX69/rear lid drive unit 2 VX77 for disposal	99
<b>18</b>	<b>Tightness of seal</b>	<b>101</b>
18.1	Causes of water ingress	101
18.2	Locating water ingress	105
18.3	Check list for locating water ingress	106