



Contents

00 - Technical data	1
1 Repair instructions	1
1.1 General repair instructions	1
1.2 Routing and attachment of lines	1
1.3 Notes on repair of CAN bus wiring	1
1.4 General information	1
91 - Communication	3
1 Infotainment system	3
1.1 Overview of fitting locations – Infotainment system	3
1.2 Removing and installing infotainment system display	4
1.3 Removing and installing control unit 1 for information electronics J794	5
1.4 Renewing rotary knobs for infotainment system display	7
1.5 Removing and installing chip card reader control unit J676	7
2 Sound system	9
2.1 Overview of fitting locations - sound system	9
2.2 Removing and installing digital sound package control unit/amplifier	11
2.3 Removing and installing bracket for digital sound package control unit J525	12
2.4 Removing and installing front treble loudspeakers R20/R22	13
2.5 Removing and installing rear treble loudspeakers R14/R16	13
2.6 Removing and installing front mid-range loudspeakers	13
2.7 Removing and installing front bass loudspeakers R21/R23	14
2.8 Removing and installing rear bass loudspeakers R15/R17	15
2.9 Removing and installing subwoofer R211	16
2.10 Removing and installing centre loudspeaker	17
3 Aerial systems	19
3.1 Overview of fitting locations - aerial systems	19
3.2 Removing and installing aerial module	21
3.3 Removing and installing TV aerial amplifier	22
3.4 Removing and installing frequency modulation (FM) frequency filter in negative wire R178	23
3.5 Removing and installing frequency modulation (FM) frequency filter in positive wire R179	24
3.6 Removing and installing roof aerial	24
3.7 Removing and installing bumper aerials	25
4 Telephone system	28
4.1 Overview of fitting locations - telephone system	28
4.2 Removing and installing telephone microphone R38	29
4.3 Removing and installing two-way signal amplifier for mobile telephone/data services J984	30
4.4 Removing and installing storage compartment with interface for mobile telephone R265	31
5 TV system	32
5.1 Overview of fitting locations - TV system	32
5.2 Removing and installing TV tuner	32
6 Multifunction steering wheel	35
6.1 Assembly overview - multifunction steering wheel	35
6.2 Removing and installing steering wheel multifunction buttons E441/E440	36
6.3 Removing and installing Tiptronic switch in steering wheel E439/E438	38
7 Connection for external multimedia devices	39
7.1 Removing and installing connection for external multimedia devices	39
7.2 Removing and installing USB charging socket 1 U37	41
7.3 Removing and installing USB hub R293	42
8 Car-Net	43
8.1 Overview of fitting locations - Car-Net services	43
8.2 Removing and installing emergency call module control unit and communication unit J949	44



8.3	Removing and installing Telematics button module E734	45
8.4	Removing and installing loudspeaker for emergency call module R335	46
8.5	Removing and adapting control unit for emergency call module	46
8.6	Removing and installing battery for control unit for emergency call module	47
8.7	Initial setup of ERA-GLONASS	48