



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions when working on a high-voltage system	1
1.2 Safety precautions when working in the vicinity of high-voltage components	2
2 Hazard classification for the high-voltage system	3
3 Repair instructions	4
3.1 General repair instructions	4
3.2 Routing and attachment of lines	4
3.3 Notes on repair of CAN bus wiring	4
3.4 Transmitting power and aerial fitting locations	4
91 - Radio, telephone, navigation	6
1 Infotainment system	6
1.1 Components of infotainment system	6
1.2 Overview of fitting locations – Infotainment system	13
1.3 Pin assignment	14
2 Sound system	15
2.1 Components of sound system	15
2.2 Overview of fitting locations – sound system	16
2.3 Assembly overview - sound system (passenger compartment)	17
2.4 Removing and installing amplifier R12 for digital sound package	18
2.5 Removing and installing rear treble loudspeakers R14/R16	19
2.6 Removing and installing front treble loudspeakers R20/R22	21
2.7 Removing and installing front mid-range loudspeakers R103/R104	21
2.8 Removing and installing rear bass loudspeakers R15/R17	22
2.9 Removing and installing front bass loudspeakers R21/R23	25
2.10 Removing and installing centre loudspeaker R208	27
2.11 Pin assignment	28
3 Aerial systems	31
3.1 Components of aerial systems	31
3.2 Overview of fitting locations – aerial systems	32
3.3 Removing and installing roof aerial R216	36
3.4 Removing and installing aerial module	38
4 Radio	48
4.1 Overview of radio	48
4.2 Overview of fitting locations – radio	48
4.3 Assembly overview – radio	49
4.4 Removing and installing radio	50
4.5 Pin assignment	53
4.6 Removing and installing operating button on display unit for front information display and operating unit control unit J685	61
5 Telephone system	62
5.1 Overview of telephone system	62
5.2 Preparation for mobile telephone	63
5.3 Overview of fitting locations – telephone system	64
5.4 Removing and installing telephone microphone R38	66
5.5 Removing and installing rear right microphone R145 for telephone system in rear passenger compartment	68
5.6 Removing and installing coupling aerial for Bluetooth mobile phone R309	68
5.7 Removing and installing two-way signal amplifier for mobile telephone/data services J984	70
5.8 Removing and installing loudspeaker control unit for telephone system in rear passenger compartment	71



5.9	Removing and installing mobile telephone operating electronics control unit J412 for telephone system in rear passenger compartment	73
5.10	Removing and installing telephone holder, telephone system in rear passenger compartment	74
5.11	Removing and installing handset for telephone system in rear passenger compartment, Business	76
5.12	Removing and installing adapter box for telephone system in rear passenger compartment, Business	77
6	Navigation system	80
6.1	Overview of navigation system	80
6.2	Overview of fitting locations – navigation system	80
6.3	Pin assignment	81
6.4	Removing and installing control unit for navigation system	81
7	Reversing camera	82
7.1	Components of reversing camera system	82
7.2	Overview of fitting locations - reversing camera system	83
7.3	Assembly overview - reversing camera	84
7.4	Removing and installing reversing camera R189	85
7.5	Calibrating reversing camera	95
8	Multifunction steering wheel	96
8.1	Overview of multifunction steering wheel	96
8.2	Assembly overview – multifunction steering wheel	96
8.3	Removing and installing multifunction buttons in steering wheel E441/E440	97
8.4	Removing and installing Tiptronic switch in steering wheel E439/E438	101
9	Connection for external multimedia devices	103
9.1	Connectors – connection for external multimedia devices	103
9.2	Removing and installing connection for external audio sources R199	104
9.3	Removing and installing USB hub R293	106
10	Wi-Fi internet access and global positioning system (GPS)	108
10.1	System overview - Wi-Fi internet access and global positioning system (GPS)	108
10.2	General description	109
10.3	Removing and installing internet access control unit J666	110
11	Rear Seat Entertainment (RSE)	116
11.1	Components of Rear Seat Entertainment system	116
11.2	Overview of fitting locations – Rear Seat Entertainment system	118
11.3	Assembly overview - rear seat entertainment system	119
11.4	Removing and installing multimedia system display unit 1 Y22	120
11.5	Removing and installing interface for multimedia systems J1176, rear seat entertainment system with 15.4-inch monitor	126
11.6	Removing and installing bulb for interior lighting, rear seat entertainment system with 10.2-inch monitor	127
11.7	Changing battery for multimedia system headphones R123/R124	128
11.8	Changing battery for multimedia system operating unit E380	131
11.9	Pin assignment – Rear Seat Entertainment system	132
11.10	Fuse assignment - rear seat entertainment system	133
12	Car-Net	135
12.1	Components of online services	135
12.2	Overview of fitting locations – mobile online services	138
12.3	Removing and installing emergency call module control unit and communication unit J949	139
12.4	Removing and installing loudspeaker for emergency call module R335	142