



Contents

00 - Technical data	1
1 Safety information	1
1.1 Safety precautions during work on fuel system	1
1.2 Safety precautions when working on vehicles with start/stop system	1
1.3 Safety precautions when using test and measuring instruments during a road test	2
1.4 Safety precautions when working on cooling system	2
1.5 Safety precautions when working on vehicles with auxiliary/supplementary heater	2
2 General information	4
2.1 Type plates	4
2.2 Starting conditions for auxiliary/supplementary heater	5
2.3 Rules for cleanliness when working on auxiliary/supplementary heater and fuel system ..	6
3 Repair notes	7
3.1 Notes on general repairs	7
82 - Supplementary heating	8
1 Overview of fitting locations - auxiliary/supplementary heater	8
1.1 Overview of fitting locations - components not located in passenger compartment	8
1.2 Overview of fitting locations - components located outside of passenger compartment, Caddy 2011▶	9
2 Auxiliary/supplementary heater	12
2.1 Overview of fitting locations - auxiliary/supplementary heater, Thermo Top V and Thermo Top fleece	12
2.2 Assembly overview - auxiliary/supplementary heater, internal	14
2.3 Assembly overview - auxiliary/supplementary heater attachments	18
2.4 Removing and installing auxiliary/supplementary heater	18
2.5 Dismantling and assembling auxiliary/supplementary heater	22
2.6 Removing and installing air intake silencer	22
2.7 Removing and installing circulation pump V55	23
2.8 Removing and installing exhaust system	24
2.9 Removing and installing silencer with bracket	25
2.10 Removing and installing auxiliary/supplementary heater bracket	25
2.11 Removing and installing cover	26
2.12 Removing and installing auxiliary heater control unit J364	26
2.13 Removing and installing glow plug with flame monitor Q8	27
2.14 Removing and installing temperature sensor G18 and overheating sensor G189 ..	28
2.15 Dismantling and assembling burner unit	29
3 Coolant circuit with auxiliary/supplementary heater	31
3.1 Coolant hose schematic diagram for vehicles with auxiliary heater, BCA	31
3.2 Coolant hose schematic diagram for vehicles with auxiliary heater, BGU	33
3.3 Coolant hose schematic diagram for vehicles with auxiliary heater, BJB	34
3.4 Coolant hose schematic diagram for vehicles with auxiliary heater, BDJ	35
3.5 Coolant hose schematic diagram for vehicles with auxiliary heater, CAYD and CAYE	36
3.6 Coolant hose schematic diagram for vehicles with auxiliary heater, CFCH, CFCE, CFCF, CLCA, CFHC, CFHE, CFHF and CFJA	37
3.7 Coolant hose schematic diagram for vehicles with auxiliary heater, CBZA and CBZB	38
3.8 Removing and installing heater coolant shut-off valve N279	38
4 Fuel supply system	40
4.1 Overview of fitting locations - fuel supply system	40
4.2 Removing and installing metering pump V54	41
4.3 Checking fuel delivery rate	42
5 Regulation of auxiliary/supplementary heater	45
5.1 Functional description of auxiliary heater Thermo Top V	45
5.2 Functional description of Thermo Top fleece	45



5.3	Supplementary heater mode	46
5.4	Auxiliary heater mode, Caddy ▶2011	47
5.5	Auxiliary heater mode, Caddy 2011▶	47
5.6	Switching off auxiliary/supplementary heater	48
6	Other controlling and regulating components	49
6.1	Removing and installing ambient temperature sensor	49
6.2	Removing and installing remote control receiver for auxiliary coolant heater R149	49
6.3	Functional description of remote control for auxiliary/supplementary heater	50