



Contents

00 - Technical data	1
1 Repair instructions	1
1.1 General repair instructions	1
1.2 Routing and attachment of lines	1
1.3 Notes on repair of CAN bus wiring	1
1.4 Transmitting power and aerial fitting locations	2
91 - Radio, telephone, navigation	3
1 Infotainment system	3
1.1 Overview of fitting locations – Infotainment system	3
1.2 Removing and installing control unit for front display and information control panel	5
1.3 Removing and installing control unit 1 for information electronics J794	6
1.4 Renewing rotary knobs of display unit for front information display and operating unit control unit J685	7
2 Sound system	9
2.1 Overview of fitting locations - sound system	9
2.2 Removing and installing front treble loudspeakers R20/R22	9
2.3 Removing and installing front bass loudspeakers R21/R23	10
2.4 Removing and installing rear broadband loudspeaker R385/R386	11
3 Aerial systems	13
3.1 Overview of fitting locations - aerial systems	13
3.2 Removing and installing aerial module	14
3.3 Removing and installing roof aerial	16
4 Telephone system	18
4.1 Overview of fitting locations - telephone system	18
4.2 Removing and installing telephone microphone R38	19
4.3 Removing and installing storage compartment with interface for mobile telephone R265	20
4.4 Removing and installing two-way signal amplifier for mobile telephone/data services J984	21
5 Multifunction steering wheel	23
5.1 Assembly overview - multifunction steering wheel	23
5.2 Removing and installing steering wheel multifunction buttons E440/E441	23
5.3 Removing and installing Tiptronic switch in steering wheel E439/E438	25
6 Connection for external multimedia devices	27
6.1 Removing and installing USB connection U41/U42	27
7 Car-Net	29
7.1 General description – Car-Net services	29
7.2 Overview of fitting locations - Car-Net services	29
7.3 Removing and installing emergency call module control unit and communication unit J949	30
7.4 Removing and installing battery in emergency call module control unit and communication unit J949	32
7.5 Removing and installing loudspeaker for emergency call module R335	33
7.6 Removing and installing emergency assistance call button E276	33
7.7 Bringing ERA-GLONASS into operation	34