



Contents

00 - Technical data	1
1 Notes on operating mobile telephones and two-way radios	1
1.1 General information	1
1.2 Notes on performing repair work	2
1.3 Overview of battery, transmitter and receiver unit, fuse and wiring harness	3
1.4 Transmitting power and aerial fitting locations	5
2 Suppression measures	6
2.1 Implementation of suppression measures	6
91 - Communication	7
1 Radio / radio navigation systems	8
1.1 Components of radio / radio navigation systems	8
1.2 Overview of fitting locations - radio/radio navigation systems	13
1.3 Removing and installing radio and radio/navigation systems	14
1.4 Pin assignments	17
2 Sound system	20
2.1 Overview of fitting locations - sound system	20
2.2 Removing and installing front bass loudspeakers	21
2.3 Removing and installing rear bass loudspeakers	22
2.4 Removing and installing front treble loudspeakers	23
3 Aerial systems	25
3.1 General information	25
3.2 Overview of fitting locations - aerial systems	25
3.3 Removing and installing roof aerial	26
3.4 Repairing aerial cables	27
4 Car-Net	28
4.1 General information	28
4.2 Overview of fitting locations - Car-Net services	28
4.3 Removing and installing emergency call module control unit and communication unit J949	28