



Contents

50 - Body - front	1
1 Body - front section	1
1.1 Front end with complementary parts - assembly overview	1
1.2 Front end with complementary parts - remove and install	1
1.3 Front end with complementary parts - service position	3
1.4 Front wing - assembly overview	5
1.5 Engine compartment upper partition panel - assembly overview	6
55 - Bonnet, rear lid	8
1 Bonnet	8
1.1 Bonnet - assembly overview	8
1.2 Bonnet - remove and install	9
1.3 Bonnet - adjust	9
1.4 Bonnet hinge - remove and install	11
1.5 Bonnet latch operation cable - assembly overview	11
1.6 Bonnet latch Bowden cable - remove and install	12
1.7 Bonnet upper latch - remove and install	14
1.8 Bonnet lower latch - remove and install	15
2 Rear lid (Gol)	17
2.1 Rear lid - assembly overview	17
2.2 Rear door shock absorber - remove and install	18
2.3 Rear lid shock absorber - depressurize	18
2.4 Rear lid trim - remove and install	19
2.5 Rear lid - remove and install	19
2.6 Rear lid hinge - remove and install	20
2.7 Rear lid - adjust	21
2.8 Housing with latch cylinder - assembly overview	23
2.9 Housing with Latch cylinder - remove and install	23
2.10 Latch cylinder - remove and install	24
2.11 Door latch - remove and install	25
2.12 Rear lid unlocking motor V139 - remove and install	26
3 Rear lid (Voyage)	28
3.1 Rear lid - assembly overview	28
3.2 Rear lid - remove and install	29
3.3 Rear lid trim - remove and install	30
3.4 Rear lid hinge - assembly overview	30
3.5 Rear lid hinge - remove and install	31
3.6 Rear lid - adjust	33
3.7 Housing with latch cylinder - assembly overview	36
3.8 Housing with Latch cylinder - remove and install	37
3.9 Latch cylinder - remove and install	38
3.10 Door latch - remove and install	38
3.11 Rear lid unlocking motor V139 - remove and install	39
4 Rear lid (Saveiro)	41
4.1 Rear lid striker - adjust	41
4.2 Rear lid striker - lubricate	42
4.3 Rear lid lock - assembly overview	43
4.4 Rear cover lock - remove and install	43
4.5 Rod drive - assembly overview	44
4.6 Rod driver - remove and install	45
4.7 Rear lid handle with cylinder - assembly overview	46
4.8 Rear lid handle with cylinder - remove and install	47
4.9 Tailgate sustaining cable - remove and install	47



4.10	Latch cylinder - remove and install	48
4.11	Tailgate damper - remove and install	49
4.12	Rear lid shock absorber - depressurize	49
4.13	Rear lid - remove and install	50
4.14	Rear lid - adjust	51
4.15	Rear lid hinge - remove and install	52
5	Fuel reservoir nozzle compartment and lid set	54
5.1	Fuel reservoir nozzle compartment lid (Gol and Voyage) - remove and install	54
5.2	Fuel reservoir nozzle compartment lid (Saveiro) - remove and install	55
57	Front doors, door components, central locking	57
1	Front door	57
1.1	Tools	57
1.2	Front door - assembly overview	58
1.3	Front door - remove and install	59
1.4	Front door - adjusting	60
1.5	Front door - disassemble and assemble	63
1.6	Front door - replace	63
1.7	Front door arrester - adjust	63
1.8	Front door tether - remove and install	64
1.9	Internal handle - replace	65
1.10	Front door external handle and lock - assembly overview	65
1.11	Lock cylinder housing - remove and install	67
1.12	Latch cylinder - remove and install	68
1.13	Door handle - remove and install	68
1.14	Front door exterior handle - replace	70
1.15	Front door lock - remove and install	70
1.16	Lock button (locking rod) - remove and install	72
1.17	Front door lock - replace	72
1.18	Lock Bowden cable - replace	73
1.19	Door sealing membrane - remove and install	73
1.20	Internal front lid trim - remove and install	75
2	Central locking system	77
2.1	Central locking installation locations overview	77
2.2	Battery of key with radio remote command (articulated) - assembly overview	83
2.3	Battery of key with radio remote command (articulated) - remove and install	83
2.4	Key - synchronize	84
58	Rear doors, door components	86
1	Rear passenger doors	86
1.1	Rear passenger doors - assembly overview	86
1.2	Rear passenger door - remove and install	87
1.3	Rear passenger door - adjust	88
1.4	Rear passenger door - disassemble and assemble	91
1.5	Rear door - replace	91
1.6	Rear door arrester - adjust	91
1.7	Door limiter - remove and install	92
1.8	Internal handle - replace	93
1.9	Rear door external handle and lock - assembly overview	93
1.10	External handle housing - remove and install	95
1.11	External door handle - remove and install	96
1.12	External door handle - replace	98
1.13	Door lock - remove and install	98
1.14	Door lock - replace	102
1.15	Lock button (locking rod) - remove and install	102
1.16	Lock Bowden cable - replace	103



1.17	Door sealing membrane - remove and install	103
1.18	Internal door trim - remove and install	105
61	Convertible roof, hardtop, canopy	107
1	Tonneau cover (Saveiro)	107
1.1	Dropside - assembly overview	107
1.2	Tonneau cover - remove and install	108
1.3	Tonneau cover longitudinal member - assembly overview	111
1.4	Tonneau cover longitudinal member - remove and install	111
1.5	Longitudinal member of the tonneau cover (Saveiro Cross ◀10/06/2014) - replace	112
63	Bumpers	114
1	Front bumper	114
1.1	Front bumper protector - assembly overview	114
1.2	Front protector - remove and install	114
1.3	Fastening of the front license plate - install	117
1.4	Front license plate fastening (Gol Rallye / Saveiro Cross)- install	117
1.5	Front protector support - assembly overview	118
1.6	Brackets for the parking aid sensors - install	118
2	Rear bumper (Gol)	124
2.1	Rear protector - assembly overview	124
2.2	Rear protector - remove and install	125
2.3	Rear license plate fastening - install	128
2.4	Foamed rear protector support - assembly overview	128
2.5	Brackets for the parking aid sensors - install	129
3	Rear bumper (Voyage)	135
3.1	Rear protector - assembly overview	135
3.2	Rear protector - remove and install	136
3.3	Rear license plate fastening - install	139
3.4	Foamed rear protector support - assembly overview	140
3.5	Brackets for the parking aid sensors - install	140
4	Rear bumper (Saveiro)	146
4.1	Support and side protector - assembly overview	146
4.2	Side protector - remove and install	146
4.3	Support and central protector - assembly overview	147
4.4	Central protector - remove and install	148
4.5	Rear license plate fastening - install	150
64	Glazing	151
1	Repair instructions	151
1.1	Tools	151
1.2	Auxiliary materials - Brazilian market	153
1.3	Auxiliary materials - export market	154
1.4	Matching table	154
1.5	Stickers for engraving the VIS number on the windows (only for Brazil) - supply	155
1.6	Undamaged glass - prepare for install	155
1.7	New glass - prepare for install	155
1.8	Body flange - prepare to install the window	156
1.9	Assembly instructions	157
1.10	Minimum adhesive drying time	158
1.11	Paint damage - repair	159
1.12	Cleaning in case of resulting adhesive residues	160
1.13	Data stickers	160
2	Windscreen	162
2.1	Windscreen - assembly overview	162



2.2	Windscreen - remove	162
2.3	Windscreen - install	163
3	Side window	164
3.1	Rear side glass (2-door Gol) - assembly overview	164
3.2	Undamaged rear side glass (2-door Gol) - remove	164
3.3	Damaged rear side glass (2-door Gol) - remove	165
3.4	Rear side glass (2-door Gol) - install	166
3.5	Fixed rear side window (Saveiro "extended cab") - assembly overview	166
3.6	Undamaged fixed rear side window (Saveiro "extended cab") - remove	167
3.7	Damaged fixed rear side window (Saveiro "extended cab") - remove	168
3.8	Fixed rear side window (Saveiro "extended cab") - install	168
3.9	Rear side window (Saveiro "double cab") - assembly overview	168
3.10	Rear side window (Saveiro "extended cab") - remove and install	170
4	Rear window	172
4.1	Rear window (Gol) - assembly overview	172
4.2	Undamaged rear window (Gol) - remove	172
4.3	Damaged rear window (Gol) - remove	173
4.4	Rear window (Gol) - install	174
4.5	Rear window (Voyage) - assembly overview	174
4.6	Undamaged rear window (Voyage) - remove	174
4.7	Damaged rear window (Voyage) - remove	175
4.8	Rear window (Voyage) - install	176
4.9	Fixed rear window (Saveiro "single cab") - assembly overview	176
4.10	Fixed rear window (Saveiro "extended cab") - assembly overview	177
4.11	Fixed rear window (Saveiro "double cab") - assembly overview	178
4.12	Sliding rear window (Saveiro "single cab") - assembly overview	179
4.13	Sliding rear window (Saveiro "extended cab") - assembly overview	180
4.14	Undamaged fixed or sliding rear window (Saveiro) - remove	180
4.15	Rear fixed or sliding window (Saveiro) - install	182
5	Door window glass	183
5.1	Front door window glass - assembly overview	183
5.2	Front door window glass - remove and install	183
5.3	Rear door window glass - assembly overview	184
5.4	Rear door window glass - remove and install	185
5.5	Rear door fixed window - assembly overview	186
5.6	Undamaged fixed rear door window - remove	187
5.7	Damaged fixed rear door window - remove	188
5.8	Fixed rear door window - install	188
6	Window drive mechanism	189
6.1	Convenience system window drive mechanism (automatic window closing and opening mechanism) with force limiter (anti-crushing function)	189
6.2	Central control unit for glass command J1015 - remove and install	191
6.3	Window drive mechanism - remove and install	192
6.4	Window drive motor V147/ V148 - remove and install	193
6.5	Front door window crank - remove and install	194
6.6	Rear door window drive mechanism - remove and install	195
6.7	Rear window control motor V26 / V27 - remove and install	196
6.8	Rear door window drive crank - remove and install	197
7	Window channels and trim strips	198
7.1	Front door window channel - remove and install	198
7.2	Front door window internal trim - remove and install	198
7.3	Front door window external trim - replace	198
7.4	Rear door window channel - remove and install	199
7.5	Rear door window internal trim - remove and install	199
7.6	Rear door window external trim - replace	199



66 - Exterior equipment	201
1 Materials used and operational care required	201
1.1 Auxiliary materials for Brazilian market	201
1.2 Auxiliary materials for export market	201
1.3 Matching table	202
1.4 Paint damage - repair	202
1.5 Cleaning in case of dirt residues resulting from handling of polyurethane adhesive (PU) ..	203
1.6 Minimum adhesive drying time	203
2 Wheel arch protector	204
2.1 Front wheel arch protector - remove and install	204
2.2 Rear wheel arch protector - remove and install	205
3 External rear-view mirror	206
3.1 External rear-view mirror - assembly overview	206
3.2 External rearview mirror - assembly overview - continued	207
3.3 Exterior rear-view mirror - remove and install	207
3.4 Mirror glass - remove and install	208
3.5 Mirror glass - remove and install	209
3.6 Turn signal (Blinker) - remove and install	210
4 External linings	211
4.1 Windscreen lower trim - assembly overview	211
4.2 Windscreen lower trim - remove and install	211
4.3 External linings on pillars and doors - replace	212
4.4 External B-pillar coverings (Saveiro - single cab) - replace	214
4.5 Footwell cover (Saveiro) - replace	215
4.6 Side member trim external lining (►06.15)- replace	217
4.7 Side member trim external lining (Gol Rallye 06.15►) - replace	218
4.8 Side member trim external lining (Saveiro Cross e Saveiro Surf 06.15►) - replace	220
4.9 External lining of lower longitudinal member (Gol and Saveiro Rock in Rio) - replace	222
5 Side trims, roof	225
5.1 Front door trims - replace	225
5.2 Rear door trims - replace	226
5.3 Side trims (Gol - 2-door) - replace	228
5.4 Side trims (Saveiro Cross) - assembly overview	231
5.5 Front door trim (Saveiro Cross) - replace	232
5.6 Rear side panel trim (Saveiro Cross) - replace	234
5.7 Door trims (Voyage Evidence) - replace	237
5.8 Decorative side strip (Gol Rallye / Track / Seleção / Cup and Voyage Seleção) - replace	239
5.9 Rear protector decorative strip (Gol Rallye and Gol Track) - replace	241
5.10 Decorative side stripe (Saveiro Trooper) - replace	242
5.11 Decorative side stripe (Saveiro SURF) - replace	244
5.12 Rear cover trim (Voyage) - replace	246
5.13 Roof trim - assembly overview	247
5.14 Roof lining (Saveiro) - remove and install	248
6 Front grid, front protector grids, rear protector frames	250
6.1 Radiator grille - assembly overview	250
6.2 Radiator grille strips - assembly overview	251
6.3 Front protector grilles - assembly overview	252
6.4 Front protector central and lateral grid strips - assembly overview	254
6.5 Front protector central and lateral grid strips - remove and install	254
7 Side member trim	256
7.1 Longitudinal lower trim (Gol Rallye and Gol Track) - general assembly overview	257
7.2 Longitudinal lower trim (Gol Rallye and Gol Track) - replace	257
7.3 Longitudinal member lower trim (Saveiro Cross) - assembly overview	262



7.4	Longitudinal member lower trim (Saveiro Cross) - replace	262
8	Rear wing and side panel trim	266
8.1	Front protector trim (Saveiro and Gol Track) - assembly overview	267
8.2	Front protector trim (Saveiro and Gol Track) - replace	267
8.3	Front protector trim (Saveiro Cross and Gol Rallye) - assembly overview	268
8.4	Front protector trim (Saveiro Cross and Gol Rallye) - replace	269
8.5	Front wing trim (Saveiro) - assembly overview	270
8.6	Front wing trim (Saveiro) - replace	271
8.7	Front wing trim (Saveiro Cross) - assembly overview	273
8.8	Front wing trim (Saveiro Cross) - replace	274
8.9	Front wing trim (Gol Rallye) - assembly overview	276
8.10	Front wing trim (Gol Rallye) - replace	277
8.11	Rear side panel trim (Saveiro) - assembly overview	280
8.12	Rear side panel trim (Saveiro) - replace	281
8.13	Rear side panel trim (Saveiro Cross) - assembly overview	282
8.14	Rear side panel trim (Saveiro Cross) - replace	283
8.15	Rear side panel trim (Gol Rallye and Gol Track) - general assembly overview	285
8.16	Rear side panel trim (Gol Rallye and Gol Track) - replace	286
8.17	Rear side protector trim (Saveiro) - replace	289
8.18	Front protective trim (Gol Rallye) - remove and install	291
9	Cargo compartment and frames protector (Saveiro)	293
9.1	Upper tailgate frame - replace	293
9.2	Cargo compartment upper frame - replace	294
9.3	Bedliner grid - assembly overview	297
9.4	Cargo compartment protection grid - remove and install	298
9.5	External B-pillar frame - replace	299
9.6	Rear window glass upper and lower frame - remove and install	302
9.7	Bedliner - assembly overview	303
9.8	Bedliner - remove and install	304
9.9	Cargo tying adjustable hooks track (vehicle without tonneau cover) - remove and install	305
9.10	Cargo tying adjustable hooks track (vehicle with tonneau cover) - remove and install	306
9.11	Cargo compartment adjustable hooks - remove and install	307
10	Spare wheel support (Saveiro)	309
10.1	Spare wheel support (Saveiro) - assembly overview	309
10.2	Spare wheel support (Saveiro) - remove and install	310
11	Front grid, front protector grids, rear protector frames	312
11.1	Front spoiler (Saveiro Cross and Gol Rallye) - assembly overview	312
11.2	Front spoiler (Saveiro Cross and Gol Rallye) - remove and install	312
11.3	Front protector central grille (Saveiro Cross and Gol Rallye) - assembly overview	313
11.4	Front protector central grid (Saveiro Cross and Gol Rallye) - remove and install	314
11.5	Front protector side grille (Saveiro Cross and Gol Rallye) - assembly overview	315
11.6	Front protector side grid (Saveiro Cross and Gol Rallye) - remove and install	316
11.7	Lower rear protector frame (Saveiro Cross) - replace	317
11.8	Lower rear side protector frame (Saveiro Cross) - replace	319
11.9	Rear lower spoiler (Gol Rallye) - replace	321
12	Roof rack (Saveiro)	325
12.1	Roof rack (single cab) - assembly overview	325
12.2	Roof rack (single cab) - remove and install	325
12.3	Roof rack (extended and double cab) - assembly overview	328
12.4	Roof rack (extended and double cab) - remove and install	328
12.5	Roof rack (Saveiro Cross) - assembly overview	330
12.6	Roof rack (Saveiro Cross) - remove and install	330
12.7	Roof rack extension (Saveiro Cross) - assembly overview	332
12.8	Roof rack extensor (Saveiro Cross) - remove and install	332
12.9	Roof rack extensor cover (Saveiro Cross) - remove and install	334



12.10	Bed rack (Saveiro Cross “extended cab”) - assembly overview	335
12.11	Cargo compartment rack (Saveiro Cross “extended cab”) - remove and install	335
13	Badges	338
13.1	Volkswagen Badge - replace	338
13.2	Model badge - replace	340
13.3	(1.6) version badge - replace	341
13.4	(MSI) version badge - replace	342
13.5	“Imotion” Badge - replace	343
13.6	“Rallye” (Gol Rallye ►02.14) and “TRACK”lettering - replace	344
13.7	“Rallye” lettering (Gol Rallye 02.14►) - replace	345
13.8	“Seleção” lettering (Gol Seleção MY 14 ►) - replace	346
13.9	“Seleção” lettering (Voyage Seleção MY 14 ►) - replace	347
13.10	“Bandeira” lettering (Gol Seleção MY 14 ►) - replace	348
13.11	“Bandeira” lettering (Voyage 1.0L Seleção MY 14 ►) - replace	349
13.12	“Bandeira” lettering (Voyage 1.6L Seleção MY 14 ►) - replace	350
13.13	Version badge (Bluemotion Technology) - replace	352
13.14	(GT) version badge - replace	353
13.15	“VW Adhesive” lettering (Rear Window - Gol Seleção MY 14 ►) - replace	353
13.16	“VW Adhesive” lettering (Rear Window - Voyage Seleção MY 14 ►) - replace	354
13.17	Version badge (door) - replace	355
13.18	“SPORTLINE” Badge - replace	356
13.19	“CBF”lettering on the front wing (Gol and Voyage Seleção MY 14 ►) - replace	357
13.20	Version badge (Seleção) on ashtray - replace	357
13.21	Version badge “SURF ”on the front fender (Saveiro) - replace	358
13.22	“Saveiro Cross” and “Saveiro” badge on the tailgate - replace	359
13.23	Version badge “Fun” - replace	361
13.24	Version badge “Evidence” on the front fender (Voyage) - replace	364
13.25	Version badge (Rock in Rio) on front wing - replace	366
13.26	Side decorative strip (Gol Rock in Rio) - replace	368
13.27	Side decorative strip (Saveiro Rock in Rio) - replace	369
13.28	Decorative stripe on the rear protector (Gol Rock in Rio) - replace	372
13.29	Decorative stripe on the rear protector (Saveiro Rock in Rio) - replace	373
13.30	Version badge (Rock in Rio) on ashtray - replace	374
14	Spoiler	376
14.1	Roof spoiler (Gol) - assembly overview	376
14.2	Observations for the execution of the removal and installation of the spoiler	377
14.3	Removal	377
14.4	Installation	379
14.5	Roof spoiler (Voyage) - assembly overview	385
14.6	Observations for the execution of the removal and installation of the spoiler	386
14.7	Removal	386
14.8	Installation	388
15	Saveiro Cross components	394
15.1	Saveiro Cross components - assembly overview	394
16	Gol Rallye Components	395
16.1	Gol Rallye Components - assembly overview	395