



## Contents

<b>00 - Technical data</b> .....	<b>1</b>
<b>1 Vehicle identification data</b> .....	<b>1</b>
1.1 Vehicle identification number (VIN) - localization .....	1
1.2 Destructive labels (Brazil only) - VIS .....	1
1.3 Destructive labels (Brazil only) - VIS - replacement .....	2
1.4 Front panel label - location .....	2
1.5 Body identification plate .....	3
1.6 Identification number - corrosion protection .....	4
<b>2 Zinc-coated body parts</b> .....	<b>5</b>
<b>3 High-strength body plat</b> .....	<b>6</b>
<b>4 Foam parts/support</b> .....	<b>11</b>
<b>5 Body clearance dimensions</b> .....	<b>14</b>
5.1 Front body section .....	14
5.2 Front body section (Saveiro) .....	17
5.3 Central body section (4-door Gol) .....	18
5.4 Central body section (2-door Gol) .....	20
5.5 Body - central section (Saveiro) .....	21
5.6 Rear body section (Gol) .....	22
5.7 Rear body section (Voyage) .....	24
5.8 Rear body section (Saveiro) .....	27
<b>6 Body dimensions</b> .....	<b>30</b>
6.1 Body - front section .....	30
6.2 Body - central section (4-door Gol and Voyage) .....	39
6.3 Body - central section (2-door Gol) .....	46
6.4 Body - central section (Saveiro) .....	49
6.5 Body - rear section (Gol) .....	54
6.6 Body - rear section (Voyage) .....	57
6.7 Body - rear section (Saveiro extended cab) .....	62
6.8 Body - rear section (Saveiro extended cab) .....	64
6.9 Body - rear section (Saveiro single cab) .....	66
6.10 Body - rear section (All) .....	69
6.11 Body - lower front section .....	70
6.12 Body - central lower section (Gol and Voyage) .....	74
6.13 Body - central lower section (Saveiro) .....	76
6.14 Body - Rear lower section (Gol) .....	78
6.15 Body - rear lower section (Voyage) .....	81
6.16 Body - rear lower section (Saveiro) .....	83
<b>50 - Body - front</b> .....	<b>85</b>
<b>1 Engine support (engine support, right side) - replace</b> .....	<b>85</b>
1.1 Remove .....	85
1.2 Install .....	86
<b>2 Suspension wedges (Saveiro) - replace</b> .....	<b>88</b>
2.1 Remove .....	88
2.2 Install .....	89
<b>3 Hinge support - replace</b> .....	<b>90</b>
3.1 Remove .....	90
3.2 Install .....	91
<b>4 Wheel case (upper part) - replace</b> .....	<b>93</b>
4.1 Remove .....	93
4.2 Install .....	94



<b>5</b>	<b>Wheel housing reinforcement - replace</b>	<b>96</b>
5.1	Remove	96
5.2	Install	98
<b>6</b>	<b>Front wheel arch - replace</b>	<b>100</b>
6.1	Remove	100
6.2	Install	101
<b>7</b>	<b>Front wheel housing - partial part - replace</b>	<b>103</b>
7.1	Remove	103
7.2	Install	104
<b>8</b>	<b>Front longitudinal member - replace</b>	<b>107</b>
8.1	Remove	107
8.2	Install	108
<b>9</b>	<b>Front longitudinal member - partial part - replace</b>	<b>110</b>
9.1	Remove	110
9.2	Install	111
<b>10</b>	<b>Fastening support for the front panel - replace</b>	<b>113</b>
10.1	Remove	113
10.2	Install	114
<b>11</b>	<b>Threads of the assembly mounting fastening points - repair</b>	<b>115</b>
11.1	Thread - repair by inserting new thread	117
<b>51 - Body - centre</b>		<b>119</b>
<b>1</b>	<b>Roof (Gol) - replace</b>	<b>119</b>
1.1	Remove	119
1.2	Install	121
<b>2</b>	<b>Roof (Voyage) - replace</b>	<b>124</b>
2.1	Remove	124
2.2	Install	125
<b>3</b>	<b>Roof (Saveiro - extended cab) - replace</b>	<b>128</b>
3.1	Remove	128
3.2	Install	129
<b>4</b>	<b>Roof (Saveiro - extended cab) - replace</b>	<b>133</b>
4.1	Remove	133
4.2	Install	134
<b>5</b>	<b>Roof (Saveiro - single cab) - replace</b>	<b>138</b>
5.1	Remove	138
5.2	Install	139
<b>6</b>	<b>Front roof cross member - replace</b>	<b>143</b>
6.1	Remove	143
6.2	Install	144
<b>7</b>	<b>Roof reinforcement - replace</b>	<b>145</b>
7.1	Remove	145
7.2	Welding	146
<b>8</b>	<b>Rear roof cross member (Gol) - replace</b>	<b>147</b>
8.1	Remove	147
8.2	Install	148
<b>9</b>	<b>Rear roof cross member (Voyage) - replace</b>	<b>150</b>
9.1	Remove	150
9.2	Install	151
<b>10</b>	<b>Rear roof cross member (Saveiro - single cab) - replace</b>	<b>153</b>
10.1	Remove	153
10.2	Install	154
<b>11</b>	<b>Rear roof cross member (Saveiro - extended cab) - replace</b>	<b>157</b>



11.1	Remove	157
11.2	Install	158
<b>12</b>	<b>Rear roof cross member (Saveiro - extended cab) - replace</b>	<b>160</b>
12.1	Remove	160
12.2	Install	161
<b>13</b>	<b>Side panel (partial part - 2-door Gol) - replace</b>	<b>163</b>
13.1	Remove	163
13.2	Install	165
<b>14</b>	<b>Pillar A - replace</b>	<b>172</b>
14.1	Remove	172
14.2	Install 1	174
<b>15</b>	<b>Internal section of A pillar - replace</b>	<b>177</b>
15.1	Remove	177
15.2	Install	179
<b>16</b>	<b>Pillar B - external section (Gol and Voyage) - replace</b>	<b>182</b>
16.1	Remove	182
16.2	Install	183
<b>17</b>	<b>B-pillar (2-door Gol - internal section) - replace</b>	<b>185</b>
17.1	Remove	185
17.2	Install	186
<b>18</b>	<b>Pillar B - internal section (Gol and Voyage) - replace</b>	<b>190</b>
18.1	Remove	190
18.2	Install	191
<b>19</b>	<b>B-Pillar - internal section (Saveiro - extended cab) - replace</b>	<b>193</b>
19.1	Remove	193
19.2	Install	194
<b>20</b>	<b>Pillar B - internal section (Saveiro - extended cab) - replace</b>	<b>196</b>
20.1	Remove	196
20.2	Install	197
<b>21</b>	<b>B-Pillar reinforcement (Saveiro - extended cab) - replace</b>	<b>199</b>
21.1	Remove	199
21.2	Install	200
<b>22</b>	<b>Pillar C - internal section (Saveiro - extended cab) - replace</b>	<b>202</b>
22.1	Remove	202
22.2	Install	203
<b>23</b>	<b>External side panel reinforcement (Saveiro) - replace</b>	<b>205</b>
23.1	Remove	205
23.2	Install	206
<b>24</b>	<b>Lower Longitudinal member - external section (Gol and Voyage) - replace</b>	<b>208</b>
24.1	Remove	208
24.2	Install	210
<b>25</b>	<b>Lower longitudinal member (2-door Gol - external section) - replace</b>	<b>213</b>
25.1	Remove	213
25.2	Install	215
<b>26</b>	<b>Lower longitudinal member reinforcement (2-door Gol) - replace</b>	<b>219</b>
26.1	Remove	219
26.2	Install	221
<b>27</b>	<b>Lower longitudinal member reinforcement (Gol and Voyage) - replace</b>	<b>225</b>
27.1	Remove	225
27.2	Install	226
<b>28</b>	<b>Floor - partial part - replace</b>	<b>229</b>
28.1	Remove	229
28.2	Install	232



<b>53 - Body - rear</b> .....	<b>236</b>
<b>1 Rear panel (with rear cross member - Gol) - replace</b> .....	<b>236</b>
1.1 Remove .....	236
1.2 Install .....	238
<b>2 Rear panel (with rear cross member - Voyage) - replace</b> .....	<b>241</b>
2.1 Remove .....	241
2.2 Install .....	244
<b>3 Rear cross member (Gol) - replace</b> .....	<b>248</b>
3.1 Remove .....	248
3.2 Install .....	249
<b>4 Luggage compartment floor complement reinforcement (Voyage) - replace</b> .....	<b>251</b>
4.1 Remove .....	251
4.2 Install .....	252
<b>5 Tail light housing (Gol) - replace</b> .....	<b>254</b>
5.1 Remove .....	254
5.2 Install .....	255
<b>6 Tail light housing (Voyage) - replace</b> .....	<b>257</b>
6.1 Remove .....	257
6.2 Install .....	258
<b>7 Tail light housing (Saveiro) - replace</b> .....	<b>260</b>
7.1 Remove .....	260
7.2 Install .....	261
<b>8 Bucket floor reinforcement (Saveiro) - replace</b> .....	<b>263</b>
8.1 Remove .....	263
8.2 Install .....	264
<b>9 Luggage compartment floor (partial - Gol) - replace</b> .....	<b>266</b>
9.1 Remove .....	266
9.2 Install .....	268
<b>10 Luggage compartment floor complement (Voyage) - replace</b> .....	<b>270</b>
10.1 Remove .....	270
10.2 Install .....	271
<b>11 Rear longitudinal member (partial part - Gol) - replace</b> .....	<b>273</b>
11.1 Remove .....	273
11.2 Install .....	274
<b>12 Rear longitudinal member (partial part - Voyage) - replace</b> .....	<b>277</b>
12.1 Remove .....	277
12.2 Install .....	278
<b>13 Rear longitudinal member (partial part - Saveiro) - replace</b> .....	<b>280</b>
13.1 Remove .....	280
13.2 Install .....	281
<b>14 Side panel (partial part - 4-door Gol) - replace</b> .....	<b>283</b>
14.1 Remove .....	283
14.2 Install .....	285
<b>15 Side panel (partial part - Voyage) - replace</b> .....	<b>292</b>
15.1 Remove .....	292
15.2 Install .....	296
<b>16 Side panel (partial part - Saveiro - extended cab) - replace</b> .....	<b>304</b>
16.1 Remove .....	304
16.2 Install .....	307
<b>17 Side panel (partial part - Saveiro - extended cab) - replace</b> .....	<b>312</b>
17.1 Remove .....	312
17.2 Install .....	315



<b>18</b>	<b>Side panel (partial part - Saveiro - extended cab) - replace</b> .....	<b>320</b>
18.1	Remove .....	320
18.2	Install .....	323
<b>19</b>	<b>Wheel arch (2-door Gol - external section ) - replace</b> .....	<b>328</b>
19.1	Remove .....	328
19.2	Install .....	332
<b>20</b>	<b>Spare wheel housing (Gol and Voyage) - replace</b> .....	<b>339</b>
20.1	Remove .....	339
20.2	Install .....	340
<b>21</b>	<b>Cargo compartment floor (partial - Saveiro) - replace</b> .....	<b>342</b>
21.1	Remove .....	342
21.2	Install .....	343