



Contents

00 - Technical data	1
1 General information	1
1.1 General information	1
2 Electric components	2
2.1 Diagnostics	2
2.2 Locating defects and indicating faults	2
91 - Radio, telephone, navigation	3
1 Infotainment	3
1.1 Infotainment - architecture	3
1.2 Infotainment System - assembly overview	4
1.3 Connector pinout	13
2 Loudspeaker systems	20
2.1 Front bass speakers R21 and/or R23 - replace	20
2.2 Rear bass speakers R15 and/or R17 - replace	21
2.3 Front treble speaker R20 and/or R22 (front tweeter) - replace	24
3 Antenna system	26
3.1 Aerial R11 - assembly overview	26
3.2 Aerial R11 - remove and install	26
3.3 Antenna cable - assembly overview	28
3.4 Aerial cable - remove and install	30
4 Radio	35
4.1 Radio - remove and install	35
5 Phone system	47
5.1 Telephone microphone R38 - remove and install	47
5.2 USB connector inlet base (MDI) - remove and install	47
6 Navigation system	50
6.1 Multimedia system control unit J650 - remove and install	50
7 Rear view camera system	51
7.1 Rear view camera system (Saveiro) - structure	51
7.2 Rear view camera - remove and install	51
8 Multifunction steering wheel	52
8.1 Multifunction steering wheel - general information	52
8.2 Multifunction steering wheel - general assembly overview	53
8.3 Command keys - remove and install	54
8.4 Tiptronic switch on the steering wheel E439/E438 - remove and install	58
8.5 Multifunction steering wheel - adjust	59
9 Interference suppression measures	60
10 Ambient temperature sensor G17	61
10.1 Ambient temperature sensor G17 - assembly overview	61
10.2 Ambient temperature sensor G17 - remove and install	62
10.3 Ambient temperature sensor G17 - check	62