

# Contents

## CONTENTS LISTED ACCORDING TO REPAIR OPERATIONS; SPECIAL TOOLS

Operation No.	Repair	Page	VW/Audi Special Tools	Workshop equipment
80 13 15 ..	Adjusting heater control cable	1, 4		
80 13 19 ..	Removing and installing heater control cable	1, 4		
80 15 19 ..	Removing and installing regulator valve	1, 4, 10		
80 18 19 ..	Removing and installing fresh air blower	1, 4, 10		
80 23 19 ..	Removing and installing heat exchanger	1, 4, 10		
80 30 19 ..	Removing and installing refrigerant hose	1, 4		
85 10 19 ..	Removing and installing fresh air and heater control	1, 4		
85 11 19 ..	Removing and installing fresh air control cable	1, 4		
85 15 19 ..	Removing and installing fresh air box	1, 4, 10		
85 23 19 ..	Removing and installing fresh air blower switch	4		
85 30 19 ..	Removing and installing fresh air blower motor	1, 4, 10		
87 01 01 ..	Checking air conditioner	42, 49		Thermometer Vacuum gauge
87 12 19 ..	Removing and installing temperature switch	23; 28		Ohmmeter
87 25 19 ..	Removing and installing Vee belt	16-22		5/8" x 18 UNF
87 40 19 ..	Removing and installing compressor bracket	16-22		5/8" x 18 UNF
87 68 19 ..	Removing and installing air conditioner blower	10		
87 72 19 ..	Removing and installing air vents	10		
87 75 19 ..	Removing and installing left hand air duct	10		

## ALPHABETICAL INDEX

	Page		Page
Air conditioner charging and evacuating valves . . .	8	-Heater, servicing . . . . .	1, 4, 10, 14
Air conditioner, opening and evacuating. . . . .	9	Heat exchanger, removing and installing	
Air conditioner, servicing controls		● up to 1976 Model Year . . . . .	2
up to 1979 Model Year . . . . .	23	● from 1977 Model Year . . . . .	4
● from 1980 Model Year . . . . .	28	Heat exchanger for air conditioner, removing and installing . . . . .	10
Air conditioner micro switch, adjusting		Heater cable, adjusting	
● up to 1979 Model Year . . . . .	23	● up to 1976 Model Year . . . . .	1
● from 1980 Model Year . . . . .	28	● from 1977 Model Year . . . . .	5
Air conditioner cables, adjusting		Instruction regarding general repairs on vehicles with air conditioner . . . . .	9
● up to 1979 Model Year . . . . .	13	Receiver for air conditioner . . . . .	8
● from 1980 Model Year . . . . .	14	Repairs to the air conditioner which can only be carried out by specially equipped workshops . . . . .	8
Additional current flow diagrams		Repairs to the air conditioner and ventilation systems, which are possible without any special equipment	
● up to 1977 Model Year . . . . .	30	● up to 1979 Model Year . . . . .	10
● from 1977 Model Year . . . . .	32	● from 1980 Model Year . . . . .	14
● from 1978 Model Year . . . . .	34	Regulator valve, removing and installing . . . . .	1, 4, 10
● from 1979 Model Year . . . . .	36	Safety precautions when working on vehicles with air conditioner or when handling refrigerant . . . . .	7
● from 1980 Model Year . . . . .	38	Temperature switch, removing and installing	
Cover, removing and installing		● up to 1979 Model Year . . . . .	23
● up to 1979 Model Year . . . . .	1	● from 1980 Model Year . . . . .	28
● from 1980 Model Year . . . . .	4	Vacuum hose layout	
Cover for air conditioner . . . . .	10	● up to 1979 Model Year . . . . .	40
Compressor bracket, removing and installing		● from 1980 Model Year . . . . .	41
● up to 1977 Model Year . . . . .	16	Vacuum unit, removing and installing	
● from 1978 Model Year . . . . .	20	● up to 1979 Model Year . . . . .	10
● from 1979 Model Year — Golf/Diesel . . . . .	20	● from 1980 Model Year . . . . .	14
● from 1979 Model Year . . . . .	22	Vacuum system, checking	
Cooling function, checking		● up to 1979 Model Year . . . . .	42
● up to 1979 Model Year . . . . .	46	● from 1980 Model Year . . . . .	49
● from 1980 Model Year . . . . .	53	Vacuum distributor, removing and installing	
Control flap . . . . .	4	● up to 1979 Model Year . . . . .	23
Cut-off flap, removing and installing . . . . .	4	● from 1980 Model Year . . . . .	28
Direct ventilation . . . . .	1	V belt, removing, installing/adjusting	
Evaporator housing, dismantling and assembling . . . . .	10	● up to 1977 Model Year . . . . .	16
Fault Finding Instructions — air conditioner		● from 1978 Model Year . . . . .	18
● up to 1979 Model Year . . . . .	42	● from 1979 Model Year (Golf Diesel) . . . . .	10
● from 1979 Model Year . . . . .	49	● from 1979 Model Year . . . . .	22
Fresh air blower for heater, removing and installing		V belt adjusting pulley, adjusting . . . . .	22
● up to 1976 Model Year . . . . .	3		
● from 1977 Model Year . . . . .	4		
Fresh air blower for air conditioner, removing and installing . . . . .	10		
Fresh air box, removing and installing			
● Heater . . . . .	1		
● Air conditioner . . . . .	10, 14		
Fresh air flap, removing and installing . . . . .	1, 4		
Fresh air and heater controls, removing and installing			
● up to 1976 Model Year . . . . .	2		
● from 1977 Model Year . . . . .	5		
Fresh air blower switch, removing and installing . . . . .	4, 14		