



Contents

01 - Self diagnosis	1
1 Self diagnosis	1
1.1 Self diagnosis	1
1.2 Function	1
1.3 Technical data of self diagnosis	1
1.4 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit	1
1.5 Interrogating fault memory	3
1.6 Fault table	4
1.7 Erasing fault memory	6
1.8 Final control diagnosis	6
1.9 Reading measured value block	10
23 - Mixture preparation, Injection	12
1 Servicing fuel injection system	12
1.1 Servicing fuel injection system	12
1.2 Injection pump with two-part sprocket	13
1.3 Injection pump with two-part sprocket	16
1.4 Servicing fuel filter	18
1.5 Rules for cleanliness	19
1.6 Checking fuel system for leaks	20
1.7 Actuator controlled, load-dependent injection timing	21
1.8 Removing and installing injection pump	21
1.9 Checking and adjusting injection pump timing	28
1.10 Checking valve timing	32
1.11 Adjusting idling speed, idling speed boost and engine governed speed	34
1.12 Load change speed	36
1.13 Residual volume basic setting	37
1.14 Idling speed boost actuator	38
1.15 Checking commencement of injection valve	38
1.16 Checking engine temperature sender	39
1.17 Resistance figures for engine temperature sender	39
1.18 Checking idling speed boost valve	40
1.19 Check full load stop valve, engine 1Y	40
1.20 Removing and installing injectors	41
1.21 Servicing injectors	42
1.22 Checking injector nozzle valve tip for damage, injection pressure and for leakage.	43
2 Servicing injection pump	44
2.1 Servicing injection pump	44
2.2 Removing and installing throttle lever or return spring	50
2.3 Renewing pump cover throttle lever bush, pump cover gasket and throttle lever shaft O-ring	53
2.4 Renewing fuel delivery adjusting screw O-ring	56
2.5 Renewing idling speed boost shaft O-ring	56
2.6 Renewing injection timing device cover O-ring	57
2.7 Renewing CSA lever/cover O-ring	57
2.8 Sealing injection pump connections	58
28 - Glow plug system	60
1 Checking glow plug system	60
1.1 Checking glow plug system	60
1.2 Checking glow plug current consumption with V.A.G 1315A	60
1.3 Checking glow plugs	60
1.4 Glow plugs with burned electrodes	61