



Contents

00 - Technical data	1
1 Engine number/engine data	1
2 Safety precautions	5
2.1 Safety regulations for working on fuel supply	5
2.2 Safety precautions when working on ignition system	5
2.3 Releasing pressure in high-pressure area	6
3 General repair instructions	7
3.1 Rules for cleanliness	7
10 - Removing and installing engine	8
1 Removing and installing motor	8
1.1 Removing engine (Golf Plus, Eos, Scirocco, Golf, Touran, Golf Cabriolet)	8
1.2 Installing engine (Golf Plus, Eos, Scirocco, Golf, Touran, Golf Cabriolet)	18
1.3 Removing engine (Tiguan)	20
1.4 Installing engine (Tiguan)	28
1.5 Removing engine (Polo)	31
1.6 Installing engine (Polo)	39
1.7 Removing engine (Sharan)	40
1.8 Installing engine (Sharan)	48
1.9 Removing engine (Passat, Passat CC)	50
1.10 Installing engine (Passat, Passat CC)	60
2 Assembly mountings	64
2.1 Assembly overview - assembly mountings (Touran, Golf Plus, Eos, Scirocco, Golf, Golf Cabriolet)	64
2.2 Assembly overview - assembly mountings (Tiguan)	65
2.3 Assembly overview - assembly mountings (Polo)	66
2.4 Assembly overview - assembly mountings (Sharan)	67
2.5 Assembly overview - assembly mountings (Passat, Passat CC)	67
13 - Crankshaft group	69
1 Cylinder block (pulley end)	69
1.1 Assembly overview - poly V-belt drive	71
1.2 Assembly overview - cylinder block, belt pulley end	73
1.3 Removing and installing poly V-belt (Golf Plus, Eos, Scirocco, Golf, Touran, Polo, Sharan, Passat, Passat CC, Golf Cabriolet)	75
1.4 Removing and installing poly V-belt (Tiguan)	78
1.5 Removing and installing bracket for ancillaries	80
1.6 Renewing crankshaft oil seal - pulley end	81
1.7 Removing and installing crankshaft pulley	83
2 Cylinder block, gearbox end	87
2.1 Assembly overview - cylinder block, gearbox end	87
2.2 Removing and installing sealing flange on gearbox side	89
3 Crankshaft	97
3.1 Assembly overview - crankshaft	97
3.2 Pulling needle bearing out of and driving into crankshaft	98
3.3 Crankshaft dimensions	100
4 Pistons and conrods	101
4.1 Assembly overview - pistons and conrods	101
4.2 Checking piston	103
4.3 Checking cylinder bores	104
4.4 Separating new conrod	104
4.5 Removing and installing pistons	104



4.6	Removing and installing oil spray jets	105
15	- Cylinder head, valve gear	107
1	Cylinder head	107
1.1	Assembly overview - cylinder head	107
1.2	Removing and installing camshaft housing	110
1.3	Removing and installing cylinder head	116
1.4	Checking compression	118
2	Valve gear	121
2.1	Assembly overview - valve gear	121
2.2	Measuring axial clearance of camshaft	123
2.3	Reworking valve seats	123
2.4	Checking valve guides	125
2.5	Removing and installing valve stem seals	125
3	Cover for timing chain	128
3.1	Removing and installing valve timing housing (Eos, Golf Plus, Scirocco, Golf, Polo, Sharan, Golf Cabriolet)	128
3.2	Removing and installing valve timing housing (Touran, Tiguan)	132
3.3	Removing and installing valve timing housing (Passat CC, Passat)	138
4	Chain drive	143
4.1	Checking valve timing	143
4.2	Adjusting valve timing	145
4.3	Checking timing chain	152
4.4	Removing and installing timing chain and chain drive for oil pump	159
17	- Lubrication	168
1	Sump, oil pump	168
1.1	Engine oil:	168
1.2	Assembly overview - sump, oil pump	168
1.3	Removing and installing sump	171
1.4	Removing and installing oil pump	175
2	Oil filter, oil pressure switch	178
2.1	Checking oil pressure and oil pressure switch	178
19	- Cooling	180
1	Cooling system/coolant	180
1.1	Coolant hose schematic diagram (Golf Plus, Eos, Scirocco, Golf, Touran, Polo, Golf Cabriolet)	181
1.2	Schematic diagram for coolant hoses (Tiguan)	182
1.3	Schematic diagram for coolant hoses (Sharan)	183
1.4	Coolant hose schematic diagram (Passat, Passat CC)	184
1.5	Draining and filling with coolant (Golf Plus, Eos, Scirocco, Golf, Touran, Tiguan, Golf Cabriolet)	185
1.6	Draining and filling coolant (Polo)	189
1.7	Draining and filling coolant (Sharan)	193
1.8	Draining and filling coolant (Passat, Passat CC)	198
1.9	Checking cooling system for leaks (Polo, Touran, Golf Plus, Eos, Scirocco, Golf, Golf Cabriolet)	204
1.10	Checking cooling system for leaks (Sharan, Tiguan)	206
1.11	Checking cooling system for leaks (Passat, Passat CC)	208
2	Coolant pump, regulation of cooling system	211
2.1	Assembly overview - thermostat	211
2.2	Assembly overview - thermostat (Passat, Passat CC)	213
2.3	Removing and installing coolant pump (Polo, Touran, Golf Plus, Eos, Tiguan, Scirocco, Golf, Golf Cabriolet)	214



2.4	Removing and installing coolant pump belt pulley (Polo, Touran, Golf Plus, Eos, Tiguan, Scirocco, Golf, Golf Cabriolet)	218
2.5	Removing and installing coolant circulation pump V50 (Polo, Touran, Golf Plus, Eos, Tiguan, Scirocco, Golf, Golf Cabriolet)	223
2.6	Removing and installing coolant pump (Sharan)	225
2.7	Removing and installing coolant pump belt pulley (Sharan)	230
2.8	Removing and installing coolant circulation pump V50 (Sharan)	234
2.9	Removing and installing coolant pump belt pulley (Passat, Passat CC)	236
2.10	Removing and installing coolant pump (Passat, Passat CC)	242
2.11	Removing and installing coolant circulation pump V50 (Passat, Passat CC)	249
2.12	Assembly overview - heater element for engine preheater Z97 (Passat, Passat CC)	251
2.13	Removing and installing heater element for engine preheater Z97 (Passat, Passat CC)	253
3	Radiator, radiator fan	256
3.1	Assembly overview - radiator/radiator fan (Eos, Golf Plus, Scirocco, Golf, Touran, Golf Cabriolet)	256
3.2	Assembly overview - parts of cooling system, body side (Tiguan)	258
3.3	Assembly overview - radiator/radiator fan (Polo)	260
3.4	Assembly overview - radiator/radiator fan (Sharan)	261
3.5	Assembly overview - radiator/radiator fan (Passat, Passat CC)	262
3.6	Removing and installing radiator fan V7 and radiator fan 2 V177 (Eos, Golf Plus, Scirocco, Golf, Touran, Golf Cabriolet)	263
3.7	Removing and installing radiator fan V7 and radiator fan 2 V177 (Polo)	264
3.8	Removing and installing radiator, radiator fan V7 and radiator fan 2 V177 (Sharan)	265
3.9	Removing and installing radiator (Passat, Passat CC)	267
3.10	Removing and installing fan cowling (Passat, Passat CC)	270
3.11	Removing and installing radiator fan V7 and radiator fan 2 V177 (Passat, Passat CC)	271
3.12	Removing and installing radiator (Golf Plus, Eos, Scirocco, Golf, Touran, Golf Cabriolet)	272
3.13	Removing and installing radiator and radiator fan V7 (Tiguan)	273
3.14	Removing and installing radiator with charge air cooler (Polo)	275
21	Turbocharging/supercharging	278
1	Turbocharger	278
1.1	Assembly overview - turbocharger	278
1.2	Removing and installing turbocharger	282
1.3	Checking vacuum unit for turbocharger	287
1.4	Removing and installing vacuum unit for turbocharger	289
1.5	Adjusting vacuum unit for turbocharger	291
2	Compressor	297
2.1	Assembly overview - supercharger	297
2.2	Removing and installing supercharger	299
2.3	Removing and installing supercharger (Tiguan with four-wheel drive)	307
2.4	Removing and installing drive unit seal for supercharger	315
3	Charge air system	319
3.1	Assembly overview - charge air system (Eos, Golf Plus, Golf, Touran, Scirocco, Tiguan, Sharan, Golf Cabriolet)	320
3.2	Assembly overview - charge air system (Polo)	321
3.3	Assembly overview - charge air system (Passat, Passat CC)	322
3.4	Fitting hose connections with plug-in connectors	323
3.5	Checking charge air system for leaks	324
3.6	Removing and installing charge air cooler (Eos, Golf Plus, Golf, Golf Cabriolet, Touran)	327
3.7	Removing and installing charge air cooler, Sharan	329
3.8	Removing and installing charge air cooler (Scirocco)	331
3.9	Removing and installing charge air cooler, Tiguan	333
3.10	Removing and installing charge air cooler (Passat, Passat CC)	335
24	Mixture preparation - injection	340



1	Air filter	340
1.1	Assembly overview - air filter	340
1.2	Assembly overview - air filter (Polo)	341
1.3	Removing and installing air filter housing	342
1.4	Removing and installing air filter housing (Polo)	343
2	Intake manifold	344
2.1	Assembly overview - intake manifold	344
2.2	Removing and installing regulating flap control unit J808 and throttle valve module J338	349
2.3	Cleaning throttle valve module J338	351
3	Injectors	353
3.1	Assembly overview - fuel rail with injectors	353
3.2	Removing and installing injectors	355
3.3	Renewing seals on injectors	358
4	Senders and sensors	362
4.1	Checking fuel pressure sender	362
4.2	Actuator for structure-borne sound R214 and control unit for structure-borne sound J869 (Polo, left-hand drive)	365
4.3	Assembly overview - actuator for structure-borne sound R214 and control unit for structure-borne sound J869 (Polo, right-hand drive)	367
5	High-pressure pump	368
5.1	Assembly overview - high-pressure pump	368
5.2	Removing and installing high-pressure pump	369
6	Engine control unit J623	373
6.1	Removing and installing engine control unit J623 (Golf Plus, Touran)	373
6.2	Removing and installing engine control unit J623 with protective housing (Golf Plus, Touran)	375
6.3	Removing and installing engine control unit J623 (Eos)	377
6.4	Removing and installing engine control unit J623 with protective housing (Eos▶ 10.2008)	378
6.5	Removing and installing engine control unit J623 (Tiguan)	380
6.6	Removing and installing engine control unit J623 with protective housing (Tiguan)	381
6.7	Removing and installing engine control unit J623 (Scirocco)	383
6.8	Removing and installing engine control unit J623 with protective housing (Scirocco▶ 09.2008)	384
6.9	Removing and installing engine control unit J623 (Golf, Golf Cabriolet)	386
6.10	Removing and installing engine control unit J623 (Passat, Passat CC)	387
6.11	Removing and installing engine control unit J623 with protective housing (Golf, Eos 11.2008▶, Scirocco 10.2008▶, Passat, Passat CC, Golf Cabriolet)	388
6.12	Removing and installing engine control unit J623 (Polo)	391
6.13	Removing and installing engine control unit J623 with protective housing (Polo)	392
6.14	Removing and installing engine control unit J623 (Sharan)	393
6.15	Removing and installing engine control unit J623 with protective housing (Sharan)	394
26	Exhaust system	396
1	Exhaust pipes and silencers	396
1.1	Assembly overview - silencer (Golf Plus, Eos, Scirocco, Golf, Touran, Golf Cabriolet)	397
1.2	Assembly overview - silencers (Tiguan)	398
1.3	Assembly overview - silencers (Polo)	399
1.4	Assembly overview - silencers (Sharan)	400
1.5	Assembly overview - silencer (Passat, Passat CC)	401
1.6	Removing and installing front exhaust pipe (Tiguan with four-wheel drive)	402
1.7	Removing and installing front exhaust pipe (Golf Plus, Eos, Scirocco, Golf, Tiguan, Touran, Golf Cabriolet)	403
1.8	Removing and installing front exhaust pipe (Sharan)	404
1.9	Removing and installing (Passat, Passat CC)	405



1.10	Separating exhaust pipes, silencers (Tiguan)	407
1.11	Separating exhaust pipes/silencers (Golf Plus, Eos, Scirocco, Golf, Touran, Golf Cabriolet)	408
1.12	Separating exhaust pipes, silencers (Polo)	410
1.13	Separating exhaust pipes, silencers (Sharan)	411
1.14	Separating exhaust pipes/silencers (Passat, Passat CC)	412
1.15	Aligning exhaust system free of stress (Passat, Passat CC)	414
1.16	Installation position of clamp	415
2	Emission control	416
2.1	Assembly overview - exhaust gas treatment (Golf Plus, Eos, Scirocco, Golf, Touran, Tiguan, Golf Cabriolet)	416
2.2	Assembly overview - exhaust gas treatment (Tiguan with four-wheel drive)	418
2.3	Assembly overview - exhaust gas treatment (Polo)	420
2.4	Assembly overview - exhaust gas treatment (Sharan)	421
2.5	Assembly overview - exhaust gas treatment (Passat, Passat CC)	422
2.6	Removing and installing catalytic converter (Polo)	424
2.7	Removing and installing (Passat, Passat CC)	425
28	Ignition system	428
1	Ignition system	428
1.1	Assembly overview - ignition system	428
1.2	Removing and installing ignition coils with output stage	429
1.3	Removing and installing engine speed sender G28	431
1.4	Test data, spark plugs	433