



Contents

91 - Communication	1
1 Communication systems	1
1.1 General notes	1
1.2 Fault finding in communication systems	1
2 Radio units and radio navigation systems in general	2
2.1 Removing and installing radio units and radio navigation systems, Golf saloon	2
2.2 Removing and installing radio units and radio navigation systems, Golf Plus	4
2.3 Adapting radio components	7
2.4 Adapting radio navigation system components	8
3 Radio system "RCD 210"	9
3.1 General notes	9
3.2 Fault finding	9
3.3 Overview of radio system "RCD 210", Golf saloon	10
3.4 Overview of radio system "RCD 210", Golf Plus	11
3.5 Overview of connectors on radio "RCD 210"	13
3.6 Anti-theft coding	14
4 Radio system "RCD 310"	18
4.1 General notes	18
4.2 Overview of radio system "RCD 310", Golf saloon	18
4.3 Overview of radio system "RCD 310", Golf Plus	20
4.4 Overview of connectors on radio "RCD 310"	22
4.5 Anti-theft coding	24
5 Radio system "RCD 510"	27
5.1 General notes	27
5.2 Overview of radio system "RCD 510", Golf saloon	28
5.3 Overview of radio system "RCD 510", Golf Plus	29
5.4 Activating/deactivating transport lock for CD changer in "RCD 510"	30
5.5 Overview of connectors on radio "RCD 510"	31
5.6 Anti-theft coding	35
6	39
6.1 General notes	39
6.2 Overview of radio navigation system "RNS 310", Golf saloon	40
6.3 Overview of radio navigation system "RNS 310", Golf Plus	42
6.4 Overview of connectors on radio navigation system "RNS 310"	44
6.5 Anti-theft coding	46
7	50
7.1 General notes	50
7.2 Overview of radio navigation system "RNS 510", Golf saloon	51
7.3 Overview of radio navigation system "RNS 510", Golf Plus	52
7.4 Overview of connectors on radio navigation system "RNS 510"	54
7.5 Anti-theft coding	57
8	61
8.1 General description	61
8.2 Overview of radio system "Premium 8", Golf saloon	62
8.3 "Premium 8" connectors	64
8.4 Activating and deactivating transport protection device	67
8.5 Anti-theft coding	67
8.6 Adapting "Premium 8" components	68
9 CD changer	70
9.1 Removing and installing CD changer	70
10 Sound system amplifier	72



10.1	General notes	72
10.2	Removing and installing amplifier	73
11	Multimedia system control unit	75
11.1	General notes	75
11.2	Overview of “multimedia system control unit”	75
11.3	Removing and installing multimedia control unit	76
12	Connection for external audio sources	78
12.1	General notes	78
12.2	Removing and installing connection for external audio sources R199	78
12.3	Contact assignment on connection for external audio sources R199	80
13	Loudspeaker systems	81
13.1	Overview of loudspeaker system, Golf saloon	81
13.2	Overview of loudspeaker system, Golf Plus	83
13.3	Removing and installing loudspeakers, Golf saloon	84
13.4	Removing and installing loudspeakers, Golf Plus	89
14	Telephone system / preparation for mobile telephone	94
14.1	General notes on “universal preparation for mobile telephone UTP”	94
14.2	Preparation for mobile telephone “UTP Premium with Bluetooth”	95
14.3	Preparation for mobile telephone “UTP with audio streaming”	97
14.4	Removing and installing telephone transmitter and receiver unit	98
14.5	Removing and installing emergency assistance call button, Golf saloon	98
14.6	Removing and installing telephone system microphone, Golf saloon	99
14.7	Removing and installing telephone system microphone, Golf Plus	100
14.8	Removing and installing telephone bracket, Golf saloon	101
14.9	Removing and installing telephone bracket, Golf Plus	102
15	Aerial systems	104
15.1	General notes	104
15.2	Overview of fitting location of components for rear window aerial	109
15.3	Removing and installing aerial modules	109
15.4	Removing and installing frequency modulation (FM) frequency filter	110
15.5	Removing and installing amplitude modulation (AM) frequency filter	111
15.6	Removing and installing roof aerial	112
15.7	Renewal of aerial wiring	113
16	Multifunction steering wheel	114
16.1	General notes	114
16.2	Removing and installing steering wheel operating unit	114
16.3	Adapting multifunction steering wheel components	116
17	Compass system	117
17.1	General description	117
17.2	Magnetic field sender for compass G197	117
18	Notes on operating mobile telephones and two-way radios	119
18.1	General notes	119
18.2	Notes on performing repair work	119
18.3	Overview of battery, transmitter and receiver unit, fuse and wiring harness	121
18.4	Transmitting power and aerial fitting locations	122
19	Suppression measures	123
19.1	Implementation of suppression measures	123