



Contents

00 - Technical data	1
1 Repair instructions	1
1.1 General repair instructions	1
1.2 Notes on repair of CAN bus wiring	1
1.3 Transmitting power and aerial fitting locations	1
91 - Communication	3
1 Infotainment system	3
1.1 Components of infotainment system	3
1.2 Overview of fitting locations - Infotainment system	11
1.3 Removing and installing infotainment system display	12
1.4 Removing and installing control unit 1 for information electronics J794	13
2 Sound system	15
2.1 Fitting locations overview - sound systems	15
2.2 Removing and installing digital sound package control unit J525	18
2.3 Removing and installing retainer for digital sound package control unit J525	22
2.4 Removing and installing front treble loudspeakers R20 / R22	22
2.5 Removing and installing rear treble loudspeakers R14 / R16	23
2.6 Removing and installing front bass loudspeakers R21 / R23	23
2.7 Removing and installing rear bass loudspeakers R15 / R17	25
2.8 Removing and installing subwoofer R211	27
3 Aerial systems	29
3.1 Overview of fitting locations - aerial systems	29
3.2 Removing and installing aerial amplifiers R24 / R84	30
3.3 Removing and installing amplitude modulation (AM) frequency filter R177	31
3.4 Removing and installing frequency modulation (FM) frequency filter R178 / R179	32
3.5 Removing and installing roof aerial RX5	33
4 Radio	34
4.1 Components of radio system	34
4.2 Removing and installing radio	34
5 Telephone system	37
5.1 Mobile telephone preparation	37
5.2 Overview of fitting locations - telephone system	38
5.3 Removing and installing telephone microphone R38	39
5.4 Removing and installing aerial amplifier for mobile telephone R86	40
6 Navigation system	42
6.1 Components of navigation system	42
6.2 Overview of fitting locations - navigation system	42
6.3 Removing and installing control unit for navigation system	43
7 Reversing camera system	44
7.1 Components of reversing camera system	44
7.2 Overview of fitting locations - reversing camera system	44
7.3 Assembly overview - reversing camera system	46
7.4 Removing and installing reversing camera R189	46
8 Multifunction steering wheel	47
8.1 Components of multifunction steering wheel	47
8.2 Assembly overview - multifunction steering wheel	47
8.3 Removing and installing steering wheel multifunction buttons E441 / E440	49
8.4 Removing and installing Tiptronic switch in steering wheel E439 / E438	51
9 Connection for external multimedia devices	53
9.1 Removing and installing connection for external multimedia devices	53
9.2 Removing and installing USB hub R293	54



10	Car-Net	55
10.1	General information	55
10.2	Overview of fitting locations - Car-Net services	55
10.3	Removing and installing emergency call module control unit and communication unit J949	56