

Contents

54 - Vehicle-specific paintwork information	1
1 Safety information and repair notes	1
1.1 Safety information	1
1.2 Repair instructions	1
2 Explanation of symbols	2
2.1 Sanding	2
2.2 Cavity sealing	2
2.3 Seam sealing	2
3 Paintwork structure	6
3.1 Structure of factory finish, clear coat	6
3.2 Structure of factory finish, surfacer	6
3.3 Structure of factory finish, base coat	7
4 Areas exposed to stone chipping	9
4.1 Areas exposed to stone chipping – overview	9
5 Masked sectors	11
5.1 Masking areas, front body	11
5.2 Masking areas, rear body	11
6 Seam sealing	13
6.1 Seam seals, front body	13
6.2 Seam sealing: Front wheel housing	14
6.3 Seam seals, A-pillar	14
6.4 Seam seals, bonnet, inner side	15
6.5 Seam seals, roof	16
6.6 Seam seals, doors	17
6.7 Seam seals, rear wheel housing	18
6.8 Seam seals, underbody	19
6.9 Seam seals, rear cross panel	20
7 Underseal	21
7.1 Underseal, body – overview	21
7.2 Underseal, front body	21
7.3 Underseal, centre body	22
7.4 Underseal, rear body	23
8 Cavity sealing	25
8.1 Cavity sealing, body – overview	25
8.2 Cavity sealing, rear body	25
8.3 Cavity sealing, front body	25
8.4 Cavity sealing, doors	26
9 Contrasting colours	27
9.1 Contrasting colours, roof	27
9.2 Contrasting colours, rear cross panel	28
10 Paintwork repair	29
10.1 Paintwork repair - front bumper	29
10.2 Paintwork repair, radar sensor cover	30