



## Contents

<b>00 - Technical data</b>	<b>1</b>
<b>1 Repair instructions</b>	<b>1</b>
1.1 General repair instructions	1
1.2 Routing and attachment of lines	1
1.3 Notes on repair of CAN bus wiring	1
1.4 General information	1
<b>91 - Communication</b>	<b>3</b>
<b>1 Infotainment system</b>	<b>3</b>
1.1 Overview of infotainment system	3
1.2 Overview of fitting locations – Infotainment system	6
1.3 Removing and installing infotainment system display	8
1.4 Removing and installing control unit 1 for information electronics J794	9
1.5 Renewing rotary knobs of display unit for front information display and operating unit control unit J685	11
<b>2 Sound system</b>	<b>13</b>
2.1 Components of sound system	13
2.2 Overview of fitting locations – sound system	14
2.3 Removing and installing digital sound package control unit J525	15
2.4 Removing and installing bracket for digital sound package control unit J525	18
2.5 Removing and installing front treble loudspeakers R20/R22	18
2.6 Removing and installing rear treble loudspeakers R14/R16	19
2.7 Removing and installing front bass loudspeakers R21/R23	20
2.8 Removing and installing rear bass loudspeakers R15/R17	22
2.9 Removing and installing subwoofer R211	24
<b>3 Aerial systems</b>	<b>26</b>
3.1 Components of aerial systems	26
3.2 Overview of fitting locations – aerial systems	26
3.3 Removing and installing aerial module	27
3.4 Removing and installing frequency modulation (FM) frequency filter in negative wire R178	29
3.5 Removing and installing frequency modulation (FM) frequency filter in positive wire R179	30
3.6 Removing and installing roof aerial	31
3.7 LTE aerial 2 R306	33
<b>4 Removing and installing radio</b>	<b>34</b>
4.1 Removing and installing radio, Composition Colour	34
4.2 Removing and installing radio, Composition Media and Discover Pro	35
<b>5 Telephone system</b>	<b>36</b>
5.1 Preparation for mobile telephone	36
5.2 Overview of fitting locations – telephone system	37
5.3 Removing and installing telephone microphone R38	38
5.4 Removing and installing storage compartment with interface for mobile telephone R265	39
<b>6 Navigation system</b>	<b>41</b>
6.1 Overview of navigation system	41
6.2 Overview of fitting locations – navigation system	41
6.3 Removing and installing control unit for navigation system	42
<b>7 Multifunction steering wheel</b>	<b>43</b>
7.1 Overview of multifunction steering wheel	43
7.2 Assembly overview – multifunction steering wheel	43
7.3 Removing and installing multifunction buttons in steering wheel E441/E440	44
7.4 Removing and installing Tiptronic switch in steering wheel E439/E438	48
<b>8 Connection for external multimedia devices</b>	<b>50</b>



8.1	Removing and installing connection for external multimedia devices, USB connection 1 U41 in centre console storage compartment at front, variant 1 .....	50
8.2	Removing and installing connection for external multimedia devices, USB port in storage compartment of front centre console, variant 2 .....	51
<b>9</b>	<b>Online services</b> .....	<b>53</b>
9.1	General information .....	53
9.2	Overview of fitting locations – mobile online services .....	53
9.3	Removing and installing emergency call module control unit and communication unit J949 ..	54
9.4	Removing and installing operating unit for preparation for mobile telephone E508 .....	55
9.5	Removing and installing battery for control unit for emergency call module .....	56