



Contents

00 - Technical data	1
1 Repair notes	1
1.1 General repair instructions	1
1.2 Routing and attachment of lines	1
1.3 Notes on repair of CAN bus wiring	1
1.4 General information	1
91 - Communication	3
1 Infotainment system	3
1.1 Overview of infotainment system	3
1.2 Overview of fitting locations – Infotainment system	5
1.3 Removing and installing infotainment system display	7
1.4 Removing and installing control unit 1 for information electronics J794	8
1.5 Renewing rotary knobs of display unit for front information display and operating unit control unit J685	9
2 Sound system	11
2.1 Components of sound system	11
2.2 Overview of fitting locations – sound system	12
2.3 Removing and installing digital sound package control unit J525	13
2.4 Removing and installing front treble loudspeakers R20/R22	16
2.5 Removing and installing rear treble loudspeakers R14/R16	16
2.6 Removing and installing front loudspeaker R2/R3	18
2.7 Removing and installing front bass loudspeakers R21/R23	19
2.8 Removing and installing rear bass loudspeakers R15/R17	21
2.9 Removing and installing subwoofer R211	23
3 Aerial systems	25
3.1 Components of aerial systems	25
3.2 Overview of fitting locations – aerial systems	25
3.3 Removing and installing aerial module	26
3.4 Removing and installing frequency modulation (FM) frequency filter in negative wire R178	28
3.5 Removing and installing frequency modulation (FM) frequency filter in positive wire R179	29
3.6 Removing and installing roof aerial	30
3.7 Removing and installing LTE aerial 2 R306	31
4 Removing and installing radio	33
4.1 Removing and installing radio, Composition Colour	33
4.2 Removing and installing radio, Composition Media and Discover Pro	34
5 Telephone system	35
5.1 Preparation for mobile telephone	35
5.2 Overview of fitting locations – telephone system	36
5.3 Removing and installing telephone microphone R38	37
5.4 Removing and installing storage compartment with interface for mobile telephone R265	38
6 Navigation system	40
6.1 Overview of navigation system	40
6.2 Overview of fitting locations – navigation system	40
6.3 Removing and installing control unit for navigation system	41
7 Multifunction steering wheel	42
7.1 Overview of multifunction steering wheel	42
7.2 Assembly overview – multifunction steering wheel	42
7.3 Removing and installing multifunction buttons in steering wheel E441/E440	43
7.4 Removing and installing Tiptronic switch in steering wheel E439/E438	47
8 Connection for external multimedia devices	49



8.1	Removing and installing connection for external multimedia devices, USB connection 1 U41 in centre console storage compartment at front	49
8.2	Removing and installing USB charging socket 1 U37	50
9	Online services	52
9.1	General description – Car-Net services	52
9.2	Overview of fitting locations – mobile online services	52
9.3	Removing and installing emergency call module control unit and communication unit J949 ..	54
9.4	Removing and installing operating unit for preparation for mobile telephone E508	54
9.5	Removing and installing loudspeaker for emergency call module R335	55
9.6	Removing and installing battery for control unit for emergency call module	56