



Contents

00 - Technical data	1
1 Vehicle identification data	1
1.1 Type plate and vehicle identification number	1
1.2 Vehicle data sticker	1
2 Body foam insulation	2
3 Galvanized body parts	3
4 Strengthened steel body panels	4
5 Laser welding	5
6 Bonded joints	6
6.1 Bonded joints	6
6.2 Spot welded/bonded joints	6
6.3 Checking and repairing spot welded/bonded joints	6
6.4 Repair remedies for partial repairs	6
7 Body panel gaps/shut lines	8
7.1 Body - front	8
7.2 Body - rear	9
8 Body dimensions	10
8.1 Body - front	10
8.2 Body - centre	15
8.3 Body - rear	17
8.4 Floor group - front	20
8.5 Floor group - longitudinal dimensions	21
8.6 Floor group - rear	22
9 Straightening jig	23
9.1 Overview	23
50 - Body - front	31
1 Renewing engine bracket	31
1.1 Removing	31
2 Renewing gearbox bracket	33
2.1 Removing	33
3 Renewing support	35
3.1 Removing	35
4 Renewing upper wheel housing longitudinal member	37
4.1 Removing	37
5 Renewing front wheel housing - partial renewal	39
5.1 Removing	39
6 Renewing front wheel housing - partial renewal	41
6.1 Removing	41
7 Renewing longitudinal member behind subframe mounting - partial renewal	43
7.1 Removing	43
8 Longitudinal member - partial renewal	45
8.1 Removing	45
9 Renewing front section of longitudinal member	48
9.1 Removing	48
51 - Body - centre	51
1 Renewing roof	51
1.1 Removing	51
2 Renewing front roof cross member	54



2.1	Removing	54
3	Renewing rear cross member	56
3.1	Removing	56
4	Renewing inner side panel	58
4.1	Removing	58
5	Renewing A-pillar	61
5.1	Removing	61
5.2	Inner A-pillar	63
6	Renewing B-pillar	67
6.1	Removing	67
7	Renewing outer side member	70
7.1	Removing	70
8	Renewing outer side member - Lupo 3L	73
8.1	Removing	73
9	Renewing inner side member	76
9.1	Removing	76
10	Renewing floor panel	79
10.1	Removing	79
53 - Body - rear		83
1	Renewing rear cross panel	83
1.1	Removing	83
2	Renewing tail light mounting	85
2.1	Removing	85
3	Renewing rear luggage compartment floor - partial renewal	88
3.1	Removing	88
4	Renewing rear longitudinal member - partial renewal	91
4.1	Removing	91
5	Renewing side panel - partial renewal	93
5.1	Removing	93
6	Renewing rear wheel housing	96
6.1	Scope of work: outer wheel housing liner (complete)	96
7	Renewing outer wheel housing liner - partial renewal	99
7.1	Removing	99