



Contents

68 - Interior equipment	1
1 Interior mirror	1
1.1 Automatic anti-dazzle interior mirror	1
1.2 Removing and installing interior mirror	2
2 Compartments, covers and trims	4
2.1 Assembly overview - centre console ▶ 01.01	4
2.2 Removing and installing centre console ▶ 01.01	4
2.3 Removing and installing drink holder or ashtray in centre console ▶ 01.01	8
2.4 Assembly overview - centre console 02.01 ▶ 04.03	9
2.5 Removing and installing centre console 02.01 ▶ 04.03	10
2.6 Removing rear ashtray from centre console 02.01 ▶ 04.03	14
2.7 Removing drink holder 02.01 ▶	14
2.8 Assembly overview - centre console 05.03 ▶ and Cabriolet	14
2.9 Removing and installing centre console 05.03 ▶ and Cabriolet	16
2.10 Removing rear ashtray from centre console 05.03 ▶ and Cabriolet	19
2.11 Removing and installing armrest padding 05.03 ▶ and Cabriolet	19
2.12 Removing trim under centre of dash panel	20
2.13 Removing glove compartment	21
2.14 Removing and installing glove compartment lock cylinder	21
2.15 Removing and installing glove compartment lid	23
2.16 Removing footwell cover (driver side)	23
2.17 Removing trim under steering column	24
2.18 Removing spectacles compartment	25
2.19 Removing front centre armrest	26
2.20 Removing and installing armrest clip	26
2.21 Removing sun visor	27
2.22 Removing sun visor (Cabriolet)	27
2.23 Removing plenum chamber inner cover	27
2.24 Removing and installing centre console stowage net (Mexico)	29
2.25 Removing and installing trim of steering wheel clip	29
3 Grab handles	32
3.1 Removing grab handle (dash panel)	32
3.2 Removing grab handle with mobile telephone retainer (dash panel)	32
3.3 Removing grab handle (roof)	33
3.4 Removing grab straps	33
4 Sill mouldings	34
4.1 Assembly overview - sill moulding	34
4.2 Removing and installing sill moulding	35
4.3 Assembly overview - sill moulding (Cabriolet)	36
4.4 Removing and installing sill moulding (Cabriolet)	37
69 - Passenger protection	39
1 Seat belts	39
1.1 Safety regulations for belt tensioners	39
1.2 Assembly overview - front seat belt with belt tensioner	39
1.3 Assembly overview - rear seat belts (Cabriolet)	41
1.4 Assembly overview - front seat belt with belt tensioner (Cabriolet)	41
1.5 Assembly overview - rear seat belt (Cabriolet)	43
2 Seat belts - checking	44
2.1 Installing and retrofitting LATCH system "Lower Anchors and Tethers for Children (child seat securing system) (USA)	47
3 Automatic roll-over protection (Cabriolet)	49



3.1	Safety precautions and notes for working on automatic roll-over protection	49
3.2	Assembly overview - automatic roll-over protection	50
3.3	Removing and installing automatic roll-over protection	52
3.4	Lowering automatic roll-over protection	54
3.5	Lowering roll-over protection (Cabriolet roof closed)	55
3.6	Removing and installing impact carrier	56
4	Airbag	57
4.1	Tools	57
4.2	Detailed overview - airbag	57
4.3	Component overview (Cabriolet)	59
4.4	Safety precautions and notes when working on airbag	60
4.5	Renewing airbag units following an accident	61
4.6	Assembly overview - driver airbag unit	63
4.7	Removing and installing driver airbag unit	64
4.8	Assembly overview - front passenger airbag unit	67
4.9	Removing and installing front passenger airbag unit	67
4.10	Assembly overview - steering wheel	71
4.11	Removing and installing steering wheel	71
4.12	Removing and installing return spring with slip ring	72
4.13	Removing and installing airbag control unit J234	74
4.14	Assembly overview - side airbag for driver/front passenger side	74
4.15	Removing and installing side airbag on driver/front passenger side	75
4.16	Assembly overview - side airbag on driver/front passenger side, from 05.03	78
4.17	Removing and installing side airbag for driver/front passenger side, from 05.03	78
4.18	Assembly overview - side airbag sensor for driver/front passenger side	81
4.19	Removing and installing side airbag sensor for driver/front passenger side	81
4.20	Assembly overview - side airbag sensor for driver/front passenger side, from 05.03	84
4.21	Removing and installing side airbag sensor for driver/front passenger side, from 05.03 (in lower part of B-pillar)	84
4.22	Assembly overview - side airbag sensor for driver/front passenger side (Cabriolet)	87
4.23	Removing and installing side airbag sensor for driver/front passenger side (Cabriolet)	87
4.24	Assembly overview - driver airbag crash sensor G283 and front passenger airbag crash sensor G284	89
4.25	Removing and installing driver airbag crash sensor G283 and front passenger airbag crash sensor G284	89
4.26	Removing and installing front passenger airbag deactivation switch E224 , 05.03 >	91
4.27	Removing and installing front passenger airbag deactivation switch E224 (Cabriolet)	91
4.28	Assembly overview - underside of Passive Occupant Detection System (PODS), (USA)	92
4.29	Assembly overview - upper side of Passive Occupant Detection System (PODS), (USA)	93
4.30	Removing and installing Passive Occupant Detection System (PODS), (USA)	93
70	Trim, insulation	99
1	Dash panel	99
1.1	Tools	99
1.2	Removing and installing dash panel	99
2	Door trim	110
2.1	Tools	110
2.2	Assembly overview - front door trim	110
2.3	Removing and installing front door trim	111
2.4	Assembly overview - front door trim (Cabriolet)	113
2.5	Removing and installing front door trim (Cabriolet)	114
2.6	Repairing door trim	115
2.7	Assembly overview - door trim	116
2.8	Removing and installing upper part (shoulder) of door trim	117
2.9	Assembly overview - door trim (Cabriolet)	120



2.10	Removing and installing upper part (shoulder) of door trim (Cabriolet)	121
3	Pillar and side trims	122
3.1	Assembly overview - upper A-pillar trim	122
3.2	Removing and installing upper A-pillar trim	122
3.3	Removing and installing lower A-pillar trim	123
3.4	Assembly overview - B-pillar trim	124
3.5	Removing and installing B-pillar trim	125
3.6	Assembly overview - C-pillar trim	127
3.7	Removing and installing C-pillar trim	127
3.8	Assembly overview - side trim	129
3.9	Removing and installing side trim	129
4	Pillar and side trims (Cabriolet)	131
4.1	Assembly overview - A-pillar upper trim	131
4.2	Removing and installing upper A-pillar trim	131
4.3	Assembly overview - side trim	133
4.4	Removing and installing side trim	133
4.5	Assembly overview - side panel trim on Cabriolets with motorised folding roof, with large roof flaps and flap control motor	136
4.6	Repairing side panel	137
4.7	Assembly overview - flap module	138
4.8	Removing and installing push rod	139
4.9	Removing and installing large roof flap	140
4.10	Removing and installing Bowden cable	140
4.11	Removing and installing small roof flap	141
4.12	Removing and installing flap positioning motor	141
4.13	Removing and installing lever	142
4.14	Removing and installing large and small trim	142
4.15	Adjusting large and small trim	143
4.16	Assembly overview - Cabriolets with manually operated folding roof and motorised folding roof with no large roof flaps and flap control motor	146
4.17	Repairing side panel	147
4.18	Assembly overview - flap module	148
4.19	Removing and installing Bowden cable	149
4.20	Removing and installing small roof flap	149
4.21	Removing and installing flap positioning motor	150
4.22	Removing and installing small trim	150
4.23	Adjusting small trim	150
4.24	Removing and installing roll-over protection	152
4.25	Removing and installing rear shelf	154
4.26	Assembly overview water strip	155
4.27	Removing and installing water strip	155
5	Luggage compartment trims	158
5.1	Assembly overview - luggage compartment side trim on left	158
5.2	Assembly overview - luggage compartment side trim on right	159
5.3	Removing and installing luggage compartment side trim on left or right	159
5.4	Assembly overview - load sill cover	161
5.5	Removing and installing load sill cover	161
5.6	Assembly overview - luggage compartment trim on left (Cabriolet)	163
5.7	Assembly overview - luggage compartment trim on right (Cabriolet)	164
5.8	Removing and installing luggage compartment side trim on left or right (Cabriolet)	164
5.9	Removing and installing luggage compartment side trim (Cabriolet)	165
5.10	Assembly overview - load sill cover (Cabriolet)	166
5.11	Removing and installing load sill cover (Cabriolet)	167
5.12	Assembly overview - rear bulkhead trim (Cabriolet)	169
5.13	Removing and installing rear bulkhead trim (Cabriolet)	170
6	Tailgate/boot lid trim	172



6.1	Assembly overview - rear lid upper trim	172
6.2	Removing and installing rear lid upper trim	172
6.3	Assembly overview - rear lid lower trim	174
6.4	Removing and installing rear lid lower trim	174
6.5	Assembly overview - rear lid lower trim	176
6.6	Removing and installing rear lid lower trim	176
6.7	Assembly overview - luggage compartment lid trim (Cabriolet)	178
6.8	Removing and installing luggage compartment lid trim (Cabriolet)	179
6.9	Assembly overview - luggage compartment lid trim (Cabriolet for USA)	181
6.10	Removing and installing luggage compartment lid trim (Cabriolet for USA)	182
7	Roof trims	185
7.1	Tools	185
7.2	Removing and installing moulded headliner	185
7.3	Assembly overview - inner and outer trim for roof cross member (Cabriolet)	192
7.4	Removing and installing inner and outer trim for roof cross member (Cabriolet)	192
7.5	Assembly overview - roof cross member seal and retaining rail (Cabriolet)	194
7.6	Removing and installing roof cross member seal and retaining rail (Cabriolet)	194
72	Seat frames	196
1	Front seats	196
1.1	Tools	196
1.2	Removing and installing front seat	196
1.3	Assembly overview - front backrest	201
1.4	Removing and installing front backrest	202
1.5	Removing and installing head restraint guides	203
1.6	Assembly overview - seat height adjuster element	203
1.7	Removing and installing seat height adjustment element	204
1.8	Assembly overview - fire extinguisher bracket (front passenger side)	207
1.9	Removing and installing fire extinguisher bracket on front passenger side	208
1.10	Assembly overview - backrest frame ► 04.03 and (Cabriolet)	209
1.11	Assembly overview - backrest frame 05.03 ►	210
1.12	Removing and installing cable for adjusting seat longitudinally	210
1.13	Removing and installing lumbar support frame 05.03 ►	211
1.14	Removing and installing backrest release cable 05.03 ►	213
2	Rear seats	214
2.1	Removing and installing rear bench seat (one-piece)	214
2.2	Removing and installing backrest (one-piece)	215
2.3	Assembly overview - backrest locking device (one-piece backrest)	216
2.4	Removing and installing backrest locking device (one-piece backrest)	216
2.5	Removing and installing rear bench seat (two-piece)	218
2.6	Removing and installing backrest (two-piece)	219
2.7	Assembly overview - backrest locking device (two-piece backrest)	221
2.8	Removing and installing right backrest locking device (two-piece backrest)	221
2.9	Assembly overview - left backrest locking device (two-piece backrest)	223
2.10	Removing and installing left backrest locking device (two-piece (split) backrest)	224
2.11	Removing and installing rear bench seat (Cabriolet)	226
2.12	Removing and installing backrest (Cabriolet)	227
2.13	Assembly overview - through-loading aperture (Cabriolet)	228
2.14	Removing and installing through loading aperture (Cabriolet)	229
74	Seat - padding, covers	230
1	Front seat cover and padding	230
1.1	Tools	230
1.2	Removing and installing front seat cover and padding	230
1.3	Removing and installing front backrest cover and padding	232
1.4	Removing and installing cover and padding for front seat backrest 05.03 ►	235



1.5	Removing seat heater element	238
1.6	Removing backrest heater element	239
2	Rear seat cover and padding	241
2.1	Tools	241
2.2	Assembly overview - cover and padding for bench seat	241
2.3	Removing and installing cover and padding for rear bench seat	243
2.4	Assembly overview - cover and padding for seat backrest (one-piece or right-hand side)	244
2.5	Removing and installing cover and padding for seat backrest (one-piece or right-hand side)	245
2.6	Assembly overview - cover and padding for left backrest	248
2.7	Removing and installing cover and padding for left seat backrest	248
2.8	Assembly overview - cover and padding for backrest (Cabriolet)	251
2.9	Removing and installing cover and padding for seat backrest (Cabriolet)	252
2.10	Assembly overview - cover and padding for bench seat (Cabriolet)	253
2.11	Removing and installing cover and padding for bench seat (Cabriolet)	254