

|  |       |
|--|-------|
| 002 - 2.0l petrol engine , AEG,(6Y0),(8T0)   | 1-11  |
| 1. 2.0l petrol engine , AEG,(6Y0),(8T0)  | 1     |
| 2. Starter, Alternator, Ignition/starter switch, X-contact relief relay  | 2     |
| 3. Motronic control unit, Ignition transformer   | 3     |
| 4. Coolant temperature display sender, Hall sender, Coolant temperature sender, Throttle valve potentiometer, Throttle valve module potentiometer, Motronic control unit, Throttle valve module, Throttle valve module | 4     |
| 5. Engine speed sender, Knock sensor 1, Knock sensor 2, Motronic control unit  | 5     |
| 6. Lambda probe, Motronic control unit, Heater element for crankcase breather  | 6     |
| 7. Motronic control unit, Secondary air pump relay, Injector, cylinder 1, Injector, cylinder 2, Injector, cylinder 3, Injector, cylinder 4, Secondary air pump motor   | 7     |
| 8. Air mass meter, Lambda probe 2, Motronic control unit   | 8     |
| 9. Motronic control unit, Activated charcoal filter solenoid valve 1, Secondary air inlet valve, Fuel system diagnostic pump   | 9     |
| 10. Oil pressure switch, Fuel system pressurisation pump, Speedometer sender, Coolant shortage indicator sender, Fuel pump relay, Control unit in dash panel insert  | 10    |
| 11. Control unit in dash panel insert  | 11    |
| 009 - Convenience system with electric window regulators   | 12-23 |
| 1. Convenience system with electric window regulators  | 12    |
| 2. Front left window regulator switch, Front right window regulator switch in driver door, Driver side interior locking switch, Driver door control unit   | 13    |
| 3. Driver side central locking lock unit, Driver door control unit, Driver side mirror adjustment motor 2, Driver side mirror adjustment motor, Heated exterior mirror on driver side                                  | 14    |
| 4. Mirror adjustment switch, Mirror adjustment changeover switch, Driver door control unit, Front left entry light   | 15    |
| 5. Window regulator switch in front passenger door, Front passenger side central locking lock unit, Front passenger door control unit, Front passenger side window regulator motor                                     | 16    |
| 6. Front passenger door control unit, Front passenger side mirror adjustment motor 2   | 17    |
| 7. Driver vanity mirror contact switch, Front passenger vanity mirror contact switch, Front interior light, Rear left reading light, Rear right reading light  | 18    |
| 8. Convenience system central control unit   | 19    |
| 9. Tank filler flap remote release switch, Convenience system central control unit, Rear lid central locking motor, Tank filler flap locking motor   | 20    |
| 10. Convenience system central control unit  | 21    |
| 11. Contact switch in lock cylinder for rear lid, anti-theft alarm system and central locking system, Convenience system central control unit  | 22    |
| 12. Ignition/starter switch, Convenience system central control unit   | 23    |
| 019 - 2.0l petrol engine , AEG   | 24-33 |
| 1. 2.0l petrol engine , AEG  | 24    |
| 2. Starter, Alternator, Fuse 1 (30), in battery fuse holder, Fuse 2 (30), in battery fuse holder, Fuse 4 (30), in battery fuse holder, Fuse 5 (30), in battery fuse holder   | 25    |
| 3. Motronic control unit   | 26    |
| 4. Coolant temperature display sender, Motronic control unit, Throttle valve module  | 27    |
| 5. Engine speed sender, Knock sensor 1, Knock sensor 2, Motronic control unit  | 28    |
| 6. Lambda probe, Motronic control unit, Injector, cylinder 1, Injector, cylinder 2, Injector, cylinder 3, Injector, cylinder 4, Fuse 32 in fuse holder   | 29    |
| 7. Air mass meter, Lambda probe 2, Motronic control unit, Secondary air pump relay, Activated charcoal filter solenoid valve 1, Secondary air pump motor   | 30    |
| 8. Fuel gauge sender, Fuel system pressurisation pump, Coolant shortage indicator sender, Motronic control unit, Secondary air inlet valve, Fuse 43 in fuse holder, Fuel system diagnostic pump                        | 31    |
| 9. Oil pressure switch, Speedometer sender, Control unit in dash panel insert, Alternator warning lamp, Oil pressure warning lamp  | 32    |
| 10. Control unit in dash panel insert  | 33    |
| 036 - Convenience system with electric window regulators   | 34-45 |
| 1. Convenience system with electric window regulators  | 34    |
| 2. Front left window regulator switch, Front right window regulator switch in driver door, Driver side interior locking switch, Driver door control unit   | 35    |
| 3. Driver side central locking lock unit, Driver door control unit, Driver side mirror adjustment motor 2, Driver side mirror adjustment motor, Heated exterior mirror on driver side                                  | 36    |
| 4. Mirror adjustment switch, Mirror adjustment changeover switch, Driver door control unit, Left door warning lamp   | 37    |
| 5. Window regulator switch in front passenger door, Front passenger side central locking lock unit, Front passenger door control unit, Front passenger side window regulator motor                                     | 38    |
| 6. Front passenger door control unit, Front passenger side mirror adjustment motor 2   | 39    |
| 7. Driver vanity mirror contact switch, Front passenger vanity mirror contact switch, Front interior light. Rear left reading light. Rear right reading light  | 40    |

|  |       |
|--|-------|
| 8. Luggage compartment light switch, Convenience system central control unit   | 41    |
| 9. Tank filler flap remote release switch, Convenience system central control unit, Rear lid central locking motor, Tank filler flap locking motor | 42    |
| 10. Convenience system central control unit, Remote release switch illumination bulb   | 43    |
| 11. Contact switch in lock cylinder for rear lid, anti-theft alarm system and central locking system, Convenience system central control unit      | 44    |
| 12. Ignition/starter switch, Convenience system central control unit   | 45    |
| 806 - -Fitting locations: Earth points - 3   | 46-47 |
| 1. Earth points  | 46-47 |
| 1.1 Overview of earth points, from MY 1998 through MY 2002   | 46    |
| 1.2 Overview of earth points, from MY 2003   | 47    |