



Contents

27 - Starter, current supply, CCS	1
1 Battery	1
1.1 Battery - general notes	1
1.2 Types of battery	1
1.3 Warning notices and safety regulations	3
1.4 Battery terminal connection	5
2 Checking battery	6
2.1 Testing different battery types	6
2.2 Inspection	8
2.3 Information about battery replacement and battery gas venting	9
2.4 Checking colour indicator in battery cover, magic eye	10
2.5 Battery tester with printer VAS 5097 A	12
2.6 Battery tester with printer VAS 6161	17
2.7 Midtronics battery tester MCR340V , only for USA and Canada	22
2.8 Battery test using the vehicle diagnostic tester	26
2.9 Current draw test	27
2.10 Checking no-load voltage of battery (stock and stored vehicles)	28
3 Charging battery	30
3.1 Battery charger VAS 5095 A	30
3.2 Battery charger VAS 5900	35
3.3 Battery charger VAS 5903	47
3.4 Battery charger VAS 5906	59
3.5 Midtronics battery charger INC 940 , only for USA/Canada	61
3.6 Solar charger module VAS 6102 A	66
3.7 Totally discharged batteries	67
4 Cruise control system (CCS)	69
4.1 Function of cruise control system	69
4.2 Activating and deactivating cruise control system (CCS)	69
90 - Gauges, instruments	70
92 - Windscreen wash/wipe system	71
1 Washer fluid lines	71
1.1 Windscreen and rear window washer system	71
1.2 Headlight washer system	72
1.3 Repairing washer fluid lines	72
2 Distinguishing features of jointless wiper blades	75
94 - Lights, bulbs, switches - exterior	76
1 Operation and safety notes for gas discharge lamps	76
96 - Lights, bulbs, switches - interior	79
1 Cigarette lighter, socket	79
1.1 Assembly overview - cigarette lighter, 12 V socket	79
1.2 Removing and installing cigarette lighter U1	80
1.3 Removing and installing socket illumination bulb L42	83
1.4 Removing and installing cigarette lighter illumination bulb L28	83
97 - Wiring	85
1 Vehicle diagnosis, testing and information systems	85
1.1 General description - vehicle diagnosis, testing and information system	85
1.2 Connecting vehicle diagnostic tester	85
1.3 Connecting vehicle diagnostic tester, Bora/Golf, model years 1998 to 2003	86



2	Wiring harness and connector repairs	87
2.1	General notes concerning repairs to vehicle electrical system	87
2.2	Wiring harness repair set	88
2.3	Tool descriptions	90
2.4	Repairs to wiring harnesses	93
2.5	Repairs to fibre optic cables	109
2.6	Repair of aerial wires	115
2.7	Repairs to contact housings and connectors	126
2.8	Releasing and dismantling contact housings	130
3	Cleaning contact surfaces	136
3.1	Contact surface cleaning set VAS 6410	136
4	Renewing Lambda probe	142
4.1	Renewing LSF Lambda probe (4-pin)	142
4.2	Renewing LSU Lambda probe (6-pin)	142
4.3	Types of protective tube on uniform Lambda probes	143