



Contents

68 - Interior equipment	1
1 Interior mirror	1
1.1 Interior mirror	1
1.2 Automatic anti-dazzle interior mirror	1
1.3 Removing interior mirror	3
1.4 Installing interior mirror	3
1.5 Bonding retaining plate for interior mirror	3
1.6 Removing and installing interior mirror (with rain sensor)	5
1.7 Bonding on interior mirror base with rain sensor	5
2 Compartments, covers and trim	7
2.1 Compartments, covers and trim	7
2.2 Removing and installing centre console (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	7
2.3 Removing and installing centre console (Polo Classic 10.99 >, Polo Estate 10.99 >)	9
2.4 Removing handbrake lever grip and trim (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	13
2.5 Removing handbrake lever hand grip (Polo Classic 10.99 >, Polo Estate > 10.99)	14
2.6 Removing and installing driver's side compartment (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	15
2.7 Removing driver's side compartment (Polo Classic 10.99 >, Polo Estate 10.99 >)	17
2.8 Removing driver's side footwell cover	18
2.9 Removing front passenger's compartment (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	18
2.10 Removing glove box (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	19
2.11 Removing glove box (Polo Classic 10.99 >, Polo Estate 10.99 >)	20
2.12 Removing dash panel insert trim (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	21
2.13 Removing dash panel insert trim (Polo Classic 10.99 >, Polo Estate 10.99 >)	21
2.14 Removing sun visor	22
2.15 Removing and installing stowage compartment in front of roof headliner (Caddy)	23
3 Grab handle	24
3.1 Grab handle	24
3.2 Removing hand hold (roof)	24
4 Sill panel trims	25
4.1 Sill panel trims	25
4.2 Removing and installing inner sill panel trim	25
5 Luggage compartment cover	26
5.1 Luggage compartment cover	26
5.2 Removing and installing load area cover (Polo Estate)	26
5.3 Removing and installing load area floor (Polo Estate)	28
69 - Passenger protection	29
1 Seat belts	29
1.1 Seat belts	29
1.2 Safety regulations for belt tensioners	29
1.3 Checking belt tensioner	29
1.4 Removing and installing front seat belts with belt tensioning system (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	30
1.5 Removing and installing front seat belts with belt tensioning system (Polo Classic 10.99 >, Polo Estate 10.99 >)	33
1.6 Removing and installing belt height adjustment fittings (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	36
1.7 Removing and installing belt height adjustment fittings (Polo Classic 10.99 >, Polo Estate 10.99 >)	37
1.8 Removing front fittings	38
1.9 Removing front belt latch	38



1.10	Removing and installing rear seat belts	39
1.11	Removing and installing rear inertia reel (Caddy)	41
1.12	Removing and installing rear inertia reel (Polo Classic)	43
1.13	Removing and installing rear inertia reel (Polo Estate)	45
1.14	Removing and installing lap belt and double latch	47
2	Inspecting seat belts	47
2.1	Inspecting seat belts	47
3	Airbag	51
3.1	Airbag	51
3.2	Tools	51
3.3	Locations overview (Caddy, Polo Classic 09.99 >, Polo Estate > 09.99)	52
3.4	Locations overview (Polo Classic 10.99 >, Polo Estate 10.99 >)	54
3.5	Safety precautions when working on the airbag	55
3.6	Replacing airbag units following an accident	56
3.7	Removing and installing driver's airbag unit (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	57
3.8	Removing and installing driver's airbag unit (Polo Classic 10.99 >, Polo Estate 10.99 >)	59
3.9	Removing and installing steering wheel (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	63
3.10	Removing and installing steering wheel (Polo Classic 10.99>, Polo Estate 10.99 >)	64
3.11	Removing and installing coil connector with slip ring (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	66
3.12	Removing and installing coil connector with slip ring (Polo Classic 10.99>, Polo Estate 10.99>)	67
3.13	Removing and installing front passenger's airbag unit (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	69
3.14	Removing and installing front passenger's airbag unit (Polo Classic 10.99 >, Polo Estate 10.99 >)	72
3.15	Removing and installing airbag control unit (J 234)	75
3.16	Removing and installing driver's/front passenger's side airbag	76
3.17	Removing and installing sensor for driver's/front passenger's side airbag	79
70	- Trim/Insulation	82
1	Dash panel	82
1.1	Dash panel	82
1.2	Tools	82
1.3	Removing dash panel (Caddy, Polo Classic > 09.99, Polo Estate > 09.99)	83
1.4	Removing and installing dash panel (Polo Classic 10.99 >, Polo Estate 10.99 >)	88
2	Door trim	95
2.1	Door trim	95
2.2	Tools	95
2.3	Front door trim - assembly overview	96
2.4	Removing and installing front door trim	99
2.5	Rear door trim - Assembly overview (Caddy)	102
2.6	Rear door trim - Assembly overview (Polo Classic, Polo Estate)	104
2.7	Removing and installing rear door trim (Polo Classic, Polo Estate)	106
2.8	Removing and installing door insulation sheeting	108
3	Pillars and side trims	110
3.1	Pillars and side trims	110
3.2	Removing and installing A pillar trim	110
3.3	Removing and installing B pillar upper trim (Caddy)	112
3.4	Removing and installing side trim (Caddy)	114
3.5	Removing and installing B pillar trim (Polo Classic, Polo Estate)	116
3.6	Removing and installing C and D pillar trim (Polo Classic)	119
3.7	Removing and installing C pillar lower trim (Polo Classic)	122
3.8	Removing and installing C pillar upper trim (Polo Estate)	124
3.9	Removing and installing C pillar lower trim (Polo Estate)	126
3.10	Removing and installing D pillar trim (Polo Estate)	128



4	Tailgate/boot lid trim	130
4.1	Tailgate/boot lid trim	130
4.2	Removing and installing boot lid trim (Polo Classic)	130
4.3	Removing and installing tailgate trim (Polo Estate)	131
5	Load area/luggage compartment trim	132
5.1	Load area/luggage compartment trim	132
5.2	Removing and installing - load area trim (Caddy)	132
5.3	Removing and installing luggage compartment floor trim (Polo Classic)	133
5.4	Removing and installing luggage compartment side trim (Polo Classic)	134
5.5	Removing and installing rear lock carrier cover (Polo Classic)	136
5.6	Removing and installing rear shelf (Polo Classic)	138
5.7	Removing and installing rear lock carrier cover (Polo Estate)	139
5.8	Removing and installing load area side panel trim (Polo Estate)	140
6	Roof trim	142
6.1	Roof trim	142
6.2	Removing and installing front moulded headlining (Caddy)	142
6.3	Removing and installing rear moulded headlining (Caddy)	144
6.4	Removing and installing moulded headliner (Polo Classic, Polo Estate)	145
6.5	Removing and installing moulded headliner with sliding/tilting sun roof (Polo Classic, Polo Estate)	150
72	- Seat frames	156
1	Front seat	156
1.1	Front seat	156
1.2	Tools	156
1.3	Removing seat	156
1.4	Removing and installing front seat with side airbag	157
1.5	Front bearing for folding front seat (Caddy) - Assembly overview	160
1.6	Removing and installing backrest	162
1.7	Seat frame - Assembly overview	166
1.8	Folding seat frame (Caddy) - Assembly overview	168
1.9	Removing and installing cable for releasing folding seat (Caddy)	170
1.10	Removing pull loop	171
1.11	Backrest frame - Assembly overview	172
2	Rear seat	173
2.1	Rear seat	173
2.2	Removing seat and backrest (split) (Caddy)	173
2.3	Removing seat and backrest (split) (Polo Classic, Polo Estate)	174
74	- Seats - Upholstery, Covers	176
1	Front seat cover and padding	176
1.1	Front seat cover and padding	176
1.2	Removing and installing cover and padding for front seat cushion	176
1.3	Removing and installing front backrest cover and padding (Caddy)	181
1.4	Removing and installing front backrest cover and padding (Polo Classic, Polo Estate)	186
2	Rear seat cushion cover and padding	191
2.1	Rear seat cushion cover and padding	191
2.2	Removing and installing cover and padding for rear seat (one-piece)	191
2.3	Removing and installing cover and padding for backrest (one-piece)	192
2.4	Removing and installing cover and padding for seat (split)	194
2.5	Removing and installing covers and padding for backrest (split)	195