



Contents

27 - Starter, current supply, CCS	1
1 Battery A	1
1.1 Important information concerning battery A	1
1.2 Battery A types	2
1.3 Warning notes and safety norms	3
1.4 Battery A connection terminals	5
2 Battery A - check	6
2.1 Battery A checking sequence	6
2.2 Check visually	6
2.3 Check the battery A with inspection window	7
2.4 Check the battery A with battery inspection window "3 colours"	8
2.5 Check the battery A with battery inspection window "2 colours"	8
2.6 Checking the low-maintenance battery A	9
2.7 Check the charge of the Battery A	13
2.8 Charge acceptance test	21
2.9 Check the resting current of the battery	23
2.10 Check the final battery charge	26
2.11 Checking the resting voltage of batteries (unused or stored vehicles)	28
3 Battery A - charging	30
3.1 Battery charger VAS 5095A	30
3.2 Battery charger VAS 5900	35
3.3 Battery charger VAS 5900A	47
3.4 Battery charger VAS 5903	49
3.5 Battery charger VAS 5906	60
3.6 Battery charger VAS 5908	63
3.7 Completely flat batteries	72
3.8 Battery (Delphi) - charging procedure	73
4 Speed regulator (GRA)	77
4.1 Speed regulator (GRA) - activating/deactivating	77
92 - Windscreen wash/wipe system	78
1 Washer hoses - connecting and disconnecting	78
2 Washer hoses - repair	80
2.1 Repairing smooth hoses	80
2.2 Repairing wrinkled hoses	80
94 - Lights, bulbs, switches - exterior	83
1 Adhere to the safety warnings and the application of gas-discharge lamps	83
97 - Wiring	86
1 Vehicle diagnostic, testing and information system	86
1.1 Vehicle Diagnosis, Measurement and Information System - connect	86
2 Harness and connection repairs	89
2.1 Harness repair kits	89
2.2 Description of tools	90
2.3 General notes on repair work on the electrical system of the vehicle	94
2.4 Harness repair	95
2.5 Repairing connector terminals and connectors	107
2.6 Unlocking and disassembling the terminals	113