



Contents

01 - Self-diagnosis	1
1 Vehicle diagnosis, testing and information systems	1
1.1 Connecting vehicle diagnosis, testing and information system VAS 5051A	2
2 Immobilizer self-diagnosis	4
2.1 Performing immobilizer self-diagnosis	4
2.2 Fault table	9
2.3 Reading data block	11
2.4 Coding immobilizer control unit J362	13
3 Guided functions for immobilizer	15
3.1 Observe additional information and prerequisites for "online request with GeKo-VW"	15
3.2 Online system test	16
3.3 Adaptation of ignition keys	16
3.4 Adaption (matching) after changing engine control unit	17
3.5 Adapting immobilizer	17
27 - Starter, current supply, CCS	18
1 Battery	18
1.1 Battery contents list	18
1.2 Fundamentals for batteries	18
1.3 Battery handling instructions	19
1.4 Batteries with magic eye	21
1.5 Batteries with no magic eye	23
1.6 Checking specific gravity	26
1.7 Battery load test	29
1.8 Charging battery	30
1.9 Removing and installing battery	31
1.10 Explanation of central gas venting	35
2 Starter	37
2.1 Removing and installing starter (1.4 l petrol engine)	37
2.2 Removing and installing starter (1.6 l, 1.8 l petrol engines and diesel engines)	38
3 Alternator	41
3.1 Assembly overview	41
3.2 Poly-V-belt drives	51
3.3 Checking V-belt	52
3.4 Checking poly-V-belt	53
3.5 Removing and installing poly-V-belt	53
3.6 Compact alternator with poly-V-belt drive, vehicles ▶ 04.99	58
3.7 Checking carbon brushes for alternator, vehicles ▶ 04.99	58
3.8 Removing and installing voltage regulator for alternator, vehicles ▶ 04.99	59
3.9 Compact alternator with poly-V-belt drive, vehicles 05.99 ▶	59
3.10 Checking carbon brushes for alternator, vehicles 05.99 ▶	60
3.11 Removing and installing voltage regulator for alternator, vehicles 05.99 ▶	60
3.12 Renewing poly-V-belt pulley on alternator	61
3.13 Removing and installing poly-V-belt pulley with freewheel	62
90 - Gauges, instruments	64
1 Dash panel insert	64
1.1 Removing and installing dash panel insert	64
1.2 Renewing bulbs in dash panel insert (VDO)	65
1.3 Renewing bulbs in dash panel insert (MOTOMETER)	66
1.4 Dash panel insert warning lamp symbols (VDO unit)	67
1.5 Pin assignment on dash panel insert	68



2	Service interval display	69
2.1	Service interval display	69
2.2	Resetting service interval display	69
2.3	Flexible service interval display	70
2.4	Resetting flexible service interval display	70
2.5	Entering service interval data	71
92	- Windscreen wash/wipe system	73
1	Windscreen wiper system	73
1.1	Assembly overview - windscreen wiper system	73
1.2	Removing and installing windscreen wiper system	74
1.3	Removing and installing wiper rubber blade	78
2	Windscreen washer and headlight washer system	79
2.1	Assembly overview - windscreen washer and headlight washer system	79
2.2	Adjusting windscreen washer system jets	79
2.3	Adjusting headlight washer system jets	80
2.4	Removing windscreen washer system spray jets	81
2.5	Removing headlight washer system spray jets	81
2.6	Removing windscreen washer and headlight washer system reservoir	81
3	Rear window wipe/wash system	83
3.1	Assembly overview - rear window wiper system (Caddy)	83
3.2	Assembly overview - rear window wiper system (Polo Variant)	84
3.3	Adjusting rear window wiper park position	84
3.4	Adjusting washer jet	85
3.5	Removing rear window wiper (Caddy)	86
3.6	Removing rear window wiper system (Polo Variant)	87
94	- Lights, bulbs, switches - exterior	89
1	Headlight	89
1.1	Assembly overview - headlight	89
1.2	Adjusting headlights	90
1.3	Removing and installing headlight	90
1.4	Replacing headlight bulb	90
1.5	Removing and installing headlight range control motor	91
2	Front fog lights	93
2.1	Removing and installing fog light	93
2.2	Removing and installing fog light bulb	93
3	Front turn signals	94
3.1	Removing and installing front turn signal	94
3.2	Removing and installing turn signal bulb	94
4	Side mounted repeater turn signals	95
4.1	Removing and installing side mounted repeater turn signal	95
5	Tail lights	96
5.1	Assembly overview - tail light (Caddy)	96
5.2	Assembly overview - tail light (Polo Classic)	96
5.3	Assembly overview - tail light (Polo Variant)	97
5.4	Removing and installing tail light bulb holder (Caddy)	98
5.5	Removing and installing tail light bulb holder (Polo Variant)	99
5.6	Removing and installing tail light bulb holder (Polo Classic)	99
6	Additional brake lights	100
6.1	Additional brake light (Polo Classic)	100
6.2	Additional brake light (Polo Variant)	101
7	Number plate lights	103
7.1	Number plate light (Polo Classic)	103



7.2	Number plate light (Caddy)	104
7.3	Number plate light (Polo Variant)	104
8	Steering column switch and ignition and starter switch	106
8.1	Assembly overview - steering column	106
8.2	Removing and installing steering column switch	107
8.3	Pin assignment on steering column switch	109
8.4	Removing and installing steering lock housing	110
8.5	Removing and installing lock cylinder	113
8.6	Removing and installing ignition / starter switch	114
8.7	Pin assignment for ignition switch	114
96	- Lights, bulbs, switches - interior	115
1	Immobilizer	115
1.1	Assembly overview - immobilizer	115
1.2	Removing and installing immobilizer control unit J362	115
1.3	Removing and installing immobilizer reader coil D2	116
1.4	Transponder	116
2	Interior lights and switches	117
2.1	Assembly overview - switches in dash panel	117
2.2	Removing and installing light switch E1	117
2.3	Removing and installing switches in centre of dash panel	118
2.4	Interior light	118
2.5	Removing and installing glove compartment light W6	120
2.6	Removing and installing door contact switch	120
2.7	Removing and installing luggage compartment light switch	120
2.8	Removing and installing luggage compartment light W3	121
97	- Wiring	122
1	Removing and installing relay plate, coupling station and fuse holder	122
1.1	Removing and installing relay plate	122
1.2	Removing and installing multi-pin connector on back of relay plate	123
2	Wiring harness and connector repairs	124
2.1	Notes on safety	124
2.2	General notes concerning repairs to vehicle electrical system	124
2.3	Notes on repairs to wiring harness and connectors	124
2.4	Supplementary notes on repair of CAN bus wiring	125
2.5	Wiring harness repair set V.A.G 1978	125
3	Renewal of aerial wiring	127
3.1	General description	127
3.2	Assembly overview - aerial wire	127
3.3	Installing a new aerial wire	127