



Contents

1	Engine list	1
2	Delivery Inspection	5
3	Oil change service	6
3.1	Oil change service every 7,500 km	6
3.2	Oil change service every 15,000 km	6
4	Inspection service	7
4.1	Inspection service every 12 months	7
4.2	Inspection service at 30,000, 60,000 , 90,000, 120,000 km etc.	8
5	Descriptions of work	11
5.1	Oil level: Check	11
5.2	Engine oil: Change	11
5.3	Fuel filter: Renew	13
5.4	Fuel filter: Drain water (diesel engine)	14
5.5	Valve clearance: Check and adjust (rocker finger motor)	14
5.6	Contact breaker points: Renew (engine code GT)	15
5.7	Engine (from below): Perform visual check for leaks and damage	16
5.8	Engine (from above): Perform visual check for leaks and damage	16
5.9	Frost protection: Check, if necessary replenish coolant additive	17
5.10	Coolant level: Check, if necessary replenish coolant	18
5.11	Read fault memory using fault reader V.A.G 1551	19
5.12	Performing engine basic setting (vehicles with petrol engine and regulated catalytic converter)	21
5.13	Idling speed: Check, adjust if necessary (diesel engine)	41
5.14	Components influencing emissions: Perform visual check	42
5.15	Connecting test units	42
5.16	Test sequence	42
5.17	V-belt: Check condition and tension, tension V-belt if necessary	43
5.18	Camshaft drive toothed belt: Check condition and tension, tension if necessary	44
5.19	Checking and adjusting clutch play	45
5.20	Gearbox/final drive: Check oil level, replenish oil if necessary (manual gearbox)	46
5.21	Track rod ends: Check play, security and boots	46
5.22	Tyres (including spare): Check	47
5.23	Wheel securing bolts: Check for prescribed torque setting	49
5.24	Front and rear brake pads/linings: Check thickness	49
5.25	Front disc brake pads: Check thickness	50
5.26	Brake system: Perform visual check for leaks and damage	50
5.27	Brake fluid level: Check	50
5.28	Changing brake fluid (every 2 years)	51
5.29	Underbody protection: Perform visual check for damage	52
5.30	Door arrester and securing pins: Grease	53
5.31	Headlight setting: Check, adjust if necessary	53
5.32	Battery: Check no load voltage	55
5.33	Battery: Check electrolyte level and top-up with distilled water if necessary	56
5.34	Windscreen wipe/wash system: Check jet setting, adjust jets if necessary	56
5.35	Headlight washer system: Check, if necessary adjust spray jets	58
5.36	Windscreen wiper blades: Check park position and setting angle if wiper blades judder, adjust if necessary	58
5.37	Activating radio anti-theft coding	60
5.38	Clock: Set to correct time	61
5.39	Performing road test	61
5.40	Type plate, vehicle identification number	61
5.41	Engine code and engine number	62
5.42	Lifting vehicle	62



5.43	Tow starting and towing	63
6	Legally required extra work according to country	65
6.1	Perform emissions test	65