



Contents

1	Engine list	1
2	Service work	5
2.1	Information on LongLife service and time or distance dependent service	5
2.2	Service tables	7
2.3	Delivery inspection	11
2.4	Oil change service	13
2.5	Interval service 2008►	14
2.6	Inspection ►2007	16
2.7	Inspection service 2008►	18
2.8	Time or distance dependent additional work	20
2.9	Service intervals with market-specific deviations	24
3	General information	26
3.1	Stickers	26
3.2	Entries in service schedule	27
3.3	Connecting vehicle diagnostic tester	28
3.4	Raising vehicle with lifting platform or trolley jack	29
3.5	Vehicle identification number	31
3.6	Vehicle data sticker	32
3.7	Countries where diesel has a high sulphur content	32
3.8	Engine code and engine number	33
3.9	RME fuel (biodiesel)	33
3.10	Severe operating conditions	34
3.11	Type plate	34
4	Descriptions of work:	36
4.1	Removable towing bracket: checking and cleaning if necessary	37
4.2	Swivel joints and suspension link mountings: inspecting	39
4.3	Automatic gearbox: checking ATF level	40
4.4	Automatic gearbox: changing ATF (09G gearbox)	40
4.5	Battery: checking battery terminal clamps for secure seating	41
4.6	Battery: Checking using battery tester with printer VAS 5097A or VAS 6161	42
4.7	Brake and clutch system: Changing brake fluid	42
4.8	Brake fluid level: checking	47
4.9	Front passenger airbag: checking key switch and "On/Off function"	48
4.10	Tyres: checking condition, wear pattern, tread depth, tyre pressure and age	49
4.11	Brake system and shock absorbers: inspecting for leaks and damage	58
4.12	Brakes, front and rear: checking thickness of brake pads and condition of brake discs	59
4.13	Electric windows: Carry out initialisation (activation)	63
4.14	Vehicle system test: Carry out test	63
4.15	Bonnet: greasing arrester	64
4.16	Adding multi-purpose additive G17	64
4.17	Boots: inspecting	65
4.18	Checking expiry date of first-aid kit	65
4.19	Interior and exterior body: inspecting for corrosion with doors and flaps open	65
4.20	Poly V-belt: Checking tension, adjusting if necessary	65
4.21	Poly V-belt: checking condition	65
4.22	Checking number plate on vehicle bumper (Polo Cross)	66
4.23	Fuel filter: Renewing (diesel engine)	66
4.24	Fuel filter: Draining water (diesel engine)	67
4.25	Cooling system: checking frost protection and coolant level	69
4.26	Air filter: Cleaning housing and renewing filter element	71
4.27	Engine oil level: Check, replenish engine oil if necessary	74
4.28	Engine oil: Draining or extracting and replenishing; renewing oil filter	75



4.29	Engine and components in engine compartment: inspecting for leaks and damage (from above and below)	81
4.30	Removing and installing engine cover panel -top-	81
4.31	Removing and installing engine cover -bottom- (noise insulation)	84
4.32	Road test: performing (driving behaviour, noises, air conditioner etc.)	85
4.33	Wheel securing bolts: tightening to specified torque	85
4.34	Radio/radio navigation system: entering PIN of anti-theft coding and storing local radio stations to station buttons	87
4.35	Radio code: reading using vehicle diagnostic tester	88
4.36	Tyre repair set: checking	89
4.37	Tyre Pressure Loss Indicator: performing basic setting	89
4.38	Manual gearbox/final drive: Checking oil level, replenishing oil if necessary	90
4.39	Window wiper and washer system and headlight washer system: Checking function	90
4.40	Wiper blade protection: removing	95
4.41	Headlight adjustment: Check, adjust headlights if necessary	98
4.42	Sunroof: checking function, cleaning and greasing guide rails	103
4.43	Service interval display: resetting	103
4.44	Service interval display: recoding	106
4.45	Track rod ends: checking clearance, firm seating and boots	107
4.46	Dust and pollen filter: renew filter element	108
4.47	Door arrester: grease.	108
4.48	Transportation device: Remove blocking pieces from front axle springs	109
4.49	Recoding dash panel insert	110
4.50	Clock: setting to correct time	111
4.51	Underseal: inspecting for damage to underseal, underbody cladding, routing of lines and plugs	111
4.52	Toothed belt and tensioning roller: Renew	111
4.53	Camshaft drive toothed belt: Renewing (4-cylinder 5-valve petrol engine)	112
4.54	Camshaft drive toothed belt: Check (4-cylinder petrol engine) not for engine code AXU	112
4.55	Renewing spark plugs	112
4.56	Diesel particulate filter: check.	119
5	Exhaust emissions test	120
5.1	Exhaust emissions test for petrol engines	120
5.2	Exhaust emissions test for diesel engines	129
6	Glossary	149