



## Contents

<b>27 - Starter, current supply, CCS</b>	<b>1</b>
<b>1 Battery</b>	<b>1</b>
1.1 Fundamentals for batteries	1
1.2 Types of battery	1
1.3 Warning notices and safety regulations	2
1.4 Battery terminal connection	4
<b>2 Checking battery</b>	<b>5</b>
2.1 Checking battery with magic eye	5
2.2 Checking absorbent glass mat battery (AGM battery)	5
2.3 Visual check	6
2.4 Checking colour display of magic eye	6
2.5 Battery tester with printer VAS 5097 A	7
2.6 Current draw test	12
2.7 Checking no-load voltage of battery on stock and stored vehicles	13
<b>3 Charging battery</b>	<b>15</b>
3.1 Battery charger VAS 5095 A	15
3.2 Battery charger VAS 5900	19
3.3 Battery charger VAS 5903	27
3.4 Totally discharged batteries	36
<b>4 Cruise control system (CCS)</b>	<b>37</b>
4.1 Activating and deactivating cruise control system (CCS)	37
<b>92 - Windscreen wash/wipe system</b>	<b>38</b>
<b>1 Washer fluid line hose couplings</b>	<b>38</b>
1.1 Windscreen and rear window washer system	38
1.2 Headlight washer system	39
<b>2 Hose repair</b>	<b>40</b>
2.1 General description	40
2.2 Repairing smooth pipe	40
2.3 Repairing corrugated pipe	40
<b>94 - Lights, bulbs, switches - exterior</b>	<b>42</b>
<b>1 Operation and safety notes for gas discharge bulbs</b>	<b>42</b>
<b>97 - Wiring</b>	<b>45</b>
<b>1 Vehicle diagnosis, testing and information systems</b>	<b>45</b>
1.1 Connecting vehicle diagnosis, testing and information system VAS 5051A	45
1.2 Connecting vehicle diagnosis, testing and information system VAS 5051A , Golf Model Year 1998 - 2003	47
<b>2 Repairing wiring harness and connectors</b>	<b>48</b>
2.1 Wiring harness repair set	48
2.2 Tool descriptions	49
2.3 General notes concerning repairs to vehicle electrical system	52
2.4 Repairs to wiring harnesses	53
2.5 Repairs to contact housings and connectors	64
2.6 Releasing and dismantling contact housings	68