



Contents

00 - Technical data	1
1 — Change history —	1
2 Repair instructions	2
2.1 General repair instructions	2
2.2 Installation and securing of pipelines and cables	2
2.3 Notes on CAN-Bus cable repair work	2
91 - Communication	3
1 Infotainment	3
1.1 Infotainment - architecture	3
1.2 Infotainment system - overview of fitting locations	5
1.3 Infotainment system display - remove and install	6
1.4 Control unit 1 for information electronics J794 - remove and install	8
1.5 Infotainment system, Mib Regio - remove and install	9
2 Radio system	11
2.1 Sound system - assembly overview	11
2.2 Amplifier R12 - remove and install	12
2.3 Amplifier R12 support bracket - remove and install	13
2.4 Front treble loudspeaker R20 / R22 - remove and install	14
2.5 Rear loudspeaker R4 / R5- remove and install	14
2.6 Front bass loudspeaker R2 / R3 - remove and install	16
2.7 Subwoofer R211 - remove and install	17
2.8 Subwoofer R211 support bracket - remove and install	18
3 Aerial systems	22
3.1 Aerial systems - architecture	22
3.2 Aerial systems - overview of fitting locations	22
3.3 Rear window aerial 1 R130 - remove and install	23
3.4 Roof aerial RX5 - remove and install	24
4 Radio	26
4.1 Radio - architecture	26
4.2 Radio - remove and install	27
5 Phone system	29
5.1 Provision for mobile telephone	29
5.2 Telephone system - overview of fitting locations	29
5.3 Telephone microphone R38 - remove e install	30
5.4 Connecting base for USB charging socket 2 U38 - remove and install	32
6 Navigation system	34
6.1 Navigation system - architecture	34
6.2 Navigation system - fitting location overview	34
6.3 Navigation system control unit - remove and install	35
7 Rear view camera system	36
7.1 Rear view camera - architecture	36
7.2 Rear view camera system - assembly overview	36
7.3 Reversing camera R189 - remove and install	38
8 Multifunction steering wheel	41
8.1 Multifunction steering wheel - architecture	41
8.2 Multifunction steering wheel - general assembly overview	41
8.3 Multifunction steering wheel buttons E440 / E441 - remove and install	42
8.4 Tiptronic switch on the steering wheelE439 / E438 - remove and install	46
9 Port for external multimedia devices	48
9.1 USB 1 port U41 USB port in the front centre console - remove and install	48



9.2 USB port 2 U42 USB port in the rear centre console - remove and install 49