



Contents

| | |
|---|----|
| 00 - Technical data | 1 |
| 1 --- Change history --- | 1 |
| 2 Repair instructions | 2 |
| 2.1 General repair instructions | 2 |
| 2.2 Installation and securing of pipelines and cables | 2 |
| 2.3 Notes on CAN-Bus cable repair work | 2 |
| 91 - Communication | 3 |
| 1 Infotainment | 3 |
| 1.1 Infotainment - architecture | 3 |
| 1.2 Infotainment - assembly overview | 5 |
| 1.3 Infotainment system display - remove and install | 7 |
| 1.4 Control unit 1 for information electronics J794 - remove and install | 8 |
| 1.5 Infotainment system, Mib Regio – remove and install | 9 |
| 2 Radio system | 11 |
| 2.1 Radio system - assembly overview | 11 |
| 2.2 Front treble loudspeaker R20 / R22 - remove and install | 12 |
| 2.3 Rear loudspeaker R4 / R5- remove and install | 13 |
| 2.4 Front bass loudspeaker R2 / R3 - remove and install | 14 |
| 2.5 Support of the Digital sound package control unit J525 - remove and install | 15 |
| 2.6 Digital sound package generator/control unit - remove and install | 16 |
| 2.7 Subwoofer R211 - remove and install | 17 |
| 2.8 Remove and install the subwoofer R211 support | 19 |
| 3 Aerial systems | 22 |
| 3.1 Aerial systems - assembly overview | 22 |
| 3.2 Left aerial module R108- remove and install | 22 |
| 3.3 Roof aerial RX5 - remove and install | 24 |
| 3.4 Rear bumper aerial LTE 1 R297 - remove and install | 25 |
| 4 Radio | 27 |
| 4.1 Radio - architecture | 27 |
| 4.2 Radio - remove and install | 28 |
| 5 Phone system | 30 |
| 5.1 Provision for mobile telephone | 30 |
| 5.2 Telephone systems - assembly overview | 31 |
| 5.3 Telephone microphone R38 - remove e install | 32 |
| 5.4 USB connector inlet base (MID) - remove and install | 34 |
| 5.5 Storage compartment with mobile phone interface R265 - remove and install | 35 |
| 6 Navigation system | 36 |
| 6.1 Navigation system - structure | 36 |
| 6.2 Navigation system - assembly overview | 36 |
| 6.3 Navigation system control unit - remove and install | 37 |
| 7 Rear view camera system | 38 |
| 7.1 Rear view camera - structure | 38 |
| 7.2 Reversing camera R189 - remove and install | 38 |
| 8 Multifunction steering wheel | 39 |
| 8.1 Multifunction steering wheel - architecture | 39 |
| 8.2 Multifunction steering wheel - general assembly overview | 39 |
| 8.3 Multifunction steering wheel buttons J453 / E441 - remove and install | 40 |
| 8.4 Tiptronic switch on the steering wheelE439 / E438 - remove and install | 44 |
| 9 Port for external multimedia devices | 46 |
| 9.1 USB port in the front centre console - remove and install | 46 |



| | | |
|-----|--|----|
| 9.2 | USB 2 ports U37 - remove and install | 47 |
|-----|--|----|