



## Contents

<b>00 - Technical data</b>	<b>1</b>
<b>1 Safety information</b>	<b>1</b>
1.1 Safety precautions when working on air conditioning systems	1
1.2 Safety precautions when handling refrigerants	1
1.3 Safety measures when working on vehicles with a start/stop system	2
1.4 Safety precautions when using air conditioner service stations	2
1.5 Safety precautions when handling refrigerants R1234yf and R134a	2
1.6 Safety measures for working on vehicles with high-voltage system	3
1.7 Safety precautions when working in the vicinity of high-voltage components	3
<b>2 Laws and regulations</b>	<b>5</b>
2.1 Legal regulations and standards	5
2.2 Charging refrigerant circuit with different refrigerants	6
2.3 Occupational health and safety	6
<b>3 Repair notes</b>	<b>7</b>
3.1 Rules for cleanliness	7
3.2 Refrigerant circuit seals	7
3.3 Refrigerant and refrigerant oil	7
3.4 Handling pressure vessels	10
3.5 Handling refrigerants	11
<b>4 Identification</b>	<b>13</b>
4.1 Notice for refrigerant circuit	13
<b>5 Technical data</b>	<b>14</b>
5.1 Refrigerant capacity	14
5.2 Refrigerant oil capacities	14
5.3 Safety data sheets	14
<b>6 Basic technical and physical properties</b>	<b>15</b>
6.1 Basics of air conditioning technology	15
6.2 Physical properties	21
6.3 Product characteristics	26
6.4 Function and role of air conditioning system	27
6.5 Other reference material	28
<b>87 - Air conditioning system</b>	<b>29</b>
<b>1 Refrigerant circuit</b>	<b>29</b>
1.1 System overview - refrigerant circuit	29
1.2 General description - components of refrigerant circuit	29
1.3 Possible complaints	41
1.4 Investigating leaks	43
1.5 Renewing components	47
1.6 Cleaning refrigerant circuit	52
1.7 Checking pressures with pressure gauge	57
<b>2 Working with air conditioner service station</b>	<b>59</b>
2.1 General information on working with air conditioner service station	59
2.2 Connecting air conditioner service station to refrigerant circuit	61
2.3 Purging refrigerant circuit	62
2.4 Evacuating refrigerant circuit	64
2.5 Charging refrigerant circuit	67
2.6 Bringing air conditioning system into service after charging	70
2.7 Switching off air conditioner service station and separating from refrigerant circuit	70
2.8 Filling refrigerant into internal pressure vessel	72
2.9 Connecting and detaching supplied cylinder	72
2.10 Emptying air conditioner service station	72



2.11	Cleaning refrigerant circuit .....	72
2.12	Filling contaminated refrigerant in a recycling cylinder for analysis, processing or disposal ..	72
<b>3</b>	<b>Testing equipment and tools .....</b>	<b>73</b>
3.1	Tools and materials available from distribution centre or importer .....	73
3.2	Tools and materials available commercially .....	73