



Contents

27 - Starter, current supply, CCS	1
1 Battery A	1
1.1 Important information concerning battery A	1
1.2 Battery A types	2
1.3 Warning notes and safety norms	3
1.4 Battery A connection terminals	6
2 Battery A - check	7
2.1 Battery A checking sequence	7
2.2 Check visually	8
2.3 Battery degassing and replacement instructions	9
2.4 Check the Battery A with inspection window	9
2.5 Checking the low-maintenance Battery	11
2.6 Current consumption - test	15
2.7 Check the charge of the Battery A	16
2.8 Charge acceptance test	28
2.9 Check the resting current of the battery	29
2.10 Check Battery A charging	32
2.11 Checking the resting voltage of batteries (unused or stored vehicles)	34
3 Battery A - charging	36
3.1 Cautions when handling Battery A chargers	36
3.2 Battery charger VAS 5095A	38
3.3 Battery charger VAS 5900	43
3.4 Battery charger VAS 5900A	55
3.5 Battery charger VAS 5903	57
3.6 Battery charger VAS 5906	68
3.7 Battery charger VAS 5908	71
3.8 Completely flat batteries	80
3.9 Battery (Delphi) - charging procedure	81
4 Speed regulator (GRA)	85
4.1 Speed regulator (GRA) - activating/deactivating	85
92 - Windscreen wash/wipe system	86
1 Washer hoses - connecting and disconnecting	86
2 Washer hoses - repair	88
2.1 Repairing smooth hoses	88
2.2 Repairing wrinkled hoses	88
94 - Lights, bulbs, switches - exterior	91
1 Adhere to the safety warnings and the application of gas-discharge lamps	91
96 - Lights, bulbs, switches - interior	94
1 12-V socket	94
1.1 12-V socket - remove and install	94
1.2 Socket box light bulb L42 - remove and install	94
2 Lighter U1	95
2.1 General description	95
2.2 Assembly overview	96
2.3 Lighter socket - remove and install	97
2.4 Cigarette lighter light bulb L28 - remove and install	100
97 - Wiring	102
1 Vehicle diagnostic, testing and information system	102



1.1	Vehicle Diagnosis, Measurement and Information System - connect	102
2	Harness and connection repairs	105
2.1	General notes on repair work on the electrical system of the vehicle	105
2.2	Harness repair kits	106
2.3	Description of tools	108
2.4	Harness repair	113
2.5	Fibre optic cable repairs	140
2.6	Aerial cable repairs	149
2.7	Repairing connector terminals and connectors	161
2.8	Unlocking and disassembling the terminals	167
3	Electrical contact cleaning set VAS 6410	175
3.1	Use of the Electrical contact cleaning set VAS 6410	175
4	Lambda probe - replace	183
4.1	LSF lambda probe (4 poles) - replace	183
4.2	LSU lambda probe (6 poles) - replace	184
4.3	Versions of the protection tube of unit lambda probes	185