Contents

01 - Self-diagnosis 1
1 General to self-diagnosis 1
1.1 General to self-diagnosis 1
1.2 Features of self-diagnosis 1
1.3 Technical data of self-diagnosis 1
1.4 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert 2
1.5 Significance of exhaust emissions warning lamp 3
1.6 Connecting fault reader 4
2 Fault memory 7
2.1 Fault memory 7
2.2 Interrogating and erasing fault memory of engine control unit 7
2.3 Automatic test sequence 8
3 Fault table: SAE P0 codes 9
3.1 Fault table: SAE P0 codes 9
4 Fault table: SAE P1 codes 13
4.1 Fault table: SAE P1 codes 13
5 Final control diagnosis 19
5.1 Final control diagnosis 19
5.2 Performing final control diagnosis 19
6 Readiness code 22
6.1 Readiness code 22
6.2 Function 22
6.3 Reading readiness code 22
6.4 Generating readiness code 23
7 Measured value blocks 29
7.1 Measured value blocks 29
7.2 Safety precautions 29
7.3 Read measured value block 29
8 Evaluating measured value blocks, display groups 0...9 -Basic functions- 31
8.1 Evaluating measured value blocks, display groups 0...9 -Basic functions- 31
9 Evaluating measured value blocks, display groups 10...29 -Ignition- 34
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition- 34
10 Evaluating measured value blocks, display grps 30...49, 99 -Lambda regulation- 38
10.1 Evaluating measured value blocks, display grps 30...49, 99 -Lambda regulation- 38
11 Evaluating measured value blocks, display groups 50...69 -Speed regulation- 43
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation- 43
12 Evaluating measured value blocks, display groups 70...79 -Reducing emissions- 46
12.1 Evaluating measured value blocks, display groups 70...79 -Reducing emissions- 46
13 Evaluating measured value blocks, display group 100 -Readiness code- 47
13.1 Evaluating measured value blocks, display group 100 -Readiness code- 47

24 - Mixture preparation, Injection 48
1 Servicing injection system 48
1.1 Servicing injection system 48
1.2 Fitting locations overview 48
1.3 General notes on injection 52
1.4 Removing and installing parts of the injection system 53
1.5 Dismantling and assembling intake manifold 62
1.6 Dismantling and assembling fuel rail with injectors 65
1.7 Dismantling and assembling air cleaner 68
1.8 Safety precautions 72

1.9 Rules for cleanliness 73
1.10 Technical data 73
2 Checking components 74
2.1 Checking components 74
2.2 Checking Lambda probe heating before catalyst 74
2.3 Checking Lambda probe heating after catalyst 78
2.4 Checking throttle valve control part 81
2.5 Checking intake manifold pressure sender 84
2.6 Checking intake air temperature sender 86
2.7 Checking coolant temperature sender 90
2.8 Checking engine speed sender 94
2.9 Checking injectors 96
2.10 Checking fuel pressure regulator and holding pressure 102
2.11 Checking intake air system for leaks (unmetered air) 106
2.12 Checking intake air preheating 107
2.13 Checking vacuum valve 107
3 Checking functions 109
3.1 Checking functions 109
3.2 Idling check 109
3.3 Checking Lambda probe and Lambda regulation before catalyst 111
3.4 Checking Lambda probe and Lambda regulation after catalyst 116
3.5 Checking ageing of Lambda probe before catalyst 120
3.6 Checking engine operating mode 121
4 Engine control unit 123
4.1 Engine control unit 123
4.2 Checking control unit voltage supply 123
4.3 Procedure after voltage supply open circuit 125
4.4 Replacing engine control unit 125
4.5 Coding engine control unit 126
4.6 Adapting engine control unit to throttle valve control part 127
4.7 Adapting engine control unit to electronic immobilizer 129
5 Checking additional signals 130
5.1 Checking additional signals 130
5.2 Checking speed signal 130
5.3 Checking signal from/to air conditioning system 132
5.4 Checking signal from brake light switch and brake pedal switch 133
5.5 Checking rpm signal 135
5.6 Checking matching resistor of data bus 136

28 - Ignition system 138
1 Servicing ignition system 138
1.1 Servicing ignition system 138
1.2 General notes on ignition system 138
1.3 Removing and installing parts of the ignition system 139
1.4 Safety precautions 142
1.5 Test data, spark plugs 142
1.6 Checking Hall sender 143
1.7 Checking ignition transformer 144
1.8 Checking knock sensor 148
1.9 Check misfiring recognition 150