

Contents

01 - Self-diagnosis	1
1 Air-conditioner self-diagnosis	1
1.1 Air-conditioner self-diagnosis	1
1.2 Function of self-diagnosis	1
1.3 Fault recognition	1
1.4 Safety precautions	2
1.5 Technical self-diagnosis data	2
2 Performing self-diagnosis of manually controlled air conditioner	3
2.1 Performing self-diagnosis of manually controlled air conditioner	3
2.2 Connecting fault reader V.A.G 1551 and selecting functions	3
2.3 Overview of function selection	5
2.4 Interrogating fault memory	6
2.5 Fault table	6
2.6 Performing final control diagnosis	9
2.7 Reading measured value block	11
3 Performing self-diagnosis of fully automatic air conditioner	14
3.1 Performing self-diagnosis of fully automatic air conditioner	14
3.2 Connecting fault reader V.A.G 1551 and selecting functions	14
3.3 Overview of function selection	16
3.4 Interrogating fault memory	17
3.5 Fault table	17
3.6 Performing final control diagnosis	28
3.7 Basic setting	32
3.8 Erasing fault memory, ending output	34
3.9 Coding operating and display unit -E87	35
3.10 Coding table	36
3.11 Reading measured value block	37
4 Air conditioner electrical check	47
4.1 Air conditioner electrical check	47
4.2 Checking wiring of diagnostic sockets	55
80 - Heating	59
1 Servicing heating	59
1.1 Servicing heating	59
1.2 Dash panel vents and air ducts	59
1.3 Heating, heater controls and air ducts	66
2 Removing and installing heater	72
2.1 Removing and installing heater	72
2.2 Rectifying fault: fresh air heated, although temperature controller in "cold stop" position ..	74
3 Dismantling and assembling heater	77
3.1 Dismantling and assembling heater	77
4 Removing and installing dust and pollen filter	86
4.1 Removing and installing dust and pollen filter	86
5 Servicing electrical additional heater - Vehicles with TDI engine 06.94 ä	88
5.1 Servicing electrical additional heater - Vehicles with TDI engine 06.94 ä	88
5.2 Removing and installing heater element for additional heater -Z35	88
5.3 Checking function of electrical additional heater	89
82 - Auxiliary heating	91
1 Servicing auxiliary heater	91
1.1 Servicing auxiliary heater	91
1.2 Safety precautions when working on auxiliary heater	91
1.3 Notes on general repairs to vehicles with auxiliary heaters	91



1.4	Rules for cleanliness	91
1.5	Auxiliary heater components	92
2	Removing and installing auxiliary heater	100
2.1	Removing and installing auxiliary heater	100
2.2	Removing and installing auxiliary heater - Audi S4	102
3	Coolant circuit	103
3.1	Coolant circuit	103
3.2	Incorporation of auxiliary heater into coolant circuit	103
3.3	Removing and installing metering pump -V54	104
4	Fuel system	105
4.1	Fuel system	105
4.2	Auxiliary heater fuel diversion	105
4.3	Checking fuel delivery	106
5	Exhaust system	109
5.1	Exhaust system	109
5.2	Detaching and attaching exhaust system and bracket at auxiliary heater	110
5.3	Detaching and attaching exhaust system and bracket at auxiliary heater - Audi S4	116
5.4	Checking and setting CO ₂ -content of exhaust gas	121
6	Removing and installing auxiliary heater components	122
6.1	Removing and installing auxiliary heater components	122
7	Dismantling and assembling auxiliary heater	133
7.1	Dismantling and assembling auxiliary heater	133
7.2	Function diagrams	137
87 - Air conditioning		147
1	Safety precautions when working on cars with air-conditioners and when handling refrigerant	147
1.1	Safety precautions when working on cars with air-conditioners and when handling refrigerant	147
2	Notes on general repairs	150
2.1	Notes on general repairs	150
3	Servicing of refrigerant circuit	150
3.1	Servicing of refrigerant circuit	150
3.2	Refrigerant circuit with refrigerant R12 > 09.92	151
3.3	Refrigerant circuit with refrigerant R134a 10.92 ä	157
3.4	Complaint of "smell from air conditioner"	166
4	Removing compressor from and attaching it to bracket; removing and installing compressor bracket	168
4.1	Removing compressor from and attaching it to bracket; removing and installing compressor bracket	168
4.2	4-cylinder engine with V-belt	169
4.3	4-cylinder engine with ribbed V-belt	171
4.4	5-cylinder engine	173
4.5	6-cylinder engines	174
4.6	Zexel compressor	175
4.7	Nippondenso compressor	177
4.8	8-cylinder engine	179
5	Servicing magnetic clutch -N25	180
5.1	Servicing magnetic clutch -N25	180
5.2	Zexel compressor	181
5.3	Nippondenso compressor	185
6	Connection diagram for vacuum hoses	189
6.1	Connection diagram for vacuum hoses	189
7	Servicing components of manually controlled air conditioner	192
7.1	Servicing components of manually controlled air conditioner	192

7.2	Checking refrigeration capacity of manually controlled air-conditioner	199
8	Servicing components for control and regulation of fully automatic air-conditioner	202
8.1	Servicing components for control and regulation of fully automatic air-conditioner	202
8.2	Components in engine compartment	203
8.3	Components in passenger compartment	212
8.4	Checking refrigeration capacity of fully automatic air-conditioner	219
9	Servicing of refrigerant circuit	222
9.1	Servicing of refrigerant circuit	222
9.2	Refrigerant R12 > 09.92	222
9.3	Refrigerant R134a 10.92 ä	234
9.4	Removing and installing evaporator	248