

Contents

01 - Self-diagnosis	1
1 Self-diagnosis of Multi Point Injection	1
1.1 Self-diagnosis of Multi Point Injection	1
1.2 Control unit overview	1
1.3 Technical self-diagnosis data	2
1.4 Safety precautions	2
1.5 Connecting vehicle diagnosis, measurement and information system VAS 5051 or fault reader V.A.G 1551 and selecting functions	3
2 Interrogating and erasing fault memory	6
2.1 Interrogating and erasing fault memory	6
2.2 Fault table	7
2.3 Fault codes 01119 - 17509	7
2.4 Fault codes 17514 - 18020	17
3 Final control diagnosis	27
3.1 Final control diagnosis	27
4 Basic setting	29
4.1 Basic setting	29
5 Coding control unit	31
5.1 Coding control unit	31
5.2 Code table for control unit no. 8A0 906 266 C	32
5.3 Code table for control unit no. 8A0 906 266 E, H, J	33
5.4 Code table for control unit no. 8A0 906 266 G	33
6 Reading measured value block	34
6.1 Reading measured value block	34
6.2 Display group overview	35
6.3 Reading measured value block: Display groups 000 to 010	38
6.4 Reading measured value block: Display groups 011 to 099	53
7 Adaptation	59
7.1 Adaptation	59
7.2 CO adjustment on vehicles not fitted with lambda probes	59
8 Checking wiring of diagnostic connector	62
8.1 Checking wiring of diagnostic connector	62
8.2 Checking voltage supply for "black" diagnostic connector	63
8.3 Checking wiring connection between "white" diagnostic connector and engine control unit	63
24 - Mixture preparation, Injection	67
1 Servicing Multi Point Injection system	67
1.1 Servicing Multi Point Injection system	67
1.2 Safety precautions	67
1.3 Rules for cleanliness	67
1.4 Technical data	68
1.5 Fitting locations overview	69
1.6 Dismantling and assembling air cleaner	73
1.7 Dismantling and assembling fuel manifold with injectors	75
1.8 Removing and installing throttle valve unit and intake manifold changeover system components	77
1.9 Checking wiring and components with test box V.A.G 1598	80
1.10 Replacing engine control unit	81
1.11 Checking idling speed and CO content	84
1.12 Checking system pressure, fuel pressure regulator and holding pressure	85
1.13 Checking injectors	88
1.14 Testing injection quantity, leak tightness and spray pattern of injectors	93



1.15	Checking fuel pump relay -J17 and actuation	96
1.16	Checking idling stabilisation valve -N71	101
1.17	Checking air mass meter -G70	105
2	Checking intake manifold changeover function	109
2.1	Checking intake manifold changeover function	109
2.2	Checking function	109
2.3	Checking vacuum system for leaks	110
2.4	Checking intake manifold changeover valve -N156	112
3	Testing lambda control	116
3.1	Testing lambda control	116
3.2	Engine running problems after cold start	117
3.3	Checking function of lambda probes	118
3.4	Checking lambda probe heating	121
3.5	Checking lambda probe and signal wire	124
3.6	Removing and installing lambda probe	125
4	Checking fuel tank breather	126
4.1	Checking fuel tank breather	126
4.2	Checking activated charcoal filter solenoid valve 1 -N80	127
5	Checking throttle valve potentiometer -G69	131
5.1	Checking throttle valve potentiometer -G69	131
5.2	Checking idling switch -F60	135
6	Checking EGR	139
6.1	Checking EGR	139
6.2	Checking EGR valve -N18	139
6.3	Testing mechanical exhaust gas recirculation valve	143
6.4	Checking EGR temperature sensor -G98	145
7	Checking auxiliary signals	148
7.1	Checking auxiliary signals	148
7.2	Checking the air conditioner compressor shutoff	148
7.3	Checking engine speed signal	150
7.4	Checking vehicle speed signal	151
7.5	Checking consumption signal for on-board computer	153
7.6	Checking output signal for throttle valve position	153
7.7	Checking gear signal	155
7.8	Checking ignition timing retardation on changing gear	158
7.9	Checking engine torque signal from ABS/TCS control unit	160
8	Vacuum diagram	161
8.1	Vacuum diagram	161
8.2	Vehicles with manual gearbox without EGR	161
8.3	Vehicles with automatic gearbox without EGR	163
8.4	Vehicles with manual gearbox and EGR	165
8.5	Vehicles with automatic gearbox and EGR	171
28 - Ignition system		176
1	Checking ignition system	176
1.1	Checking ignition system	176
1.2	Safety precautions	176
1.3	Technical data	176
1.4	Removing and installing ignition system components	177
1.5	Checking ignition coils -N, -N128, and -N158	180
1.6	Checking output stage -N122	183
1.7	Checking ignition timing sender -G4	186
1.8	Checking engine speed sender -G28	188
1.9	Checking coolant temperature sender -G62	193
1.10	Checking control unit power supply	196
1.11	Checking knock sensors	199

1.12 Checking Hall sender -G40202