

Contents

01 - Self-diagnosis	1
1 Motronic self-diagnosis	1
1.1 Motronic self-diagnosis	1
1.2 Technical data of self-diagnosis	1
1.3 Safety precautions	1
1.4 Connecting up vehicle diagnostic, testing and information system VAS 5051 and selecting functions	1
2 Interrogating and erasing fault memory	4
2.1 Interrogating and erasing fault memory	4
2.2 Interrogating fault memory	4
2.3 Erasing fault memory	6
2.4 End of output	7
2.5 Fault table	7
2.6 Fault codes 00281 - 00537	8
2.7 Fault codes 00540 - 65535	13
3 Final control diagnosis	19
3.1 Final control diagnosis	19
4 Basic setting	24
4.1 Basic setting	24
5 Encoding control unit	26
5.1 Encoding control unit	26
6 Reading measured value block	28
6.1 Reading measured value block	28
7 Checking wiring of diagnostic connectors	33
7.1 Checking wiring of diagnostic connectors	33
7.2 Checking power supply for "black" diagnostic connector	34
7.3 Checking wiring between "white" diagnostic connector and engine control unit	34
7.4 Checking wiring of encoding connector	38
24 - Mixture preparation, Injection	39
1 Servicing Motronic injection system	39
1.1 Servicing Motronic injection system	39
1.2 Safety precautions	39
1.3 Rules for cleanliness	39
1.4 Technical data	40
1.5 Exploded view of fitting locations	41
1.6 Removing and installing injection system components	45
1.7 Wiring and component check with test box V.A.G 1598 A and adapter 1598/5	48
1.8 Replacing engine control unit	49
1.9 Checking idling speed	51
1.10 Checking system pressure, fuel pressure regulator and holding pressure	53
1.11 Checking injectors	56
1.12 Dismantling and assembling fuel rail with injectors	61
1.13 Removing and installing injectors	63
1.14 Checking injection quantity, freedom from leaks and spray pattern of injectors	66
1.15 Checking fuel pump relay -J17 and actuation	68
1.16 Checking idling-speed stabilisation valve -N71	74
1.17 Checking air-mass meter -G70	78
1.18 Checking intake system for leaks (unmetered air)	81
2 Checking Lambda control	83
2.1 Checking Lambda control	83
2.2 Checking Lambda-probe signal wire and actuation	84
2.3 Checking Lambda probe heating	86

2.4	Removing and installing Lambda probe	92
3	Checking fuel tank breather system	93
3.1	Checking fuel tank breather system	93
3.2	Checking activated charcoal filter solenoid valve -N80	94
4	Checking throttle valve potentiometer -G69	98
4.1	Checking throttle valve potentiometer -G69	98
4.2	Checking idling switch -F60	101
5	Checking additional signals	104
5.1	Checking additional signals	104
5.2	Checking engine-speed signal	105
5.3	Checking consumption signal for on-board computer	105
5.4	Checking signals from/to air conditioner	105
5.5	Checking vehicle-speed signal	107
5.6	Checking gear signal	108
5.7	Checking ignition timing retard on changing gear	108
5.8	Checking output signal for throttle valve position	109
28 - Ignition system	111	
1	Checking ignition system	111
1.1	Checking ignition system	111
1.2	Safety precautions	111
1.3	Technical data	111
1.4	Checking ignition coils with output stages	112
1.5	Ignition cable routing	116
1.6	Checking firing point sender -G4	117
1.7	Checking engine speed sender -G28	119
1.8	Checking intake-air temperature sender -G42	121
1.9	Checking coolant temperature sender -G62	123
1.10	Checking control unit power supply	125
1.11	Checking knock sensors	127
1.12	Checking Hall sender -G40	130