

Contents	
01 - Self-diagnosis	1
1 Self-diagnosis of Multi Point Injection	1
1.1 Self-diagnosis of Multi Point Injection	1
1.2 Control unit overview	1
1.3 Technical self-diagnosis data	2
1.4 Safety precautions	2
1.5 Connecting vehicle diagnosis, measurement and information system VAS 5051 or fault reader V.A.G 1551 and selecting functions	2
2 Interrogating and erasing fault memory	5
2.1 Interrogating and erasing fault memory	5
2.2 Fault table	7
2.3 Fault codes 01119 - 17509	7
2.4 Fault codes 17514 - 18020	17
3 Final control diagnosis	26
3.1 Final control diagnosis	26
4 Basic setting	28
4.1 Basic setting	28
5 Encoding control unit	31
5.1 Encoding control unit	31
5.2 Encoding table for control unit no. 8A0 906 266 C	32
5.3 Encoding table for control unit no. 8A0 906 266 E, H, J	32
6 Reading measured value block	33
6.1 Reading measured value block	33
6.2 Display group overview	34
6.3 Reading measured value block: Display groups 000 to 002	37
6.4 Reading measured value block: Display groups 003 to 010	44
6.5 Reading measured value block: Display groups 011 to 099	52
7 Adaptation	59
7.1 Adaptation	59
7.2 CO adjustment on vehicles not fitted with lambda probes	59
8 Testing wiring connection for diagnostic connector	62
8.1 Testing wiring connection for diagnostic connector	62
8.2 Check power supply for "black" diagnostic connector	63
8.3 Check wiring connection between "white" diagnostic connector and engine control unit	63
24 - Mixture preparation, Injection	67
1 Servicing Multi Point Injection system	67
1.1 Servicing Multi Point Injection system	67
1.2 Safety precautions	67
1.3 Rules for cleanliness	67
1.4 Technical data	68
1.5 Fitting locations overview	69
1.6 Dismantling and assembling fuel manifold with injectors	73
1.7 Removing and installing throttle valve unit and intake manifold changeover system components	75
1.8 Checking wiring and components with test box V.A.G 1598	78
1.9 Renewing engine control unit	79
1.10 Checking idling speed and CO content	82
1.11 Checking system pressure, fuel pressure regulator and holding pressure	83
1.12 Checking injectors	86
1.13 Testing injection quantity, leak tightness and spray pattern of injectors	91
1.14 Testing fuel pump relay -J17 and actuation	94
1.15 Checking idling stabilisation valve -N71	99

1.16	Checking air mass meter -G70	103
2	Checking intake manifold changeover valve	107
2.1	Checking intake manifold changeover valve	107
2.2	Check function	107
2.3	Checking vacuum system for leaks	108
2.4	Checking intake manifold changeover valve -N156	110
3	Test lambda control	114
3.1	Test lambda control	114
3.2	Engine running problems after cold start	115
3.3	Checking function of lambda probes	116
3.4	Checking lambda probe heating	118
3.5	Checking lambda probe and signal wire	121
3.6	Removing and installing lambda probe	122
4	Checking fuel tank breather	123
4.1	Checking fuel tank breather	123
4.2	Checking activated charcoal filter solenoid valve 1 -N80	124
5	Checking throttle valve potentiometer -G69	128
5.1	Checking throttle valve potentiometer -G69	128
5.2	Checking idling switch -F60	132
6	Checking EGR	136
6.1	Checking EGR	136
6.2	Checking EGR valve -N18	136
6.3	Testing mechanical exhaust gas recirculation valve	140
6.4	Checking temperature sensor for EGR -G98	142
7	Checking auxiliary signals	145
7.1	Checking auxiliary signals	145
7.2	Checking heated rear window signal	145
7.3	Checking the air conditioner compressor shutoff	147
7.4	Checking engine speed signal	149
7.5	Checking vehicle speed signal	150
7.6	Checking consumption signal for on-board computer	152
7.7	Checking output signal for throttle valve position	152
7.8	Checking gear signal	154
7.9	Checking change-up/change-down signal	156
7.10	Checking ignition timing retardation on changing gear	157
7.11	Checking engine torque signal from ABS/TCS control unit	159
8	Vacuum diagram	160
8.1	Vacuum diagram	160
8.2	Vehicles with manual gearbox:	160
8.3	Vehicles with automatic gearbox:	163
28 - Ignition system	166	
1	Checking ignition system	166
1.1	Checking ignition system	166
1.2	Safety precautions	166
1.3	Technical data	166
1.4	Removing and installing ignition system components	167
1.5	Checking ignition coils -N, -N128, and -N158	170
1.6	Checking output stage -N122	173
1.7	Checking ignition timing sender -G4	176
1.8	Checking engine speed sender -G28	178
1.9	Checking coolant temperature sender -G62	183
1.10	Checking control unit power supply	186
1.11	Checking knock sensors	189
1.12	Checking Hall sender -G40	192