

Contents

01 - Self-diagnosis	1
1 Self-diagnosis for the Motronic system	1
1.1 Self-diagnosis for the Motronic system	1
1.2 Technical data for the self-diagnosis	1
1.3 Connecting the V.A.G 1551 fault reader and selecting the engine electronics control unit ..	2
1.4 Interrogating and erasing fault memory	3
1.5 Fault table	4
1.6 Final control diagnosis	15
1.7 Basic setting	17
1.8 Encoding the control unit	19
1.9 Reading measured value block	20
1.10 Reading measured value block: Display Groups 00 to 10	26
1.11 Reading measured value block: Display Groups 08 to 99	32
24 - Mixture preparation, Injection	43
1 Repairing the Motronic fuel injection system	43
1.1 Repairing the Motronic fuel injection system	43
1.2 Safety precautions	43
1.3 Rules for cleanliness	43
1.4 Technical data	43
1.5 Overview of fitting locations	45
1.6 Wiring and component check with test box V.A.G 1598/22	47
1.7 Replacing the engine control unit	48
1.8 Checking idling speed	49
1.9 Checking fuel pressure regulator and holding pressure	50
1.10 Checking injection quantity, leak tightness and spray pattern of injectors	52
1.11 Checking the injectors	53
1.12 Checking fuel pump relay and actuation	56
1.13 Checking the air mass meter	59
2 Checking the boost pressure system	61
2.1 Checking the boost pressure system	61
2.2 Checking the boost pressure control	61
2.3 Checking solenoid valve for boost pressure control	61
2.4 Checking altitude sensor	63
3 Checking the lambda control	65
3.1 Checking the lambda control	65
3.2 Poor performance after cold start	66
3.3 Checking operation	67
3.4 Checking lambda probe heating	68
3.5 Checking lambda probe signal line and actuation	69
3.6 Removing and installing the lambda probe	70
4 Checking the fuel tank breather system	71
4.1 Checking the fuel tank breather system	71
4.2 Checking the solenoid valve 1 for the activated carbon canister	71
5 Checking the throttle valve control unit - vehicles without CCS	73
5.1 Checking the throttle valve control unit - vehicles without CCS	73
5.2 Adaptation of the throttle valve control unit without CCS	73
5.3 Checking the idling switch without CCS	75
5.4 Checking the throttle valve potentiometer without CCS	76
5.5 Checking the sensor for throttle valve positioner without CCS	78
5.6 Checking throttle valve positioner without CCS	79
6 Checking the throttle valve control unit - vehicles with CCS	80
6.1 Checking the throttle valve control unit - vehicles with CCS	80



6.2	Adaptation of the throttle valve control unit with CCS	80
6.3	Checking the idling switch with CCS	82
6.4	Checking the throttle valve potentiometer with CCS	83
6.5	Checking the sensor for the throttle valve positioner with CCS	85
6.6	Checking the throttle valve positioner with CCS	86
7	Checking auxiliary signals	87
7.1	Checking auxiliary signals	87
7.2	Checking air conditioner compressor shut-off	87
7.3	Checking the engine speed adaptation by switching on the air conditioner	88
7.4	Checking selector lever position on automatic gearbox	89
7.5	Checking engine speed signal	91
7.6	Checking throttle valve positioner	91
7.7	Checking the speed signal	92
7.8	Checking the gearbox intervention signal when changing gear	93
7.9	Checking clutch pedal switch	94
7.10	Checking the power steering pressure switch	95
7.11	Checking the Motronic system/ABS/gearbox data exchange (CAN bus)	96
28	- Ignition system	98
1	Checking ignition system	98
1.1	Checking ignition system	98
1.2	Safety precautions	98
1.3	Technical data	98
1.4	Checking ignition coils	98
1.5	Checking output stages for ignition coils	101
1.6	Checking the intake air temperature sensor	103
1.7	Checking the engine speed sensor	104
1.8	Checking the sensor for coolant temperature	105
1.9	Checking the power supply for the control unit	106
1.10	Checking the knock sensors	106
1.11	Checking the Hall sensor	108