

## Contents

<b>01 - Self-diagnosis . . . . .</b>	<b>1</b>
<b>1 Self-diagnosis of Motronic system . . . . .</b>	<b>1</b>
1.1 Self-diagnosis of Motronic system . . . . .	1
1.2 Technical data for self-diagnosis . . . . .	1
1.3 Safety precautions . . . . .	1
1.4 Connecting vehicle diagnostic, testing and information system VAS 5051 or fault reader V.A.G 1551 and selecting functions . . . . .	1
<b>2 Interrogating and erasing fault memory . . . . .</b>	<b>4</b>
2.1 Interrogating and erasing fault memory . . . . .	4
2.2 Fault table . . . . .	5
<b>3 Final control diagnosis . . . . .</b>	<b>13</b>
3.1 Final control diagnosis . . . . .	13
<b>4 Basic setting . . . . .</b>	<b>16</b>
4.1 Basic setting . . . . .	16
<b>5 Coding control unit . . . . .</b>	<b>17</b>
5.1 Coding control unit . . . . .	17
5.2 Coding table . . . . .	18
<b>6 Reading measured value block . . . . .</b>	<b>18</b>
6.1 Reading measured value block . . . . .	18
<b>24 - Mixture preparation, Injection . . . . .</b>	<b>20</b>
<b>1 Servicing Motronic injection system . . . . .</b>	<b>20</b>
1.1 Servicing Motronic injection system . . . . .	20
1.2 Safety precautions . . . . .	20
1.3 Rules for cleanliness . . . . .	20
1.4 Technical data . . . . .	21
1.5 Fitting locations overview . . . . .	22
1.6 Dismantling and assembling air cleaner . . . . .	30
1.7 Wiring and component check with test box V.A.G 1598/31 . . . . .	31
1.8 Renewing engine control unit . . . . .	33
1.9 Testing idling speed . . . . .	34
1.10 Checking system pressure, fuel pressure regulator and holding pressure . . . . .	36
1.11 Testing injectors . . . . .	40
1.12 Dismantling and assembling fuel rail with injectors . . . . .	44
1.13 Removing and installing injectors . . . . .	48
1.14 Checking injection quantity, leak-tightness and spray pattern of injectors . . . . .	50
1.15 Testing fuel pump relay -J17 and activation . . . . .	52
1.16 Testing air mass meter -G70 . . . . .	56
1.17 Checking intake air system for leaks (unmetered air) . . . . .	60
<b>2 Testing lambda control . . . . .</b>	<b>62</b>
2.1 Testing lambda control . . . . .	62
2.2 Operation of lambda control . . . . .	62
2.3 Testing lambda probe and lambda control . . . . .	63
2.4 Testing lambda probe heating . . . . .	69
2.5 Removing and installing lambda probe . . . . .	72
<b>3 Testing secondary air system . . . . .</b>	<b>73</b>
3.1 Testing secondary air system . . . . .	73
3.2 Testing secondary air inlet valve -N112 . . . . .	77
3.3 Testing secondary air pump relay -J299 and activation . . . . .	81
<b>4 Testing fuel tank breather . . . . .</b>	<b>86</b>
4.1 Testing fuel tank breather . . . . .	86
4.2 Testing solenoid valve 1 for activated charcoal filter -N80 . . . . .	86

<b>5</b>	<b>Testing electronic engine power control (electronic throttle)</b>	<b>89</b>
5.1	Testing electronic engine power control (electronic throttle)	89
5.2	Operation of electronic throttle system	89
5.3	Notes on EPC warning lamp (fault warning lamp for electronic throttle) in dash panel insert	90
5.4	Testing electronic throttle warning lamp -K132	90
5.5	Testing throttle valve control part -J338	92
5.6	Performing adaption of throttle valve control part	92
5.7	Testing angle senders for throttle valve drive	95
5.8	Testing accelerator position senders	98
<b>6</b>	<b>Vacuum system layout</b>	<b>103</b>
6.1	Vacuum system layout	103
<b>7</b>	<b>Testing auxiliary signals</b>	<b>107</b>
7.1	Testing auxiliary signals	107
7.2	Checking engine speed signal	107
7.3	Testing fuel consumption signal for on-board computer	107
7.4	Testing road speed signal	108
7.5	Testing air conditioner compressor shut-off	110
7.6	Testing brake light switch and brake pedal switch	112
7.7	Testing clutch pedal switch -F36	116
7.8	Testing power steering pressure switch -F88	119
7.9	Testing data exchange between Motronic system and ABS (CAN bus)	122
<b>28</b>	<b>- Ignition system</b>	<b>124</b>
<b>1</b>	<b>Testing ignition system</b>	<b>124</b>
1.1	Testing ignition system	124
1.2	General notes on ignition system	124
1.3	Safety precautions	124
1.4	Technical data	124
1.5	Testing ignition coils with output stages	125
1.6	Testing intake air temperature sender -G42	129
1.7	Testing engine speed sender -G28	132
1.8	Testing coolant temperature sender -G62	134
1.9	Testing voltage supply for control unit	137
1.10	Testing knock sensor control limit	138
1.11	Testing knock sensors	139
1.12	Testing Hall sender -G163	141