

Contents

00 - Technical data	1
1 Technical data	1
1.1 Engine number	1
1.2 Engine data	1
2 General repair instructions	3
2.1 Safety precautions	3
2.2 Rules for cleanliness when working on the injection system	3
2.3 Important: Required procedure prior to opening high-pressure injection system	4
10 - Removing and installing engine	7
1 Removing and installing engine	7
1.1 Removing engine	7
1.2 Separating engine and gearbox	21
1.3 Securing engine to assembly stand	23
1.4 Installing engine	25
2 Adjusting engine mountings	30
2.1 Checking adjustment	30
2.2 Adjusting engine mountings	30
13 - Crankshaft group	34
1 Servicing work on pulley end	34
1.1 Poly V-belt drive - exploded view of components	34
1.2 Removing and installing poly V-belt	35
1.3 Removing and installing crankshaft pulley	37
1.4 Renewing crankshaft oil seal	38
1.5 Timing chain cover - exploded view of components	41
1.6 Removing and installing timing chain cover	43
1.7 Camshaft timing chain - exploded view of components	53
1.8 Checking valve timing	55
1.9 Removing and installing camshaft timing chain	57
2 Servicing work on flywheel end	65
2.1 Flywheel/drive plate and sealing flange - exploded view of components	65
2.2 Removing and installing flywheel	67
2.3 Removing and installing drive plate	67
2.4 Renewing sealing flange - vehicles up to VIN 8P_4_103000	68
2.5 Renewing sealing flange - vehicles from VIN 8P_4_103001 onwards	75
3 Removing and installing crankshaft	83
4 Dismantling and assembling pistons and conrods	84
4.1 Pistons and conrods - exploded view of components	84
4.2 Piston and cylinder dimensions	86
15 - Cylinder head, valve gear	87
1 Removing and installing cylinder head	87
1.1 Cylinder head - exploded view of components	87
1.2 Removing and installing cylinder head	89
1.3 Checking compression	103
2 Servicing valve gear	107
2.1 Camshaft housing - exploded view of components	107
2.2 Removing and installing camshaft housing	108
2.3 Valves - exploded view of components	112
2.4 Renewing valve stem oil seals	114
2.5 Checking valve guides	117



2.6	Checking valves	118
2.7	Valve dimensions	119
2.8	Machining valve seats	119
17	- Lubrication	122
1	Removing and installing parts of lubrication system	122
1.1	Oil pump, sump (bottom section) - exploded view of components	122
1.2	Removing and installing sump	123
1.3	Removing and installing oil pump	129
1.4	Oil filter housing - exploded view of components	131
1.5	Oil cooler - exploded view of components	133
1.6	Removing and installing oil cooler	133
1.7	Checking oil pressure and oil pressure switch	138
1.8	Engine oil	140
1.9	Checking oil level	140
19	- Cooling	142
1	Removing and installing parts of cooling system	142
1.1	Diagram of coolant hose connections	142
1.2	Draining and filling cooling system	144
1.3	Coolant pump - Overview of components	148
1.4	Removing and installing coolant pump	150
1.5	Thermostat housing - exploded view of components	152
1.6	Removing and installing thermostat	154
1.7	Removing and installing thermostat housing and coolant pipe	158
1.8	Radiator and radiator fan - exploded view of components	163
1.9	Removing and installing radiator	164
1.10	Checking cooling system for leaks	167
1.11	Removing and installing radiator fan V7 and radiator fan 2 V177	169
26	- Exhaust system	172
1	Removing and installing parts of exhaust system - vehicles with engine code letters BAG	172
1.1	Exhaust system - exploded view of components	172
1.2	Removing and installing front exhaust pipe with starter catalytic converter	174
1.3	Centre and rear silencers - exploded view of components	177
1.4	Separating centre and rear silencers	178
1.5	Removing and installing exhaust manifold	179
1.6	Stress-free alignment of exhaust system	182
1.7	Checking exhaust system for leaks	183
2	Removing and installing parts of exhaust system - vehicles with engine code letters BLF, BLP	184
2.1	Exhaust system - exploded view of components	184
2.2	Removing and installing front exhaust pipe with starter catalytic converter	186
2.3	Centre and rear silencers - exploded view of components	189
2.4	Separating centre and rear silencers	190
2.5	Removing and installing exhaust manifold	191
2.6	Stress-free alignment of exhaust system	194
2.7	Checking exhaust system for leaks	195
3	Exhaust gas recirculation system	196
3.1	Exhaust gas recirculation system - exploded view of components	196
3.2	Checking adaption of zero position for exhaust gas recirculation valve N18	198
3.3	Removing and installing exhaust gas recirculation valve N18 with exhaust gas recirculation potentiometer G212	199