

Contents

01 - Self-diagnosis	1
1 Self-diagnosis	1
1.1 Self-diagnosis	1
1.2 Technical data for self-diagnosis	1
1.3 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit	2
1.4 Interrogating and erasing fault memory	4
1.5 Fault table	4
1.6 Actuator diagnosis	13
1.7 Basic setting	15
1.8 Encoding control unit	17
1.9 Reading measured value block	18
1.10 Specified display values	24
24 - Mixture preparation, Injection	32
1 Repairing the Motronic fuel injection system	32
1.1 Repairing the Motronic fuel injection system	32
1.2 Safety precautions	32
1.3 Cleanliness rules	32
1.4 Technical data	32
1.5 Installation locations overview	33
1.6 Wiring and component check with test box V.A.G 1598/22	35
1.7 Replacing engine control unit	35
1.8 Testing idling speed	36
1.9 Testing fuel pressure regulator and holding pressure	38
1.10 Testing injection quantity, leak tightness and spray pattern of injectors	40
1.11 Removing and installing injectors	42
1.12 Testing injectors	43
1.13 Testing fuel pump relay	46
2 Testing the boost pressure system	49
2.1 Testing the boost pressure system	49
2.2 Testing the boost pressure control	49
2.3 Testing the solenoid valve for boost pressure control	50
2.4 Testing the altitude sensor	52
3 Test lambda control	54
3.1 Test lambda control	54
3.2 Poor performance after cold start	54
3.3 Testing operation	55
3.4 Check lambda probe heating	57
3.5 Testing lambda probe signal wiring and activation	58
3.6 Removing and installing lambda probe	59
4 Testing fuel tank breather system	60
4.1 Testing fuel tank breather system	60
4.2 Checking function	60
4.3 Testing solenoid valve 1 for active carbon canister	60
5 Testing throttle valve control unit	62
5.1 Testing throttle valve control unit	62
5.2 Adaptation of the throttle valve control unit to the engine control unit	62
5.3 Testing idling switch	63
5.4 Testing throttle valve potentiometer	64
5.5 Testing throttle valve actuator sensor	66
5.6 Testing throttle valve actuator	67
6 Testing control unit input values	68
6.1 Testing control unit input values	68



6.2	Testing control unit voltage supply	68
6.3	Testing engine speed sensor	69
6.4	Testing coolant temperature sensor	70
6.5	Checking the intake air temperature sensor	71
6.6	Testing airflow meter	72
7	Testing auxiliary signals	74
7.1	Testing auxiliary signals	74
7.2	Testing signals from/to automatic gearbox	74
7.3	Testing signals from/to air conditioning system	76
7.4	Testing engine speed signal	77
7.5	Testing road speed signal	77
28	Ignition system	79
1	Testing ignition system	79
1.1	Testing ignition system	79
1.2	Safety precautions	79
1.3	Technical data	79
1.4	Testing ignition coils	79
1.5	Testing power output stages for ignition coils	82
2	Testing knock control	83
2.1	Testing knock control	83
2.2	Testing knock sensors	83
2.3	Testing Hall sensor	85