

Contents

01 - Self-diagnosis	1
1 Self-diagnosis for the Motronic system	1
1.1 Self-diagnosis for the Motronic system	1
1.2 Technical self-diagnosis data	1
1.3 Significance of the warning lamp for self-diagnosis (exhaust gas warning lamp); For vehicles which conform to emission standard EU III	1
1.4 Connecting vehicle diagnostic, testing and information system VAS 5051 or fault reader V.A.G 1551 and selecting functions	3
2 Interrogating and erasing fault memory	6
2.1 Interrogating and erasing fault memory	6
2.2 Fault table	7
2.3 Fault codes up to fault code P1330 (17738)	8
2.4 Fault codes up to fault code P1854 (18262)	17
3 Final control diagnosis	26
3.1 Final control diagnosis	26
4 Basic setting	30
4.1 Basic setting	30
5 Encoding control unit	32
5.1 Encoding control unit	32
6 Reading measured value block	34
6.1 Reading measured value block	34
7 Readiness code	35
7.1 Readiness code	35
7.2 Reading the readiness code	35
7.3 Producing the readiness code	37
24 - Mixture preparation, Injection	48
1 Servicing Motronic injection system	48
1.1 Servicing Motronic injection system	48
1.2 Safety precautions	48
1.3 Rules for cleanliness	48
1.4 Technical data	49
1.5 Fitting locations overview	49
1.6 Removing and installing intake manifold	59
1.7 Wiring and component check with test box V.A.G 1598/31	64
1.8 Procedure following interruption of voltage supply	67
1.9 Renewing engine control unit	68
1.10 Checking idling speed	70
1.11 Checking fuel pressure regulator and holding pressure	71
1.12 Checking injectors	73
1.13 Testing injection quantity, leak tightness and spray pattern of injectors	76
1.14 Dismantling and assembling fuel manifold with injectors	82
1.15 Test fuel pump relay and activation	84
1.16 Testing air mass meter	86
1.17 Checking intake air system for leaks (unmetered air)	91
2 Checking lambda control	92
2.1 Checking lambda control	92
2.2 Function of lambda control	92
2.3 Checking lambda probe and lambda control before catalytic converter	93
2.4 Checking ageing of lambda probes before catalytic converter (on vehicles which conform to emission standard EU III)	97
2.5 Checking lambda probe and lambda control after catalytic converter (on vehicles which conform to emission standard EU III)	100

2.6	Checking lambda probe heating	106
2.7	Testing lambda probe signal wiring and activation	109
2.8	Removing and installing lambda probes	114
3	Checking fuel tank breather	115
3.1	Checking fuel tank breather	115
3.2	Testing solenoid valve 1 for activated charcoal filter	115
4	Checking electronic engine power control (electronic throttle)	118
4.1	Checking electronic engine power control (electronic throttle)	118
4.2	Function of the electronic throttle system	118
4.3	Significance of the EPC warning lamp (fault warning lamp for electronic throttle) in instrument cluster	119
4.4	Checking throttle valve control part	120
4.5	Performing adaption of throttle valve control part	121
4.6	Checking angle sender for throttle valve actuator	123
4.7	Checking accelerator position sender	125
4.8	Learning kickdown function	128
5	Vacuum diagram	130
5.1	Vacuum diagram	130
5.2	Air duct, general	130
5.3	Subsystem, boost pressure control	132
5.4	Subsystem, fuel tank breather (ACF-system)	133
5.5	Subsystem air recirculation control (air recirculation thrust control)	134
5.6	Subsystem, crankcase breather	135
6	Checking auxiliary signals	136
6.1	Checking auxiliary signals	136
6.2	Checking engine speed signal	136
6.3	Checking consumption signal for vehicle computer	137
6.4	Checking coolant temperature sender	137
6.5	Check vehicle speed signal	138
6.6	Checking fuel level signal wiring	138
6.7	Checking brake light switch and brake pedal switch	139
6.8	Checking clutch pedal switch -F36	141
6.9	Testing crash signal	142
6.10	Testing rough road detection signal from ABS/EDS control unit	143
6.11	Testing data exchange between engine/ABS/gearbox control unit, instrument cluster	144
28	- Ignition system	148
1	Checking ignition system	148
1.1	Checking ignition system	148
1.2	General notes on ignition system	148
1.3	Safety precautions	148
1.4	Technical data for ignition system	148
1.5	Checking ignition coils	149
1.6	Checking output stages for ignition coils	151
1.7	Checking the intake air temperature sender	153
1.8	Testing engine speed sender	155
1.9	Test coolant temperature sensor	157
1.10	Checking control unit power supply	160
1.11	Checking knock control stop	160
1.12	Checking knock sensors	163
1.13	Checking Hall sender	166
1.14	Testing misfire detection	169