

## Contents

<b>01 - Self diagnosis</b> .....	<b>1</b>
<b>1 Self-diagnosis of Motronic system</b> .....	<b>1</b>
1.1 Self-diagnosis of Motronic system .....	1
1.2 Technical data of self-diagnosis .....	1
1.3 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit .....	2
<b>2 Interrogating and erasing fault memory</b> .....	<b>4</b>
2.1 Interrogating and erasing fault memory .....	4
2.2 Fault table .....	4
2.3 Fault codes 00282 - 16507 .....	5
2.4 Fault codes 16514 - 18259 .....	15
<b>3 Final control diagnosis</b> .....	<b>27</b>
3.1 Final control diagnosis .....	27
<b>4 Basic setting</b> .....	<b>30</b>
4.1 Basic setting .....	30
<b>5 Coding control unit</b> .....	<b>32</b>
5.1 Coding control unit .....	32
<b>6 Reading measured value block</b> .....	<b>33</b>
6.1 Reading measured value block .....	33
6.2 Reading measured value block: Display Groups 001 to 010 .....	38
6.3 Read measured value block: Display Groups 011 to 099 .....	48
<b>24 - Mixture preparation, Injection</b> .....	<b>57</b>
<b>1 Servicing Motronic injection system</b> .....	<b>57</b>
1.1 Servicing Motronic injection system .....	57
1.2 Safety precautions .....	57
1.3 Rules for cleanliness .....	57
1.4 Technical data .....	58
1.5 Fitting locations overview .....	59
1.6 Removing and installing parts of the injection system .....	63
1.7 Dismantling and assembling air cleaner .....	69
1.8 Dismantling and assembling fuel rail with injectors .....	70
1.9 Removing and installing parts of intake manifold change-over .....	71
1.10 Removing and installing throttle valve control part .....	73
1.11 Vacuum connections .....	75
1.12 Wiring and component check with test box V.A.G 1598/22 .....	77
1.13 Renewing engine control unit .....	78
1.14 Testing idling speed .....	79
1.15 Checking system pressure, fuel pressure regulator and holding pressure .....	80
1.16 Checking injectors .....	82
1.17 Testing injection quantity, leak-tightness and spray pattern of injectors .....	85
1.18 Testing fuel pump relay and activation .....	87
1.19 Checking air mass meter .....	90
<b>2 Testing intake manifold change-over function</b> .....	<b>92</b>
2.1 Testing intake manifold change-over function .....	92
2.2 Testing operation .....	92
2.3 Testing vacuum system for leaks .....	93
2.4 Testing intake manifold change-over valve .....	94
<b>3 Testing lambda control</b> .....	<b>97</b>
3.1 Testing lambda control .....	97
3.2 Poor performance after cold start .....	97
3.3 Testing operation of lambda probes .....	98
3.4 Checking Lambda probe heating .....	100
3.5 Testing lambda probe signal wiring and activation .....	101



3.6	Removing and installing lambda probe . . . . .	102
<b>4</b>	<b>Testing secondary air system . . . . .</b>	<b>103</b>
4.1	Testing secondary air system . . . . .	103
4.2	Testing secondary air inlet valve . . . . .	103
4.3	Testing secondary air pump replay . . . . .	104
<b>5</b>	<b>Testing fuel tank breather system . . . . .</b>	<b>105</b>
5.1	Testing fuel tank breather system . . . . .	105
5.2	Testing operation . . . . .	105
5.3	Testing solenoid valve 1 for activated charcoal filter . . . . .	105
<b>6</b>	<b>Testing throttle valve control part . . . . .</b>	<b>108</b>
6.1	Testing throttle valve control part . . . . .	108
6.2	Testing learning requirement . . . . .	108
6.3	Performing adaption of throttle valve control part . . . . .	109
6.4	Testing idling speed switch . . . . .	110
6.5	Testing throttle valve potentiometer . . . . .	111
6.6	Testing throttle valve positioner sender . . . . .	112
6.7	Testing throttle valve positioner . . . . .	113
<b>7</b>	<b>Testing auxiliary signals . . . . .</b>	<b>114</b>
7.1	Testing auxiliary signals . . . . .	114
7.2	Testing air conditioner compressor shut-off . . . . .	114
7.3	Checking engine speed signal . . . . .	116
7.4	Testing speed signal . . . . .	116
7.5	Testing fuel consumption signal for on-board computer . . . . .	117
7.6	Testing output signal for throttle valve position . . . . .	118
7.7	Testing signal for actual engine torque . . . . .	119
7.8	Testing signal for specified engine torque from ABS/ASR control unit . . . . .	119
7.9	Testing gear selection signal . . . . .	119
7.10	Checking ignition retardation during gear selection . . . . .	121
7.11	Testing change-up and change-down signals . . . . .	122
7.12	Testing CAN bus . . . . .	122
<b>28</b>	<b>- Ignition system . . . . .</b>	<b>124</b>
<b>1</b>	<b>Testing ignition system . . . . .</b>	<b>124</b>
1.1	Testing ignition system . . . . .	124
1.2	Safety precautions . . . . .	124
1.3	Removing and installing parts of the ignition system . . . . .	125
1.4	Technical data . . . . .	128
1.5	Testing ignition coils . . . . .	128
1.6	Checking intake air temperature sender . . . . .	131
1.7	Checking engine speed sender . . . . .	133
1.8	Testing coolant temperature sender . . . . .	136
1.9	Checking control unit voltage supply . . . . .	138
1.10	Testing knock sensors . . . . .	140
1.11	Checking Hall sender . . . . .	142
<b>2</b>	<b>Testing camshaft timing control . . . . .</b>	<b>146</b>
2.1	Testing camshaft timing control . . . . .	146
2.2	Testing operation of camshaft timing control . . . . .	146
2.3	Testing solenoid valves for camshaft adjustment . . . . .	147