

## Contents

<b>01 - Self-diagnosis, electrical checks</b> .....	<b>1</b>
<b>1 Air conditioner self-diagnosis</b> .....	<b>1</b>
1.1 Technical data of self-diagnosis .....	1
1.2 Function .....	2
1.3 Fault recognition .....	2
1.4 Safety precautions .....	4
<b>2 Self-diagnosis procedure</b> .....	<b>5</b>
2.1 Connecting up vehicle diagnostic, testing and information system VAS 5051A and selecting functions .....	5
<b>3 Interrogating fault memory</b> .....	<b>11</b>
3.1 Fault table .....	13
3.2 Fault table (up to fault code "00975") .....	14
3.3 Fault table as of fault code "01044" .....	34
<b>4 Final control diagnosis</b> .....	<b>56</b>
4.1 Starting final control diagnosis .....	56
4.2 Control elements actuated .....	57
<b>5 Basic setting</b> .....	<b>68</b>
<b>6 Erasing fault memory, end of output</b> .....	<b>71</b>
6.1 Erasing fault memory .....	71
6.2 End of output .....	71
<b>7 Encoding operating and display unit, Climatronic control unit J255</b> .....	<b>73</b>
7.1 Encoding control unit .....	73
7.2 Encoding table .....	75
<b>8 Reading measured value block</b> .....	<b>77</b>
8.1 List of available measured value blocks (display groups) .....	78
8.2 Measured value blocks from display group "001" to display group "010" .....	84
8.3 Measured value blocks from display group "011" to display group "020" .....	102
8.4 Measured value blocks as of display group "020" .....	125
8.5 Display groups not used at present for service purposes .....	140
<b>9 Adaption of operating and display unit, Climatronic control unit J255</b> .....	<b>142</b>
9.1 List of adaption channels .....	142
9.2 Adaption procedure in the various adaption channels (except adaption channels "08" and "81") .....	150
9.3 Adaption procedure for reducing fresh air blower speed (adaption channel 08) .....	153
9.4 Chassis number adaption procedure (adaption channel "81") .....	157
<b>10 Checking convenience data bus system</b> .....	<b>160</b>
10.1 Function of data bus systems .....	160
10.2 Checking convenience data bus system .....	162
<b>11 Electrical checks on air conditioner</b> .....	<b>167</b>
11.1 Wiring and component check using test box V.A.G 1598A .....	167
11.2 Test steps "1" to "4" .....	170
11.3 Test steps "5" to "9" .....	180
<b>12 Electrical checks on components actuated by operating and display unit, Climatronic control unit J255</b> .....	<b>192</b>
12.1 Checking of heated rear window Z1 .....	192
12.2 Checking heated seats .....	196
12.3 Checking electric supplementary heater .....	201
12.4 Checking actuation of heated windscreen Z2 .....	203
<b>13 Heated windscreen</b> .....	<b>205</b>
13.1 Operation of heated windscreen Z2 .....	206
13.2 Deactivating heated windscreen .....	207



<b>14</b>	<b>Electrical checking of solar roof</b> .....	<b>208</b>
14.1	Checking operation of solar roof .....	208
<b>15</b>	<b>Mode of operation of air quality sensor G238</b> .....	<b>210</b>
15.1	Checking air quality sensor G238 .....	211
<b>87</b>	<b>- Air conditioning system</b> .....	<b>216</b>
<b>1</b>	<b>Safety measures when working on vehicles with air conditioner and for handling refrigerant</b> .....	<b>216</b>
1.1	Safety measures .....	216
1.2	Draining refrigerant circuit .....	216
1.3	Working on refrigerant circuit .....	217
1.4	Painting work on vehicles with air conditioner .....	218
<b>2</b>	<b>Notes on general repairs</b> .....	<b>219</b>
2.1	Note on vehicles with auxiliary heater (poor heat output) .....	220
<b>3</b>	<b>Servicing work on refrigerant circuit</b> .....	<b>222</b>
3.1	Exploded view of components .....	222
3.2	Removing and installing high-pressure sender G65 .....	224
3.3	O-rings for refrigerant circuit .....	224
<b>4</b>	<b>Detaching compressor from holder/attaching</b> .....	<b>225</b>
4.1	Vehicles with 4 or 6-cyl. engine (belt-driven compressor) .....	225
4.2	Vehicles with 8-cyl. engine (shaft-driven compressor) .....	227
<b>5</b>	<b>Replacing pulley/compressor drive unit</b> .....	<b>228</b>
5.1	Replacing pulley (compressor version "1") .....	228
5.2	Detaching pulley from compressor/re-attaching (compressor version "1") .....	229
5.3	Replacing pulley (compressor version "2") .....	230
5.4	Detaching pulley from compressor/re-attaching (version "2") .....	232
5.5	Checking/replacing compressor drive unit .....	234
5.6	Unfastening and tightening compressor drive shaft .....	236
5.7	Removing and installing compressor drive shaft .....	237
5.8	Detaching drive plate with overload safeguard/attaching .....	237
5.9	Checking concentricity of drive plate with overload safeguard/adjusting .....	238
5.10	Unscrewing drive plate from compressor/screwing on .....	238
5.11	Removing and installing drive plate with rolling bearing .....	239
<b>6</b>	<b>Components for control and regulation of air conditioner</b> .....	<b>240</b>
6.1	Components in engine compartment and at rear end .....	240
6.2	Removing and installing dust and pollen filter .....	243
6.3	Dust and pollen filter with activated charcoal filter element .....	243
6.4	Removing and installing air quality sensor G238 .....	245
6.5	Checking vent frame .....	246
6.6	Components located in passenger compartment .....	246
6.7	Cleaning evaporator of air conditioner with ultrasonic air conditioner cleaning unit VAS 6189 .....	251
6.8	Removing and installing operating and display unit, Climatronic control unit J255 .....	254
6.9	Removing and installing air duct connection for glove box cooling .....	259
6.10	Removing and installing fresh air blower control unit J126 and fresh air blower V2 .....	259
6.11	Removing and installing left vent temperature sender G150 .....	260
6.12	Removing and installing right vent temperature sender G151 .....	260
6.13	Removing and installing evaporator outflow temperature sender G263 .....	261
6.14	Removing and installing left footwell vent temperature sender G261 .....	261
6.15	Removing and installing right footwell vent temperature sender G262 .....	261
6.16	Removing and installing sunlight penetration photosensor G107 .....	262
6.17	Removing and installing condensate drain .....	263
6.18	Checking condensate drain .....	263
6.19	Preparing adapter cables for control motor actuation .....	264
6.20	Removing and installing defroster flap control motor V107 .....	265

6.21	Removing and installing right temperature flap control motor V159	265
6.22	Removing and installing left temperature flap control motor V158	266
6.23	Removing and installing central flap control motor V70	267
6.24	Removing and installing air recirculation flap control motor V113	268
6.25	Removing and installing air flow flap control motor V71	269
6.26	Removing and installing fresh-air intake duct temperature sensor G89	270
6.27	Removing and installing auxiliary heater element Z35	272
<b>7</b>	<b>Dash panel vents and air ducts</b>	<b>274</b>
7.1	Air routing in vehicle	274
7.2	Air routing in air conditioner unit	276
7.3	Connecting element between temperature flaps "1" and "2"	278
7.4	Removing and installing intermediate piece for windscreen defroster vent	278
7.5	Removing and installing front footwell vent	279
<b>8</b>	<b>Removing and installing heating system heat exchanger</b>	<b>281</b>
8.1	Removing heat exchanger	281
8.2	Installing heat exchanger	282
<b>9</b>	<b>Checking cooling output of air conditioner</b>	<b>285</b>
9.1	Special tools, testers and other items required	285
9.2	Checking	286
9.3	Measures to be taken if readout does not match specification	291
9.4	Measures to be taken in the event of temperature increase downstream of evaporator	293
<b>10</b>	<b>Servicing refrigerant circuit</b>	<b>295</b>
10.1	Servicing refrigerant circuit	295
10.2	Refrigerant pipe connections at components (different versions)	298
10.3	Detaching refrigerant pipes at evaporator connection/attaching	299
10.4	Detaching refrigerant pipes from condenser/re-attaching	299
10.5	Removing and installing condenser	300
10.6	Removing and installing restrictor	301
10.7	Removing and installing reservoir	302
10.8	Capacities	305
<b>11</b>	<b>Removing and installing compressor</b>	<b>306</b>
11.1	Detaching refrigerant pipes at compressor/attaching	306
11.2	Removing and installing compressor (vehicles with 4 or 6-cyl. engine)	307
11.3	Removing and installing compressor (vehicles with 8-cyl. engine)	308
11.4	Starting up air conditioner after installing compressor	318
<b>12</b>	<b>Removing and installing air conditioner unit</b>	<b>320</b>
12.1	Special tools, testers and other items required	320
12.2	Removing	320
12.3	Installing	323
<b>13</b>	<b>Dismantling and assembling air conditioner unit</b>	<b>325</b>
13.1	Detaching electrical add-on components from air conditioner unit/re-attaching	325
13.2	Detaching heater elements and air ducts from air conditioner unit/attaching	327
13.3	Dismantling and assembling air conditioner unit	328
13.4	Removing and installing evaporator	328