

Contents

44 - Wheels, tyres, vehicle geometry	1
1 Wheel/Tyre Guide - general information	1
2 How to use the Wheel/Tyre Guide	2
2.1 Overview	2
2.2 General notes	2
2.3 Notes	3
2.4 Explanations on world regions	3
2.5 Definition of tyre package	4
2.6 Determining correct tyre package via version code	5
2.7 NEDC, WLTP and RDE	6
3 Legal and technical requirements (documents)	8
3.1 Legal requirements	8
3.2 Technical requirements	8
3.3 Load capacity depending on speed and winter tyres	9
3.4 Registration documents since 1 October 2005	10
3.5 COC document (EC certificate of conformity)	11
3.6 EC type approval number, sales type and trade name	11
4 Wheel change	12
4.1 Fitting instructions	12
4.2 Corrosion protection for wheel centring seat	15
4.3 Fitting wheels	16
4.4 Position of anti-theft wheel bolts - steel wheels	18
5 Tyre assembly	19
5.1 Assembly overview - alloy wheel	19
5.2 Assembly overview - run-flat wheels with Audi PAX tyres	19
5.3 Pressing tyre off	19
5.4 Removing tyre sealant	20
5.5 Removing tyre	20
5.6 Bringing tyre up to assembly temperature	23
5.7 Fitting tyre	25
5.8 Match-mounting rim and tyre	30
5.9 Checking radial and lateral runout on wheel/tyre	31
5.10 Match-mounting wheel and tyre	34
5.11 Vibration control system VAS 6230 A	35
5.12 Balancing wheel	35
6 Tyre Pressure Monitoring System	41
6.1 System description - Tyre Pressure Monitoring System	41
6.2 Assembly overview - tyre pressure sensor	43
6.3 Removing and installing tyre pressure sensor	49
6.4 Removing and installing metal valve	53
7 Wheel bolts	55
7.1 Tightening wheel bolts correctly	55
7.2 Tightening torques for wheel bolts	56
7.3 Wheel bolts - versions	58
7.4 Anti-theft wheel bolt	59
7.5 Adapter sets for anti-theft wheel bolts	59
8 Information on tyres	62
8.1 Tyre requirements and tyre maintenance	62
8.2 Tyre markings	66
8.3 Markings on tyre sidewall - Audi PAX tyres	73
8.4 EU tyre label	73
8.5 Construction - belted radial tyre	78



8.6	Construction and markings - SST tyre, run-flat tyre	79
8.7	Construction - run-flat tyre with Seal Inside technology	80
8.8	Self supporting tyres (SST) with run-flat capability	82
8.9	Storing tyres	84
8.10	Tyre ageing	84
9	Tyre sealant	86
9.1	Disposal of sealant	86
10	Information on wheel rims	87
10.1	Construction - wheel rim	87
10.2	Identification	88
10.3	Composite wheels	89
10.4	Alloy wheels - care and maintenance	89
10.5	Alloy wheels - repairing	90
10.6	Removing and installing hub cover - alloy wheels with open threaded connection	90
10.7	Renewing trim elements	91
10.8	Removing and installing valve	98
11	Problems with handling and driving characteristics	101
11.1	Tyre noise	101
11.2	Vehicle pulls to one side	103
11.3	Rough running and vibration	108
11.4	Flat spots caused by storage and handling	110
12	Evaluating tyres/tyre damage	112
12.1	Flat spots caused by storage and handling	112
12.2	Undulations	112
12.3	Saw-tooth wear	113
12.4	Flat spots caused by hard braking	114
12.5	Swellings in tyre sidewall	115
12.6	Cuts	116
12.7	Damage caused by foreign objects	116
12.8	Torn tread	117
12.9	Tyre damage due to insufficient inflation pressure	117
12.10	Checking tyres	117
12.11	Damage occurring when fitting tyres	119
13	Tyre wear	120
13.1	Factors influencing tyre service life	120
13.2	Saw-tooth wear	121
13.3	Wear of high-speed tyres	121
13.4	Measuring tread depth	122
13.5	One-sided wear	122
13.6	Outer shoulder wear	125
13.7	Diagonal erosion	126
13.8	Wear in middle of tyre	126
13.9	Permissible differences in tread depth	127
14	Assembly overviews	128
14.1	Assembly overview - alloy wheel	128
14.2	Assembly overview - run-flat wheels with Audi PAX tyres	130
15	Snow chains	133
15.1	Fitting and using snow chains	133
16	Standard/temporary spare wheels and recommended temporary spare tyres	134
16.1	Notes on using temporary spare wheels	134
16.2	Spare wheel with warning sticker	135
16.3	Retrofitting standard/temporary spare wheel	135