

Contents

01 - Self-diagnosis	1
1 Self-diagnosis of multi point fuel injection system	1
1.1 Self-diagnosis of multi point fuel injection system	1
1.2 Control unit overview	1
1.3 Technical self-diagnosis data	1
1.4 Safety precautions	1
1.5 Connecting vehicle diagnosis, measurement and information system VAS 5051 or fault reader V.A.G 1551 and selecting functions	1
2 Interrogating and erasing fault memory.	4
2.1 Interrogating and erasing fault memory.	4
2.2 Fault table	6
3 Final control diagnosis	15
3.1 Final control diagnosis	15
4 Basic setting	17
4.1 Basic setting	17
5 Coding control unit	20
5.1 Coding control unit	20
5.2 Table of codes for control unit nos. up to index "C":	21
5.3 Table of codes for control unit nos. up to index "D":	22
6 Reading measured value block	22
6.1 Reading measured value block	22
6.2 Display group overview	23
7 Adaptation	31
7.1 Adaptation	31
8 Testing diagnostic connector wiring connections	35
8.1 Testing diagnostic connector wiring connections	35
8.2 Checking voltage supply to "black" diagnostic connector:	36
8.3 Checking wiring connection between "white" diagnostic connector and engine control unit	36
24 - Mixture preparation, Injection	40
1 Servicing multi point fuel injection system	40
1.1 Servicing multi point fuel injection system	40
1.2 Safety precautions	40
1.3 Rules for cleanliness	40
1.4 Technical data	41
1.5 Fitting locations overview	42
1.6 Checking wiring and components with test box V.A.G 1598 A	47
1.7 Replacing engine control unit	48
1.8 Checking idling speed	51
1.9 Checking system pressure, fuel pressure regulator and holding pressure	53
1.10 Checking injectors	56
1.11 Removing and installing fuel rail with injectors and throttle valve unit	61
1.12 Removing and installing injectors	63
1.13 Testing injection quantity, leak tightness and spray pattern of injectors	65
1.14 Testing fuel pump relay -J17 and actuation	68
1.15 Checking idling stabilisation valve -N71	73
1.16 Checking intake air system for leaks (unmetered air)	76
2 Test lambda control	77
2.1 Test lambda control	77
2.2 Testing Lambda probe heater-vehicles > 06.96:	78
2.3 Testing Lambda probe heater-vehicles 07.96 ä	84
2.4 Checking Lambda probe and signal wire	87

2.5	Checking function of Lambda probes	89
2.6	Removing and installing Lambda probe	90
3	Checking fuel tank breather	91
3.1	Checking fuel tank breather	91
3.2	Checking activated charcoal filter solenoid valve 1 -N80	91
4	Checking throttle valve potentiometer -G69	97
4.1	Checking throttle valve potentiometer -G69	97
4.2	Checking idling switch -F60	100
5	Checking auxiliary signals	104
5.1	Checking auxiliary signals	104
5.2	Testing air conditioner compressor signal and air conditioner compressor shut-off	104
5.3	Checking engine speed signal	107
5.4	Checking consumption signal for on-board computer	107
5.5	Checking vehicle speed signal	108
5.6	Checking output signal for throttle valve position	110
5.7	Checking gear signal	112
5.8	Checking ignition timing retardation on changing gear	115
6	Vacuum diagram	117
6.1	Vacuum diagram	117
6.2	Vehicles with manual gearbox:	117
6.3	Vehicles with automatic gearbox:	119
28 - Ignition system	121	
1	Checking ignition system	121
1.1	Checking ignition system	121
1.2	Safety precautions	121
1.3	Technical data	121
1.4	Removing and installing ignition system components	122
1.5	Checking ignition coils -N, -N128, and -N158	125
1.6	Checking output stage -N122	128
1.7	Checking ignition timing sensor -G4	131
1.8	Checking engine speed sensor -G28	133
1.9	Checking intake air temperature sensor -G42	138
1.10	Checking coolant temperature sensor -G62	142
1.11	Checking control unit power supply	145
1.12	Checking knock sensors	148
1.13	Checking Hall sensor -G40	151