

Contents

01 - Self-diagnosis	1
1 Self-diagnosis of Motronic system	1
1.1 Self-diagnosis of Motronic system	1
1.2 Technical data for self-diagnosis	1
1.3 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit	2
2 Interrogating and erasing fault memory	3
2.1 Interrogating and erasing fault memory	3
2.2 Fault table	4
3 Final control diagnosis	15
3.1 Final control diagnosis	15
4 Basic setting	17
4.1 Basic setting	17
5 Coding control unit	19
5.1 Coding control unit	19
6 Reading measured value block	21
6.1 Reading measured value block	21
6.2 Readout specifications	27
24 - Mixture preparation, Injection	38
1 Servicing Motronic injection system	38
1.1 Servicing Motronic injection system	38
1.2 Safety precautions	38
1.3 Rules for cleanliness	38
1.4 Technical data	39
1.5 Fitting locations overview	39
1.6 Dismantling and assembling fuel manifold with injectors	41
1.7 Removing and installing parts of intake manifold change-over	42
1.8 Removing and installing throttle valve control part	44
1.9 Wiring and component check with test box V.A.G 1598/22	46
1.10 Renewing engine control unit	47
1.11 Testing idling speed	48
1.12 Checking fuel pressure regulator and holding pressure	49
1.13 Testing injection quantity, leak-tightness and spray pattern of injectors	50
1.14 Removing and installing injectors	52
1.15 Checking injectors	53
1.16 Testing fuel pump relay	56
1.17 Testing air mass meter	59
2 Testing lambda control	60
2.1 Testing lambda control	60
2.2 Poor performance after cold start	61
2.3 Testing operation	62
2.4 Checking Lambda probe heating	64
2.5 Testing lambda probe signal wiring and activation	65
2.6 Removing and installing lambda probe	66
3 Testing intake manifold change-over function	67
3.1 Testing intake manifold change-over function	67
3.2 Testing operation	67
3.3 Testing intake manifold change-over valve -N156	67
3.4 Testing vacuum system for leaks	70
4 Testing fuel tank breather system	71
4.1 Testing fuel tank breather system	71
4.2 Testing operation	71

4.3	Testing solenoid valve 1 for activated charcoal filter	71
5	Testing throttle valve control part	74
5.1	Testing throttle valve control part	74
5.2	Performing adaption of throttle valve control part to engine control unit	75
5.3	Testing idling speed switch	76
5.4	Testing throttle valve potentiometer	77
5.5	Testing throttle valve positioner sender	79
5.6	Testing throttle valve positioner	80
6	Testing auxiliary signals	81
6.1	Testing auxiliary signals	81
6.2	Testing air conditioner compressor shut-off	81
6.3	Testing engine speed adaption when air conditioner cuts in	83
6.4	Checking selector lever position on automatic gearbox	84
6.5	Testing engine speed signal	85
6.6	Testing throttle valve position	86
6.7	Checking speed signal	86
6.8	Checking gearbox intervention signal when a gear is changed	87
28	- Ignition system	89
1	Testing ignition system	89
1.1	Testing ignition system	89
1.2	Safety precautions	89
1.3	Technical data	89
1.4	Testing ignition coils	90
1.5	Testing output stages for ignition coils	91
1.6	Testing intake air temperature sender	93
1.7	Testing engine speed sender	94
1.8	Testing coolant temperature sender	95
1.9	Checking control unit voltage supply	96
1.10	Testing knock sensors	97
1.11	Testing Hall sender	99
2	Testing camshaft timing control	101
2.1	Testing camshaft timing control	101
2.2	Operation of camshaft timing control	101
2.3	Testing solenoid valves for camshaft adjustment (-N205 and -N208)	102