

Contents

01 - Self-diagnosis	1
1 Self-diagnosis of Motronic system	1
1.1 Self-diagnosis of Motronic system	1
1.2 Technical data of self-diagnosis	1
1.3 Safety precautions	1
1.4 Connecting vehicle diagnostic, testing and information system VAS 5051 or fault reader V.A.G 1551 and selecting functions	1
2 Interrogating and erasing fault memory	4
2.1 Interrogating and erasing fault memory	4
3 Fault table (16395 to 17658)	6
3.1 Fault table (16395 to 17658)	6
3.2 Fault table	6
4 Fault table (17695 to 18322)	12
4.1 Fault table (17695 to 18322)	12
5 Final control diagnosis	19
5.1 Final control diagnosis	19
6 Basic setting	23
6.1 Basic setting	23
7 Encoding control unit	24
7.1 Encoding control unit	24
7.2 Encoding table	25
8 Reading measured value block	26
8.1 Reading measured value block	26
9 Readiness code	27
9.1 Readiness code	27
9.2 Reading out readiness code	27
9.3 Generating the readiness code	29
24 - Mixture preparation, Injection	39
1 Servicing Motronic injection system	39
1.1 Servicing Motronic injection system	39
1.2 Safety precautions	39
1.3 Rules for cleanliness	39
1.4 Technical data	40
1.5 Fitting locations overview	41
1.6 Dismantling and assembling air cleaner	52
1.7 Wiring and component check with test box V.A.G 1598/31	53
1.8 Procedure following interruption of voltage supply	55
1.9 Replacing engine control unit	55
1.10 Exhaust warning lamp -K83 in dash panel insert	61
1.11 Checking exhaust warning lamp -K83	62
1.12 Checking idling speed	62
1.13 Checking system pressure, fuel pressure regulator and holding pressure	64
1.14 Checking injectors	67
1.15 Dismantling and assembling fuel rail with injectors	71
1.16 Removing and installing injectors	74
1.17 Checking injection quantity, absence of leaks and spray pattern of injectors	75
1.18 Checking fuel pump relay -J17 and actuation	77
1.19 Checking air mass meter -G70	81
1.20 Checking intake air system for leaks (unmetered air)	85
2 Checking lambda control	87
2.1 Checking lambda control	87



2.2	Checking lambda probe and lambda control upstream of catalytic converter	87
2.3	Checking lambda probe ageing upstream of catalytic converter	92
2.4	Checking lambda probe heating -Z19 for lambda probe upstream of catalytic converter. . .	95
2.5	Checking lambda probe and lambda control downstream of catalytic converter	98
2.6	Checking lambda probe heating -Z29 for lambda probe downstream of catalytic converter	104
2.7	Removing and installing lambda probe	107
3	Checking fuel tank breather	109
3.1	Checking fuel tank breather	109
3.2	Checking activated charcoal filter solenoid valve 1 -N80	109
4	Checking electronic engine output control (electronic throttle)	112
4.1	Checking electronic engine output control (electronic throttle)	112
4.2	Function of the electronic throttle system	112
4.3	Fault lamp for electronic throttle in dash panel insert	113
4.4	Checking electronic throttle control fault lamp -K132	114
4.5	Checking throttle valve control unit -J338	114
4.6	Performing adaption of throttle valve control unit	114
4.7	Check angle sender for throttle valve actuator	117
4.8	Check accelerator position sender	120
4.9	Adapting kick down function	123
4.10	Checking brake light switch and brake pedal switch	125
4.11	Checking clutch pedal switch -F36	129
5	Checking auxiliary signals	132
5.1	Checking auxiliary signals	132
5.2	Checking engine speed signal	133
5.3	Checking vehicle speed signal	133
5.4	Checking air conditioner compressor shut-off	134
5.5	Checking wiring for crash signal	135
5.6	Checking consumption signal for on-board computer	136
5.7	Checking fuel level signal wiring	136
5.8	Check signal for rough-road recognition	136
5.9	Checking the data exchange between engine control unit and other CAN-control units . . .	136
6	Vacuum diagram	140
6.1	Vacuum diagram	140
28 - Ignition system		144
1	Checking ignition system	144
1.1	Checking ignition system	144
1.2	General notes on ignition system	144
1.3	Safety precautions	144
1.4	Technical data	144
1.5	Checking ignition coils with output stages	145
1.6	Checking power supply relay for Motronic system -J271	151
1.7	Checking intake air temperature sender -G42	156
1.8	Checking engine speed sender -G28	159
1.9	Checking coolant temperature sender -G62	162
1.10	Checking control unit power supply	165
1.11	Checking knock control stop	166
1.12	Checking knock sensors	168
1.13	Checking Hall sender -G40	171
1.14	Checking misfire detection	174