

Contents

01 - Self-diagnosis	1
1 Self diagnosis for Motronic system	1
1.1 Self diagnosis for Motronic system	1
1.2 Technical data for self diagnosis	1
1.3 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit	2
1.4 Interrogating and erasing fault memory	3
1.5 Fault table	4
1.6 Final control diagnosis	14
1.7 Basic setting	15
1.8 Encoding control unit	17
1.9 Reading measured value block	18
1.10 Reading measured value block: Display Groups 00 to 10	24
1.11 Reading measured value block: Display Groups 08 to 99	30
24 - Mixture preparation, Injection	40
1 Repairing the Motronic injection system	40
1.1 Repairing the Motronic injection system	40
1.2 Safety precautions	40
1.3 Rules for cleanliness	40
1.4 Technical data	41
1.5 Fitting locations overview	42
1.6 Wiring and component test with test box V.A.G 1598/22	43
1.7 Replacing engine control unit	45
1.8 Testing idling speed	45
1.9 Testing fuel pressure regulator and holding pressure	46
1.10 Testing injection quantity, leak tightness and spray pattern of injectors	48
1.11 Removing and installing injectors	50
1.12 Checking injectors	51
1.13 Testing fuel pump relay	54
1.14 Testing air mass meter	56
2 Testing the boost pressure system	58
2.1 Testing the boost pressure system	58
2.2 Testing the boost pressure control	58
2.3 Checking the solenoid valve for boost pressure control	59
2.4 Checking the altitude sensor	61
3 Checking lambda control	63
3.1 Checking lambda control	63
3.2 Poor performance after cold start	63
3.3 Checking operation	64
3.4 Checking lambda probe heating	65
3.5 Testing lambda probe signal wiring and activation	67
3.6 Removing and installing lambda probe	68
4 Testing fuel tank breather system	68
4.1 Testing fuel tank breather system	68
4.2 Testing solenoid valve 1 for activated charcoal filter	68
5 Checking throttle valve control unit	72
5.1 Checking throttle valve control unit	72
5.2 Perform adaptation of the throttle valve control unit	72
5.3 Testing idling switch	73
5.4 Testing throttle valve potentiometer	75
5.5 Testing sensor for throttle valve positioner	76
5.6 Testing throttle valve actuator	77
6 Testing auxiliary signals	79

6.1	Testing auxiliary signals	79
6.2	Testing air conditioner compressor shut-off	79
6.3	Testing engine speed adaptation when air conditioner cuts in	80
6.4	Testing selector lever position on automatic gearbox	81
6.5	Testing engine speed signal	82
6.6	Checking throttle valve positioner	83
6.7	Testing speed signal	83
6.8	Testing gearshift signal when changing gear	84
28 - Ignition system		86
1	Checking ignition system	86
1.1	Checking ignition system	86
1.2	Safety precautions	86
1.3	Technical data	86
1.4	Checking ignition coils	87
1.5	Checking output stages for ignition coils	89
1.6	Checking intake air temperature sensor	91
1.7	Checking engine speed sensor	92
1.8	Checking coolant temperature sensor	94
1.9	Checking control unit power supply	95
1.10	Checking the knock sensors	96
1.11	Checking Hall sensor	97