

## Contents

<b>01 - Self diagnosis</b> .....	<b>1</b>
<b>1 Self-diagnosis of Motronic system</b> .....	<b>1</b>
1.1 Self-diagnosis of Motronic system .....	1
1.2 Technical data for self-diagnosis .....	1
1.3 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit .....	2
<b>2 Interrogating and erasing fault memory</b> .....	<b>3</b>
2.1 Interrogating and erasing fault memory .....	3
2.2 Fault table .....	4
<b>3 Final control diagnosis</b> .....	<b>9</b>
3.1 Final control diagnosis .....	9
<b>4 Basic setting</b> .....	<b>11</b>
4.1 Basic setting .....	11
<b>5 Coding control unit</b> .....	<b>13</b>
5.1 Coding control unit .....	13
<b>6 Reading measured value block</b> .....	<b>15</b>
6.1 Reading measured value block .....	15
<b>24 - Mixture preparation, Injection</b> .....	<b>16</b>
<b>1 Servicing Motronic injection system</b> .....	<b>16</b>
1.1 Servicing Motronic injection system .....	16
1.2 Safety precautions .....	16
1.3 Rules for cleanliness .....	16
1.4 Technical data .....	17
1.5 Fitting locations overview .....	18
1.6 Removing and installing parts of the injection system .....	22
1.7 Dismantling and assembling air cleaner .....	28
1.8 Dismantling and assembling fuel manifold with injectors .....	29
1.9 Removing and installing parts of intake manifold change-over system .....	30
1.10 Removing and installing throttle valve control part .....	32
1.11 Wiring and component check with test box V.A.G 1598/22 .....	35
1.12 Renewing engine control unit .....	36
1.13 Testing idling speed .....	37
1.14 Checking fuel pressure regulator and holding pressure .....	38
1.15 Testing injection quantity, leak-tightness and spray pattern of injectors .....	40
1.16 Checking injectors .....	42
1.17 Testing fuel pump relay .....	45
1.18 Checking air mass meter .....	48
<b>2 Testing intake manifold change-over function</b> .....	<b>51</b>
2.1 Testing intake manifold change-over function .....	51
2.2 Testing operation .....	51
2.3 Testing intake manifold change-over valve .....	52
2.4 Testing vacuum system for leaks .....	55
<b>3 Testing lambda control</b> .....	<b>56</b>
3.1 Testing lambda control .....	56
3.2 Testing lambda probe and lambda control .....	56
3.3 Testing lambda probe heating .....	63
<b>4 Testing fuel tank breather system</b> .....	<b>65</b>
4.1 Testing fuel tank breather system .....	65
4.2 Testing solenoid valve 1 for activated charcoal filter .....	65
<b>5 Testing throttle valve control part</b> .....	<b>68</b>
5.1 Testing throttle valve control part .....	68
5.2 Performing adaption of throttle valve control part .....	69



5.3	Testing idling speed switch . . . . .	70
5.4	Testing throttle valve potentiometer . . . . .	72
5.5	Testing angle sender for throttle valve drive . . . . .	74
5.6	Testing throttle valve drive . . . . .	76
<b>6</b>	<b>Testing auxiliary signals . . . . .</b>	<b>77</b>
6.1	Testing auxiliary signals . . . . .	77
6.2	Testing air conditioner compressor shut-off . . . . .	77
6.3	Testing engine speed adaption when air conditioner cuts in . . . . .	79
6.4	Testing drive range sensor on automatic gearbox . . . . .	81
6.5	Testing engine speed signal . . . . .	82
6.6	Testing throttle valve position . . . . .	83
6.7	Checking speed signal . . . . .	83
6.8	Checking gearbox intervention signal when a gear is changed . . . . .	85
6.9	Testing signal for actual engine torque . . . . .	86
6.10	Testing signal for specified engine torque from ABS/ASR control unit . . . . .	86
<b>28</b>	<b>- Ignition system . . . . .</b>	<b>88</b>
<b>1</b>	<b>Testing ignition system . . . . .</b>	<b>88</b>
1.1	Testing ignition system . . . . .	88
1.2	General notes on the ignition system . . . . .	88
1.3	Safety precautions . . . . .	88
1.4	Technical data . . . . .	89
1.5	Removing and installing parts of the ignition system . . . . .	89
1.6	Testing ignition coils -N, -N128 and -N158 with output stage -N122 . . . . .	91
1.7	Testing intake air temperature sender . . . . .	95
1.8	Testing engine speed sender . . . . .	97
1.9	Testing coolant temperature sender . . . . .	99
1.10	Checking voltage supply to control unit . . . . .	101
1.11	Testing knock sensor control limit . . . . .	101
1.12	Testing knock sensors . . . . .	102
1.13	Testing Hall sender . . . . .	104
<b>2</b>	<b>Testing camshaft timing control . . . . .</b>	<b>107</b>
2.1	Testing camshaft timing control . . . . .	107
2.2	Operation of camshaft timing control . . . . .	107
2.3	Testing solenoid valves for camshaft adjustment (-N205 and -N208) . . . . .	108