

Contents

01 - Self-diagnosis	1
1 Self-diagnosis of Motronic system	1
1.1 Self-diagnosis of Motronic system	1
1.2 Technical data for self-diagnosis	1
1.3 Connecting vehicle diagnostic, testing and information system VAS 5051 or fault reader V.A.G 1551 and selecting functions	1
2 Interrogating and erasing fault memory	4
2.1 Interrogating and erasing fault memory	4
2.2 Fault table	5
3 Final control diagnosis	14
3.1 Final control diagnosis	14
4 Basic setting	17
4.1 Basic setting	17
5 Coding control unit	19
5.1 Coding control unit	19
6 Reading measured value block	20
6.1 Reading measured value block	20
24 - Mixture preparation, Injection	22
1 Servicing Motronic injection system	22
1.1 Servicing Motronic injection system	22
1.2 Safety precautions	22
1.3 Rules for cleanliness	22
1.4 Technical data	23
1.5 Fitting locations overview	23
1.6 Removing and installing parts of the injection system	28
1.7 Dismantling and assembling air cleaner	34
1.8 Dismantling and assembling fuel rail with injectors	35
1.9 Removing and installing parts of intake manifold change-over	36
1.10 Wiring and component check with test box V.A.G 1598/31	37
1.11 Renewing engine control unit	38
1.12 Testing idling speed	40
1.13 Checking fuel pressure regulator and holding pressure	41
1.14 Checking injectors	43
1.15 Testing injection quantity, leak-tightness and spray pattern of injectors	47
1.16 Testing fuel pump relay and activation	49
1.17 Checking air mass meter	51
1.18 Checking intake air system for leaks (unmetered air)	55
2 Testing intake manifold change-over function	55
2.1 Testing intake manifold change-over function	55
2.2 Testing operation	56
2.3 Testing vacuum system	56
2.4 Testing intake manifold change-over valve	57
3 Testing lambda control	60
3.1 Testing lambda control	60
3.2 Operation of lambda control	60
3.3 Testing lambda probe and lambda control	60
3.4 Testing lambda probe heating	67
3.5 Removing and installing lambda probe	70
4 Testing secondary air system	71
4.1 Testing secondary air system	71
4.2 Testing secondary air inlet valve	71
4.3 Testing secondary air pump replay	72

5	Testing fuel tank breather system	73
5.1	Testing fuel tank breather system	73
5.2	Testing solenoid valve 1 for activated charcoal filter	73
6	Testing electronic engine power control (electronic throttle)	76
6.1	Testing electronic engine power control (electronic throttle)	76
6.2	Operation of electronic throttle system	76
6.3	Notes on EPC warning lamp (fault warning lamp for electronic throttle) in dash panel insert	77
6.4	Testing throttle valve control part	78
6.5	Performing adaption of throttle valve control part	79
6.6	Testing angle sender for throttle valve drive	81
6.7	Checking accelerator position sender	83
6.8	Learning kickdown function	86
7	Testing auxiliary signals	87
7.1	Testing auxiliary signals	87
7.2	Checking engine speed signal	87
7.3	Testing fuel consumption signal for on-board computer	87
7.4	Testing brake light switch and brake pedal switch	88
7.5	Testing clutch pedal switch	90
7.6	Testing road speed signal	92
7.7	Testing data exchange between engine control unit, ABS control unit and gearbox control unit	92
28 - Ignition system	94	
1	Testing ignition system	94
1.1	Testing ignition system	94
1.2	General notes on ignition system	94
1.3	Safety precautions	94
1.4	Technical data for ignition system	94
1.5	Removing and installing parts of the ignition system	95
1.6	Testing ignition coils	97
1.7	Checking intake air temperature sender	100
1.8	Checking engine speed sender	102
1.9	Testing coolant temperature sender	104
1.10	Checking control unit voltage supply	105
1.11	Testing knock sensor control limit	106
1.12	Testing knock sensors	106
1.13	Testing Hall sender	109